


Service Manual

Video Cassette Recorder

Panasonic**HQ DIGITAL****NV-D48^{EG}_B**

General Description
Adjustment Procedures
Block / Schematic Diagrams
Exploded Views / Parts List



SPECIFICATIONS

ITEM	SPECIFICATION		ITEM	SPECIFICATION
POWER	SOURCE: 220 V 50/60 Hz (NV-D48EG) 240 V 50/60 Hz (NV-D48B)		AUDIO	HEAD: 1 Stationary head (Normal Audio)
	CONSUMPTION: 29 W (NV-D48EG) 28 W (NV-D48B)			INPUT: AUDIO IN Connector (Phono type) More than - 10 dBV (316 mV), more than 50 kΩ (NV-D48EG/B) EURO AV Connector (21 pin) More than - 10 dBV (316 mV), more than 10 kΩ (NV-D48EG)
RECORDING SYSTEM	2 rotary heads, helical scanning system			OUTPUT: AUDIO OUT Connector (Phono type) - 8 dBV (400 mV), Less than 1 kΩ (NV-D48B) EURO AV Connector (21 pin) - 6 dBV (500 mV), Less than 1 kΩ (NV-D48EG)
	PAL			
TV TUNER SYSTEM	NV-D48EG	VHF I: CH E2 ~ CH E4 VHF III: CH S4 ~ CH E12 VHF H: CH S11 ~ CH S41 (PAL/SECAM B) 75Ω unbalanced UHF: CH 21 ~ CH 69 (PAL/SECAM G) 75Ω unbalanced	TAPE FORMAT	VHS Cassette tape (Tape width 12.7 mm)
	NV-D48B	UHF: CH 21 ~ CH 69 (PAL I) 75Ω unbalanced	TAPE SPEED	23.39 mm/s Record/Playback Time: 4 hours with 240 min. type tape FF/REW Time 5.5 min. with 180 min. type tape
RF OUT SYSTEM	UHF: CH 36 ± 4 (PAL/SECAM G) 73 ± 2 dBμ, 75Ω terminated (NV-D48EG) UHF: CH 36 ± 4 (PAL I) 73 ± 3 dBμ, 75Ω terminated (NV-D48B)		DIMENSIONS	430(W) × 82(H) × 357.5(D) mm
VIDEO	HEADS: 4 rotary heads 1 pair for recording, playback (L-R heads) 1 pair for trick play (L' - R' heads)		WEIGHT	5.9 kg
	INPUT: VIDEO IN Connector (BNC type) 1.0 Vp-p, 75Ω terminated (NV-D48EG/B) EURO AV Connector (21 pin) 1.0 Vp-p, 75Ω terminated (NV-D48EG)		STANDARD ACCESSORIES	1 pc. DIN-RF Cable 1 pc. Infra-red remote controller 1 pc. Digital Scanner Case 1 pc. Digital Scanner 1 pc. Programme sheet 1 pc. AC Mains Lead 1 pc. Cleaning Brush
	OUTPUT: VIDEO OUT Connector (BNC type) 1.0 Vp-p, 75Ω terminated (NV-D48B) EURO AV Connector (21 pin) 1.0 Vp-p, 75Ω terminated (NV-D48EG)			

Weight and dimensions shown are approximate.
Specifications are subject to change without notice.

Panasonic

Matsushita Electric Trading Co., Ltd.

P.O. Box 288, Central Osaka Japan

INTRODUCTION

This service manual contains technical information which will allow service personnels to understand and service this model.

Section 1 presents you with some general information of features and controls, enabling you to become familiar with each function.

Section 2 contributes to your mechanical and electrical adjustment as well disassembly and replacement procedures.

In the case of very common information relating to other models like mechanical adjustments, please refer to each service manual.

Section 3 contains block diagrams which offers you information for checking and understanding each circuit. Schematic diagrams which give you detailed information such as waveforms, voltage data, function e.t.c...

Section 4 contains exploded views and parts list.

Please place orders using the parts list and not the drawing reference numbers.

If the circuit is changed or modified, this information will be followed by supplementary service manual to be filed with original service manual.

CONTENTS

TECHNICAL INFORMATION

SECTION 1

GENERAL DESCRIPTIONS	1-1
1-1. FEATURES	1-1
1-2. CONTROLS & COMPONENTS	1-2
1-3. PROGRAMMABLE REMOTE CONTROLLER AND DIGITAL SCANNER	1-4
1-4. DIGITAL SPECIAL EFFECTS	1-6
1-5. DIGITAL INTRO SCAN FUNCTION	1-8
1-6. VHS INDEX SEARCH SYSTEM	1-9
1-7. TIME SEARCH	1-10

SECTION 2

ADJUSTMENT PROCEDURES	2-1
2-1. MECHANICAL ADJUSTMENT PROCEDURES	2-1
2-2. DISASSEMBLY METHOD	2-1
2-3. ELECTRICAL ADJUSTMENT PROCEDURES	2-4

SECTION 3

BLOCK DIAGRAMS & SCHEMATIC DIAGRAMS	3-1
3-1. SYSTEM CONTROL & TIMER BLOCK DIAGRAM	3-1
3-2. SERVO BLOCK DIAGRAM	3-4
3-3. LUMINANCE & CHROMINANCE BLOCK DIAGRAM	3-7
3-4. DIGITAL BLOCK DIAGRAM	3-9
3-5. POWER SCHEMATIC DIAGRAM	3-11
3-6. POWER C.B.A.	3-13
3-7. POWER SUPPLY Section In Main C.B.A.	3-15
3-8. SYSTEM CONTROL SCHEMATIC DIAGRAM	3-16
3-9. SERVO SCHEMATIC DIAGRAM	3-19
3-10. SYSTEM CONTROL & SERVO Section In Main C.B.A.	3-23
3-11. SUB MAIN PACK SCHEMATIC DIAGRAM	3-27
3-12. VISS PACK SCHEMATIC DIAGRAM	3-31

3-13. SUB MAIN PACK C.B.A. & VISS PACK C.B.A.	3-33
3-14. LUMINANCE & CHROMINANCE SCHEMATIC DIAGRAM	3-36
3-15. LUMINANCE & CHROMINANCE PACK SCHEMATIC DIAGRAM	3-38
3-16. LUMINANCE & CHROMINANCE Section In Main C.B.A.	3-41
3-17. LUMINANCE & CHROMINANCE PACK C.B.A.	3-44
3-18. HEAD AMP SCHEMATIC DIAGRAM	3-46
3-19. HEAD AMP C.B.A.	3-48
3-20. INPUT/OUTPUT PACK C.B.A. (NV-D48EG)	3-50
3-21. INPUT/OUTPUT PACK SCHEMATIC DIAGRAM (NV-D48EG)	3-51
3-22. SUB DIGITAL SCHEMATIC DIAGRAM	3-54
3-23. SUB DIGITAL C.B.A.	3-57
3-24. MAIN DIGITAL SCHEMATIC DIAGRAM	3-60
3-25. MAIN DIGITAL C.B.A.	3-63
3-26. AUDIO SCHEMATIC DIAGRAM	3-66
3-27. AUDIO Section In Main C.B.A.	3-69
3-28. CH SELECT Section In Main C.B.A.	3-71
3-29. CH SELECT SCHEMATIC DIAGRAM	3-73
3-30. TUNER & TV DEMODULATOR PACK SCHEMATIC DIAGRAM (NV-D48EG)	3-76
3-31. TUNER & TV DEMODULATOR PACK C.B.A. (NV-D48EG)	3-79
3-32. TUNER & TV DEMODULATOR PACK C.B.A. (NV-D48B)	3-81
3-33. TUNER & TV DEMODULATOR PACK SCHEMATIC DIAGRAM (NV-D48B)	3-83
3-34. TIMER & OPERATION SCHEMATIC DIAGRAM	3-86
3-35. TIMER C.B.A. & OPERATION C.B.A.	3-89
3-36. VPS PACK SCHEMATIC DIAGRAM (NV-D48EG)	3-92
3-37. VPS PACK C.B.A. (NV-D48EG)	3-94
3-38. MAIN C.B.A.	3-95
3-39. RF CONVERTER SCHEMATIC DIAGRAM (NV-D48EG)	3-98
3-40. RF CONVERTER SCHEMATIC DIAGRAM (NV-D48B)	3-98
3-41. DIGITAL SCANNER SCHEMATIC DIAGRAM	3-99
3-42. DIGITAL SCANNER C.B.A.	3-101
3-43. REMOTE CONTROLLER SCHEMATIC DIAGRAM	3-103
3-44. REMOTE CONTROLLER C.B.A.	3-104
3-45. INTERCONNECTION SCHEMATIC DIAGRAM	3-105
3-46. ICs & TRs INFORMATION	3-108

SECTION 4

EXPLODED VIEWS & PARTS LIST 4-1

4-1. EXPLODED VIEW	4-1
1. CHASSIS PARTS SECTION (1)	4-1
2. CHASSIS PARTS SECTION (2)	4-2
3. CASSETTE UP MECHANISM SECTION	4-3
4. CASING PARTS SECTION	4-4
5. PACKING PARTS SECTION	4-5
6. REMOTE CONTROLLER UNIT	4-6
7. DIGITAL SCANNER	4-7

MECHANICAL REPLACEMENT PARTS LIST

ELECTRICAL REPLACEMENT PARTS LIST

REMARKS (NV-D48EG West Germany model only)

1. It is possible to receive, record and play back colour broadcasts from East Germany (DDR) on this video recorder.
2. When a video tape that was recorded with a colour TV broadcast from East Germany on this VTR is played back on a SECAM (France) or a PAL VTR, the picture may be in black and white.
3. When a video tape recorded on a SECAM (France) VTR or a SECAM (France) pre-recorded video tape is played back on this VTR, the picture is in black and white.

Technical Information

Subject: How to make easier servicing

We are pleased to inform you how to make easier servicing of NV-D48EG/B.

1. HOW TO MAKE EASIER SERVICING OF A PACKED CIRCUIT

In the case of the Luminance & Chrominance Pack and Sub Main C.B.A., you can remove the Main C.B.A. from its frame. At that time unlock the 2 Hinges and lift up paying attention not touch any other portion as shown in Fig. T1 and Fig. T2.




Fig. T1

2. HOW TO CHECK OR REPLACE THE TIMER CIRCUIT

When checking or replacing the Timer circuit, the following steps should be followed to protect this circuit.

- (1) Disconnect the AC mains.
- (2) Make a short circuit at C7571 by connecting a wire to both lead wires of the C7571.




Fig. T3




Fig. T2

3. HOW TO USE THE UPPER CYLINDER REMOVER

The newly developed Upper Cylinder Remover is usefull to remove the upper cylinder easily, especially when it is too hard to remove by hand, Removing procedure is also as described below.

- (1) Remove 2 screws (A), then unsolder the soldered portions indicated by arrows as shown in Fig. T5.
- (2) Set the screws of Upper Cylinder Remover into holes (B), then tighten the screws of Upper Cylinder Remover fully.
- (3) Turn the handle of Upper Cylinder Remover clockwise holding the upper cylinder firmly until it is removed.
(Upper Cylinder is lifted up gradually during turning the handle.)




Fig. T4 UPPER CYLINDER REMOVER (VFK0341)

NOTE:

1. This Upper Cylinder Remover also can be used for other conventional VHS video head cylinder.
2. Work with extreme care when removing or replacing the upper cylinder unit. Do not touch video heads during servicing.

4. CLEANING BRUSH FOR THE DIGITAL SCANNER

If the sensor in the tip of the Digital Scanner becomes clogged with dirt, it may become impossible to read the bar codes. Clean the tip from time to time with the supplied brush as illustrated below.

Keep this brush in the storage case of the Digital Scanner.




Fig. T5

SECTION 1

GENERAL DESCRIPTIONS

1-1. FEATURES

1. HQ (High Quality) Picture System

Video recorders carrying the HQ symbol mark feature the new VHS High Quality Picture System. This system assures complete compatibility with VTRs that use the conventional VHS system.

2. Multi-Function Display

Whenever an operation button is pressed, the activated function is immediately indicated on this easy-to-see display. It shows you at a glance, in what operation mode the VTR is functioning.

3. Programmable Remote Controller

In addition to letting you control all major VTR functions, this handy Remote Controller also lets you programme timer recordings from the comfort of your armchair.

4. LCD Digital Scanner

This Digital Scanner makes it possible to programme timer recordings by tracing the corresponding bar codes on the supplied Programming Sheet. The traced programming data can be confirmed on the built-in Bar Code Reader Display before they are transmitted to the VTR at the push of a button.

5. Reception of up to 99 TV Stations

The built-in tuner in this VTR allows pre-tuning of as many as 99 TV stations. So this VTR can accommodate virtually any increase in available TV programmes in the future.

6. Slim Design and Front Loading System

This highly functional design allows loading the video cassette from the front, thus minimizing the space required for the placement.

7. Auto Operation

The extremely convenient Auto Operation functions of this VTR include Auto Start and Auto Play when a recorded cassette is inserted, Auto Eject which indicates that an inserted cassette is not suitable for recording, VTR-Off Eject for ejecting a cassette even with the VTR off, and Auto Rewind at the end of a tape. If the VTR On/Off Switch is pressed during the rewind mode including Auto Rewind, the VTR will eject the cassette and turn itself off when rewinding is completed.

8. Picture Sharpness Control

With this control, the contours of the playback picture can be made sharper or softer.

9. Lap Time Counter

The new Lap Time Counter is a great improvement over the approximate counter systems of conventional VTRs. It gives you an exact reading of the elapsed tape time in hours, minutes and seconds, and makes it easy to calculate the tape time left on a cassette.

10. Super Still, Super Still Advance and Double Super Fine Slow Playback

Super Still, Super Still Advance and Double Super Fine Slow Playback are possible with superb picture quality free from noise and jitter.

11. Super OTR Function (One-Touch Timer Recording)

This convenient function makes it possible to easily programme the VTR for recording of TV programmes with immediate start or with start within 24 hours by precisely setting the starting time and ending time to the desired minute. When the recording ends, the VTR will automatically turn itself off.

12. 1-Month Calendar Timer

The clock/timer of the VTR is programmed with the calendar up to the end of 2002, so it knows exactly what day of the week it is on any given date. Programming of as many as 8 timer recordings is possible up to one month in advance.

13. VPS (Video Programme System) (NV-D48EG)

The Video Programme System is an extremely convenient system which assures that the TV programmes you have programmed for timer recording will be recorded exactly from beginning to end, even if the actual broadcasting time is different from the scheduled time.

14. Digital Special Effect

The special digital picture effects can be enjoyed by using the Remote Controller.

15. VHS Index Search System

With the Index Search function, up to 20 addresses (places where an index signal is recorded) can be skipped to directly locate the beginning of the desired programme in forward or reverse direction in the Fast Forward or Rewind mode.

16. Time Search


It is possible to locate the desired scene directly by inputting the hour, minute and second of that scene.

17. Digital Intro Scan Function

The Intro Scan function plays back one after another the first 10 seconds of each programme on a tape and keeps a still picture of the last 3 programmes on the right side of the screen. This is convenient for easy checking what programmes are on a tape and to quickly find a desired programme.

1-2. CONTROLS & COMPONENTS

FRONT



① Cassette-in Indicator

② VTR On/Off Switch with Indicator

③ Tracking Control

④ Slow Tracking Control

⑤ Picture Sharpness Control

⑥ Edit Switch

When the Dubbing (copying) from one video cassette to another VTR and receiving weak TV broadcasts from Tuner, the Edit Switch should be set to "On" position.

⑦ Cassette Compartment

⑧ Tuner Set-up Controls

The tuner in the VTR can be preset with up to 99 stations.

	VHF			UHF
	I	III	H	U
NV-D48EG	E2-E4	S4-E12	S11-S41	21-69
NV-D48B	—	—	—	21-69

⑨ Clock Button

⑩ Timer Controls

⑪ VPS Button (NV-D48EG)

⑫ Timer Record Button

⑬ Control Panel Open Button

14 Infra-red Remote Control Receiver Window

15 Multi-Function Display

16 Eject Button (▲)

17 Rewind ◀◀/Review ◀▶ Button

18 Play Button (▶)

19 Fast Forward ▶▶/Cue ▶▶▶▶ Button

20 Stop Button (■)

21 Pause/Still Button (||)

22 Record Button (●)

23 Memory/Search Button

When this button is pressed once, the Memory Indicator "M" will light up, and when it is pressed one more time, the Search Indicator "S" will appear instead. When it is pressed a third time the Search Indicator "S" will disappear.

24 Reset/Index Button

25 Euro AV Button (NV-D48EG)

26 Channel Selection Up and Down Buttons

27 OTR On Buttons

28 OTR Off Buttons

4 Date Display

5 Clock Display

6 VPS Indicator (NV-D48EG)

7 OTR Indicator

8 Timer Recording Indicator

9 Timer Programme Number

10 Tape Running Display

11 Double Speed Indicator


12 Memory Indicator

13 Tape Counter Mode Indicator

14 Search Indicator

15 Lap Time Counter Display

Multi-Function Display




1 Recording Indicator

2 Euro AV Indicator (NV-D48EG)

3 Channel Display

REAR (NV-D48EG)



1 Audio Input Socket

2 Video Input Socket

3 DBS Switch (NV-D48EG)

4 Test Signal Switch

5 RF Output Socket


6 AC Mains Lead Socket

7 Euro AV Socket

⑧ Synchro Edit Socket

⑨ RF Input Socket

REAR (NV-D48B)




No. Description

- ① Audio Input Socket
- ② Video Input Socket
- ③ Audio Output Socket
- ④ Video Output Socket
- ⑤ RF Input Socket
- ⑥ RF Signal Level Switch
- ⑦ AC-IN Socket
- ⑧ Video Playback Channel Selector
- ⑨ RF Output Socket
- ⑩ Test Signal Switch
- ⑪ Synchro Edit Socket


1-3. PROGRAMMABLE REMOTE CONTROLLER AND DIGITAL SCANNER

Part Number: VEQ0709 (NV-D48EG)
VEQ0710 (NV-D48B)




- ① VTR On/Off Button
- ② Memory/Search Button
- ③ Reset/Index Button
- ④ Timer Recording & Programme Position Selector Buttons
- ⑤ Record Buttons (●)
- ⑥ Pause/Still Button (II)
- ⑦ Rewind ◀◀/Review ◀◀ Button
- ⑧ Slow Buttons
- ⑨ Reverse Play Button
- ⑩ Digital Function Buttons
- ⑪ Intro Scan Button
- ⑫ Double Speed Playback Button (×2)
- ⑬ Fast Forward ▶▶/Cue ▶▶ Button
- ⑭ Play Button (▶)
- ⑮ Still Advance Button (II▶)
- ⑯ Stop Button (■)
- ⑰ Time Search Button
- ⑱ +/- Button

Part Number: VEQ0691 (NV-D48EG)
VEQ0692 (NV-D48B)



- ① Transmit Button
- ② Bar Code Reading Section
- ③ Digital Scanner On/Off Switch
- ④ Bar Code Reader Display



- ① Date Display
- ② Start Time Display
- ③ End Time Display
- ④ VPS Indicator (NV-D48EG)
- ⑤ Channel Display
- ⑥ Check Indicator

⑤ Transmitting Section


How to Operate the Digital Scanner

Set the digital Scanner On/Off Switch to "ON".

- If no operation is performed for more than 25 seconds, the scanner will automatically switch over to the power-saving standby condition and the lamp will go off. (In this case, if bar codes have already been read but not yet transmitted to the VTR, the data will be cancelled.)
- When the Digital Scanner On/Off Switch is set to "ON" but the lamp is not lit, set the switch to "OFF" and then to "ON" again.

Tracing the Bar Codes

- (A) Place the Digital Scanner vertically on the Small Box.
- (B) Trace the bar code quickly in the direction of the arrow.




Multi-Language Instruction Stickers

To facilitate the use of the Programming Sheet, select the stickers with the instructions in your own language and attach them on the English indications on the Programming Sheet.

Cleaning Brush for the Digital Scanner

If the sensor in the tip of the Digital Scanner becomes clogged with dirt, it may become impossible to read the bar codes. Clean the tip from time to time with the supplied brush as illustrated below.

Keep this brush in the storage case of the Digital Scanner.



- Treat the Programming Sheet with care. If the sheet gets dirty or scratched, the bar code reading may become impossible.
- Protect the Digital Scanner from strong shocks and vibration. Keep it away from water and places with high temperature and humidity.
- If the bar code is traced slowly, it cannot be read correctly.
- When there is no "Beep" sound, the reading of the bar code is incomplete. Trace the bar code again.
- When using the Programming Sheet, put it on flat surface. Reading the bar codes while holding it in your hand or bending it, may result in incorrect operation.
- Do not deviate from the bar code, nor stop tracing halfway.
- Do not slant the scanner to trace the bar code.


Note:

- The infra-red beam should be transmitted directly at the Infra-red Remote Control Receiver on the front of the VTR.
- Direct sunlight may interfere with the beam.
- The lightsensing angle of the Infra-red Remote Control Receiver window in the VTR is about 60°.
- The unit should be used within a range of about 7 meters from the front of the VTR.

Recommendation

To save battery power, make sure to set the Digital Scanner On/Off Switch to "OFF" after using the Digital Scanner. When the batteries are exhausted, the bar code reading can no longer be performed.


- Only the sound of the large picture is reproduced.




- The TV channel can be changed with the Programme Position Selector Buttons either on the Remote Controller or on the VTR itself.

1-4. DIGITAL SPECIAL EFFECTS

The special digital picture effects can be enjoyed by using the Remote Controller.



- By pressing the "P in P" Button repeatedly, the position of the small picture can be changed as follows.




- By pressing the / Button, the large picture can be changed into the small one and vice versa.
 - Depending on the TV set used, there may be some momentary picture distortion when they are exchanged.
- To return to the normal (single-picture) playback, press the CLEAR Button.
- To watch the TV broadcast alone on the whole screen, press the STOP Button.
- When the 3-SCREEN Button is pressed during the Picture-in-Picture playback, the small picture will be displayed in the 3-Screen Multi Select mode.
- When the F. STORE Button is pressed during the Picture-in-Picture playback, the small picture will be displayed in the 1/4-Screen Frame Store mode.

Picture-in-Picture

This function makes it possible to watch a TV programme while playing back a tape.

- The Picture-in-Picture function works in any of the playback functions: normal playback, Cue, Review, Still and Slow.


- When the "P in P" Button is pressed during playback of a tape, a small picture of the TV channel selected on the VTR appears in the bottom right corner of the screen.



1/4-Screen Frame Store

This function can be used to freeze the action at any desired moment and superimpose it as a still picture in 1/4-screen size onto the moving playback picture. The reproduction of the sound of the moving picture (full screen) will continue normally. In addition to the playback of video tapes, this 1/4-Screen Frame Store function can also be used for TV broadcasts (received with the TV tuner in the VTR) as well as for pictures input from an external source.

- ① When the F. STORE Button is pressed, a still-picture of that moment's action will appear in the bottom right quarter of the screen.




- Every time the F. STORE Button is pressed, the moving picture of that moment will be displayed as a still-picture.
- When this button is kept pressed, still pictures taken at half-second intervals will be displayed for a strobe-like effect.

- ② To return to the former condition (single-picture playback or TV broadcast), press the CLEAR Button.
- ③ If the RECALL Button is pressed, the screen will return to the condition before the CLEAR Button was pressed.

3-Screen Multi Select

- ① When the 3-SCREEN Button is pressed, three small pictures frames will appear on the right side of the screen and can be filled with still-pictures from top to bottom.




- Press the 3-SCREEN Button successively at the scenes which you want to display as still-pictures. The still-pictures will be displayed and updated from top to bottom.
 - When this button is kept pressed, the still-pictures will be displayed in 0.3-second intervals.
- ② To return to the former condition (single-picture playback or TV broadcast), press the CLEAR Button.
 - ③ If the RECALL Button is pressed, the screen will return to the condition before the CLEAR Button was pressed.

- When "S" Mark in the Multi-Function Display is lit, the digital function buttons cannot be operated. If you want to use the Digital Functions, press the Memory/Search button (the "S" Mark will disappear).
- NV-D48EG model only
The digital special effects cannot be used for SECAM (OST) signals.

About the Superimposed Small Pictures


- The picture may vibrate vertically, be distorted and the colour may be unstable. However, this is not due to any malfunction.
- Depending on the type of TV set used, the small pictures may not display the full picture content.
- When the moving picture is in black-and-white, the small pictures are also in black-and white.
- When the special playback signals (Cue, Review, Still, Slow etc.) are being input from another VTR, the small picture may be distorted.

1-5. DIGITAL INTRO SCAN FUNCTION



The Intro Scan function plays back the first 10 seconds of each programme (marked by an index signal) on a tape one after another on the full screen. The first picture of each of these 10-second segments is then frozen and displayed as a still-picture in the 3-Screen Multi Select mode on the right side of the TV screen from the top to the bottom.

Convenient Digital Intro Scan Operation with the Remote Controller




- ① Insert a video cassette on which index signals are recorded.
- ② Put the VTR in the stop mode or the still playback mode.
- ③ Press the Intro Scan Button.
(The blank three small pictures will appear on the right of the screen, "S" mark will light up in the Multi-Function Display, and the Digital Intro Scan will start.)
- ④ When the desired scene is reached, press the Play Button.
• If you want to use the Digital Function after that, press the Memory/Search Button (the "S" Mark will disappear).

Digital Intro Scan Operation on the VTR


- ① Insert a video cassette.
(Put the VTR in the stop mode.)
- ② Press the Memory/Search Button twice.
(The blank three small picture appears on the right of the screen and "S" mark appears.)
- ③ Press the Fast Forward ►►/Cue ◀▶ Button.
(The Intro Scan starts.)
- ④ When the desired scene is reached, press the Play Button.
• If you want to use the Digital Function after that, press the Memory/Search Button (the "S" Mark will disappear).

- The Intro Scan function may not be activated for the first programme recorded close to the beginning of the tape.
- During the Intro Scan, if there is a portion without any recording on the tape, the Intro Scan function will be activated at that position to play back the tape for about 10 seconds, and the Intro Scan will then continue.
- The Intro Scan function may not be activated, if the interval between programme starts is less than 2 minutes.
- If a portion without any recording on the tape continues for more than about 50 minutes, the Intro Scan function will be cancelled and the playback will start.


- During the Digital Intro Scan, if there is no input signal, the VTR will automatically be in same condition as the Test Signal Switch is "ON" and the small pictures will be in black-and-white.



1-6. VHS INDEX SEARCH SYSTEM




With the Index Search function, up to 20 addresses (places where an index signal is recorded) can be skipped to directly locate the beginning of the desired programme in forward or reverse direction in the Fast Forward or Rewind mode.



A special index signal (for use of the VHS Index Search function) is automatically recorded every time the Record Button is pressed. If you want to record an additional index signal during the recording of a programme, press the Record Button again at the desired point.

- ① Press the Play Button (▶) or Stop Button (■).
- ② Press the Memory/Search Button twice.
 - The indication "S" appears on the Multi-Function Display.
- ③ Repeatedly press the Reset/Index Button to select the desired address.
 - The number of the selected address is shown on the Multi-Function Display.




- ④ Press the Rewind ◀◀/Review ◀▶ or Fast Forward ▶▶/Cue ▶▶ Button to start the VHS Index Search function (the VTR will switch to the rewind or fast-forward mode).

- Every time an index signal (address) is skipped the number in the Address Indication decreases by one.
- When the preset address is reached, the Tape Counter Indication will appear in place of the Address Indication, and the normal playback will start.
- To abort the Index Search function midway, press the Play or the Stop Button.

- If the recording is stopped temporarily by pressing the Pause Button and is later resumed, no index signal will be recorded at that position.
- It is impossible to record only index signals onto a tape that has already been recorded.
- If a tape position without any recording is passed during the Index Search function, that position may be counted as an address.
- The Index Search function can only count the addresses correctly, if the index signals are spaced at least 2 minutes.
- If the Index Search function is started extremely close to the beginning of the next programme (address) or from the beginning of the tape, the first address may not be counted.
- If you want to use the Digital Function after searching desired programme, press the Memory/Search Button (the "S" Mark will disappear).

1-7. TIME SEARCH

It is possible to locate the desired scene directly by inputting the hour, minute and second of that scene.




③ Press the Fast Forward ►►/Cue [] Button.

- The VTR automatically judges whether the tape should be fast-forward or rewind and performs the appropriate operation.
- When the designated time is reached, the playback starts.


- The numbers in the Tape Counter do not change during parts of the tape on which there is no recording.
- When the tape is ejected, the Tape Counter will automatically be reset to "0:00.00".

Put the VTR in Stop mode.

- ① Press the Time Search Button.
The indication in the Multi-Function Display changes as shown below.



- ② Input the time of the desired scene.
- The time is input by pressing the number buttons in the order: hour, minute, second.
 - The "-" indication will be counted as "0".
 - If you want to input an earlier time than "0:00.00", press the +/- Button so that the "-" indication appears ahead of the counter indication.



SECTION 2 ADJUSTMENT PROCEDURES

2-1. MECHANICAL ADJUSTMENT PROCEDURES

This Mechanical Chassis of these models NV-D48EG/B is the same as G Mechanical Chassis.
Therefore please refer to the Service Manual G Mechanical Chassis (Order No. VRD8701105).

2-2. DISASSEMBLY METHOD

2-2-1. DISASSEMBLY FLOW CHART

This flowchart indicates disassembly steps of the cabinet parts and the circuit boards in order to find the necessary items for servicing.
When reassembling, perform the steps in the reverse order.

NOTE:

When removing the Front Panel, be careful to avoid any damages for the locking portions of the panel.




Fig. D1

2-2-2. DETAIL OF DISASSEMBLY METHOD

1.REMOVAL OF THE TOP CASE

Remove the 4 screws (A), then carefully lift the rear of the Top Case to remove.




Fig. D2

2.REMOVAL OF THE BOTTOM PLATE

Place the deck upside down so that the bottomside faces upward.
Then remove the 8 screws (B).




Fig. D3

NOTE:

Place the cushion under the deck to avoid any damages.

3.REMOVAL OF THE FRONT PANEL

Open the Operation(Key Board) Unit and remove the screw (C) and unlock the 5 locking portions (D). Then hold the top portion of the panel and turn it toward the front side of the deck to remove.




Fig. D4

NOTE:

Place the cushion under the deck to avoid any damages.

4.REMOVAL OF THE OPERATION (KEY BOARD) UNIT

Remove the screw (E). Disconnect the connector P7504 (F) and remove the flexible wire. Then carefully remove the Operation (Key Board) Unit.




Fig. D5

5. REMOVAL OF THE FRONT LOWER PANEL

Place the deck upside down so that the bottomside faces upward. Then remove the screws (G) and unlock the 3 locking portions (H).




Fig. D6

NOTE:

Place the cushion under the deck to avoid any damages.

6.REMOVAL OF THE OPERATION C.B.A. AND TIMER C.B.A.

Remove the 4 screws (I) and unlock the 4 locking portions (J).




Fig. D7

7. REMOVAL OF THE MAIN C.B.A.

Remove the 6 screws (K) and take out the Main C.B.A. Putting it up right position on the frame can be available as shown in Fig. D9.




Fig. D8




Fig. D9

8. REMOVAL OF THE POWER UNIT

Remove the 3 screws (L) and take it out from the Main C.B.A. as shown in Fig. D8. Remove the shield case then checking can be performed.

9. REMOVAL OF THE DIGITAL UNIT

Remove the 2 screws (M) and lift it. Remove the shield case then checking can be performed.




Fig. D10

10. REMOVAL OF THE CASSETTE COMPARTMENT

Remove the 3 screws (N). Slide the cassette holder until appearing 2 screws (O) by turning (clockwise) the Capstan Rotor Unit (located in the bottom side as shown in Fig. D12 and remove the 2 screws (O). Remove the flexible cable from connector P1503 mounted on Take-up Photo Tr. C.B.A. , then carefully pull out the Cassette Compartment.




Fig. D11




Fig. D12

NOTE:

When reinstalling the Cassette Compartment, mechanical adjustment (alignment) must be performed for correct working refer to Service Manual (G Mechanical Chassis) (Order No. VRD8701105, item 3-10. mechanical adjustment (alignment)).

4. Signal Generator (Sinewave)
Frequency Range: 0~500KHz
5. Video Sweep Generator
Frequency Range: 0~10MHz
6. Colour Monitor TV
7. Plastic Tip Driver
8. VHS Alignment Tape (VFJ8125H3F)

2-3-2. HOW TO READ THE ADJUSTMENT PROCEDURES




Fig.E1

2-3. ELECTRICAL ADJUSTMENT PROCEDURES

This section provides complete electrical adjustment procedures which may be required for electronic circuits of VHS Video Cassette Recorder NV-D48EG/B.

2-3-1. TEST EQUIPMENTS

To perform the electrical adjustments completely, following equipments are required.

1. VTVM (Vacuum Tube Volt Meter) or DVM (Digital Volt Meter)
Voltage Range: 0.001~50V
2. Dual-Trace Oscilloscope
Voltage Range: 0.005~50V/div.
Frequency Range: DC~30MHz
Probes: 10:1 or 1:1
3. Frequency Counter
Frequency Range: 0~10MHz




Fig.E2

SERVO SECTION

2-3-3. PG SHIFTER ADJUSTMENT

TP	ADJ.	MODE	INPUT
TP2001 TP3002	VR2001	PLAY	
TAPE	M.EQ.	SPEC.	
ALIGNMENT TAPE VFJ8125H3F	OSCILLO- SCOPE	6.5+/-0.5H	




Fig.E3

2-3-4. TRACKING FIX ADJUSTMENT

TP	ADJ.	MODE	INPUT
TP2001 TP2002	VR2002	SELF RECORDING	VIDEO SIGNAL
TAPE	M.EQ.	SPEC.	
BLANK TAPE	OSCILLO- SCOPE	T=1.6+/-0.4msec.	

1. TRACKING VR is in centre fix position.
2. Record the video signal.
3. Playback the just recorded portion.
4. Adjust the VR2002 so that the period of "T" becomes 1.6+/-0.4msec. as shown in below.




Fig.E4

2-3-5. SLOW TRACKING ADJUSTMENT

TP	ADJ.	MODE	INPUT
TP2026 TP2002	VR2011	SLOW	VIDEO SIGNAL
TAPE	M.EQ.	SPEC.	
BLANK TAPE	OSCILLO- SCOPE	T=17.5+/-2msec.	

1. SLOW TRACKING VR is centre fix position.
2. Playback the just recorded portion in SLOW mode.
3. Adjust the VR2011 for 17.5+/-2msec. as shown in Fig. E5.




Fig.E5

2-3-6. SLOW FREE RUN ADJUSTMENT

TP	ADJ.	MODE	INPUT
TP2015	VR2013	STILL	VIDEO SIGNAL
TAPE	M.EQ.	SPEC.	
BLANK TAPE	FREQUENCY COUNTER	453+/-15Hz	

1. Record the video signal and playback the tape just recorded. Then place the unit in STILL mode.
2. Connect a jumper wire between TP2025 and GND.
3. Connect a jumper wire between TP2026 and GND.
4. Connect the frequency counter to TP2015.
5. Adjust the VR2013 so that the frequency is 453+/-15Hz.

2-3-7. ARTIFICIAL V-SYNC ADJUSTMENT

TP	ADJ.	MODE	INPUT
	VR2010	SELF RECORDING	VIDEO SIGNAL
TAPE	M.EQ.	SPEC.	
BLANK TAPE	TV MONITOR		

1. Playback the just recorded portion and place the deck in STILL mode.
2. Adjust the VR 2010 so that the V-dancing does not appear on the TV monitor screen.




Fig.E6

LUMINANCE, CHROMINANCE & HEAD AMP SECTION

2-3-8. LUMINANCE RECORDING CURRENT ADJUSTMENT

TP	ADJ.	MODE	INPUT
TP503 (HOT) TP504 (GND)	VR501	RECORDING	VIDEO SIGNAL
TAPE	M.EQ.	SPEC.	
BLANK TAPE	OSCILLOSCOPE	130+-5mVp-p	




Fig.E7

2-3-9. CHROMINANCE RECORDING CURRENT ADJUSTMENT

TP	ADJ.	MODE	INPUT
TP503 (HOT) TP504 (GND)	VR502	RECORDING	VIDEO SIGNAL
TAPE	M.EQ.	SPEC.	
BLANK TAPE	OSCILLOSCOPE	32+-3mVp-p	




Fig.E8

2-3-10. PLAYBACK CHROMA CYAN LEVEL ADJUSTMENT

TP	ADJ.	MODE	INPUT
TP3002 (VIDEO OUT)	VR803	SELF RECORDING	VIDEO SIGNAL
TAPE	M.EQ.	SPEC.	
BLANK TAPE	OSCILLOSCOPE	0.55+-0.05Vp-p	




Fig.E9

2-3-11. HEAD AMP FREQUENCY RESPONSE ADJUSTMENT

TP	ADJ.	MODE	INPUT
TP3002 (VIDEO OUT)	VR3012	SELF RECORDING	VIDEO SWEEP
TAPE	M.EQ.	SPEC.	
BLANK TAPE	VIDEO SWEEP/ OSCILLOSCOPE		

1. Set the sweep generator output as shown in below.




Fig.E10

2. PICTURE VR is centre fix position.
3. Adjust the VR3012 so that the waveform becomes as shown in below.




Fig.E11

2-3-12. Y-NR BALANCE ADJUSTMENT

TP	ADJ.	MODE	INPUT
IC301-9	VR302	SELF RECORDING	VIDEO SIGNAL (COLOUR BAR)
TAPE	M.EQ.	SPEC.	
BLANK TAPE	OSCILLOSCOPE	WAVEFORM IS MINIMIZED	

1. Connect the oscilloscope to Pin9 of IC301 on the Luminance & Chrominance Pack C.B.A.
2. Adjust the VR302 so that the waveform is minimized as shown in below.




Fig.E12

2-3-13. SECAM KILLER ADJUSTMENT (NV-D48EG ONLY)

TP	ADJ.	MODE	INPUT
IC851-11	T851	RECORDING	SECAM VIDEO SIGNAL
TAPE	M.EQ.	SPEC.	
BLANK TAPE	OSCILLOSCOPE	Portion A is peak to hegative direction.	

1. Adjust T851 so that the portion "A" becomes maximum waveform.




Fig.E13

AUDIO SECTION

2-3-14. AUDIO BIAS CURRENT ADJUSTMENT

TP	ADJ.	MODE	INPUT
TP4002 (+) TP4001 (-)	VR4002	RECORDING	
TAPE	M.EQ.	SPEC.	
BLANK TAPE	V.T.V.M.	2.2+-0.1mVrms	

2-3-15. AUDIO PLAYBACK LEVEL ADJUSTMENT

TP	ADJ.	MODE	INPUT
TP4001 (AUDIO OUT)	VR4001	SELF RECORDING	1KHz,0dB AUDIO SIGNAL
TAPE	M.EQ.	SPEC.	
BLANK TAPE	SIGNAL GENERATOR/ V.T.V.M.	E-E Level=-7+-2dB P.B. Level= E-E Level+-0.5dB	

NOTE:

Before this adjustment, "Tape Interchangeability Adjustment" and "Audio Bias Current Adjustment" must be completed.

2-3-16. MUTING FREQUENCY ADJUSTMENT

TP	ADJ.	MODE	INPUT
IC3002-9	VR3020	STOP	
TAPE	M.EQ.	SPEC.	
	FREQUENCY COUNTER	15.625+-0.05KHz	

1. To make this adjustment, please prepare the following circuit as shown below.




Fig.E14

2. Make a short circuit between VIDEO IN and GND.
3. Adjust VR3020 so that the frequency becomes 15.625+-0.05KHz.

DIGITAL SECTION

2-3-17. E-E LEVEL ADJUSTMENT

TP	ADJ.	MODE	INPUT
IC9504-1	VR9501	STOP	VIDEO SIGNAL (COLOUR BAR)
TAPE	M.EQ.	SPEC.	
	OSCILLOSCOPE	1.8+-0.2Vp-p	

2-3-18. OUTPUT BIAS ADJUSTMENT

TP	ADJ.	MODE	INPUT
IC9506-19	VR9502	STOP	
TAPE	M.EQ.	SPEC.	
	D.V.M	1.6+-0.1V	

1. Connect the short jumper between video-in terminal and GND as shown in Fig.E15.
(or Connect the BNC plug to video-in terminal on the unit in order to select the input signal to Line from Tuner.)
2. Connect the D.V.M to IC9506-19.
3. Adjust VR9502 so that the reading of D.V.M is 1.6+-0.1V.

2-3-19. SMALL PICTURE APC FREE RUN ADJUSTMENT

TP	ADJ.	MODE	INPUT
TP9001	VR9503	STOP	
TAPE	M.EQ.	SPEC.	
	FREQUENCY COUNTER	4,433,619+-190Hz	

1. Connect the short jumper between video-in and GND as shown in Fig.E15.
2. Connect the frequency counter to TP9001.
3. Adjust VR9503 so that the reading of frequency counter is 4,433,619+-190Hz.

TP	ADJ.	MODE	INPUT
C9545(-)	VR9504 L9506	STOP	VIDEO SIGNAL (COLOUR BAR)
TAPE	M.EQ.	SPEC.	
	OSCILLO- SCOPE	A LEVEL...MAXIMUM B LEVEL...MINIMUM	

-

WHITE LEVEL OF SMALL PICTURE

BEFORE ADJ.

AFTER ADJ.

[illegible][illegible]

TP	ADJ.	MODE	INPUT
P9501-3	VR9510	STOP	VIDEO SIGNAL (COLOUR BAR)
TAPE	M.EQ.	SPEC.	
	OSCILLO- SCOPE	Refer to Fig.E17	

-
- TP503 TP504 VR501 VR502
- REC-Y REC-C
CURR. CURR.

T851 ▲
SECAM
KILLER ADI

Diagram of the rear panel of the TV set showing the location of the Y BALANCE and P.B. CHROMA LEVEL ADJ. controls.

VR302 ▲


Y
BALANCE

P.B. CHROMA
LEVEL ADJ.


VR803 ▲

LOCATION OF TEST POINTS & CONTROLS — 2 —


TIMER C.B.A.




OPERATION C.B.A.



TUNER & TV DEMODULATOR PACK C.B.A.



IR RECEIVER C.B.A.



TIMER SECTION

- Note:
1. Do not connect the AC power plug.
 2. Make a short circuit at C7571 to discharge. (Refer to the Technical Information)

2-3-27. TIMER REFERENCE CLOCK ADJUSTMENT

TP	ADJ.	MODE	INPUT
IC7501-32	C7501		
TAPE	M.EQ.	SPEC.	
	FREQUEN- CY COUNTER	3906.25+-0.008us	

1. Set the voltage of the DC. power supply for 5.8V+-0.1V and supply it to P7502-8 (+) and GND (-).
2. Connect a jumper wire between P7502-7 and GND.
3. Connect a jumper wire between Anode and Cathode of D7537.

TV DEMODULATOR SECTION


2-3-28. TEST EQUIPMENTS

To make adjustment completely, following equipments are required.

1. VIF SWEEP GENERATOR with the Trap Adjustor
.....38.9MHz(NV-D48EG)
.....39.5MHz(NV-D48B)
2. SIF SWEEP GENERATOR
.....5.5MHz+-150KHz(NV-D48EG)
.....6.0MHz+-150KHz(NV-D48B)
3. CW OSCILLATOR
.....38.9MHz+-100KHz(NV-D48EG)
.....39.5MHz+-100KHz(NV-D48B)
4. MONITOR SCOPE
5. OSCILLOSCOPE
6. DIGITAL VOLT METER

- Note1:
1. First, remove the screw and remove the TV Demodulator Pack C.B.A. from the Main C.B.A.
 2. Unsolder the 2 soldering portions (B) and open the tuner section in TV Demodulator Pack C.B.A.

CIRCUIT BOARD LAYOUT






Fig.E18

3. Exchange the original cable to newly develop adjustment cable (VEE4250) as shown in Fig. E15.
4. Reinstall the TV Demodulator Pack C.B.A. to the Main C.B.A. on foil side and finally solder the soldering portions of the TV Demodulator Pack C.B.A.




Fig.E19

NOTE2:

To make adjustments, please prepare the following equipments and install them according to each adjustment items.




Fig.E20




Fig.E21

2-3-29. VIF SWEEP ADJUSTMENT

TP	ADJ.	MODE	INPUT
TP707	T703 (X717:EG) TUNER CONVERTER COIL		VIF SWEEP
TAPE	M.EQ.	SPEC.	
	VIF SWEEP/ MONITOR SCOPE	Refer to VIF Specification Chart (Fig. E25)	

1. Set the BAND SW of the deck for as shown in Fig. 22. And adjust the SEARCH Button (+,-) so that the voltage at BT terminal of the tuner becomes 15V+-1V.
2. Set the AFC SW of the deck for OFF mode.
3. Connect a jumper wire between TUNER terminal and GND. And connect a capacitor (50V,1uF) between TP703 and GND.
4. Connect the VIF sweep generator to TUNER TEST POINT through the FILTER JIG (A) as shown in Fig. E20. And connect the MONITOR SCOPE to TP707 through the FILTER JIG (B) as shown in Fig. E20.
5. Adjust the T703 so that the marker position (A) becomes centre position of f1 and f2 as shown in Fig. E25.
6. Preadjust the X717 and Tuner Converter Coil so that the sweep output waveform becomes maximum and then adjust the X717 and tuner Converter Coil so that the waveform becomes as shown in Fig. E25.(NV-D48EG ONLY)
7. Adjust the output of the VIF sweep generator so that the sweep wave becomes 0.3Vp-p. Then release 20dB attenuation from the attenuator of the VIF sweep generator.
8. Connect the variable resistor JIG (E) to both points TP709 and TV Demodulator Pack -(2) as shown below.

Model No.	BAND	BAND SW
NV-D48EG	VHF Low	I
NV-D48B	UHF	U

Fig.E22




Fig.E23 ADJUSTMENT JIG (E)

10. Adjust the TUNER CONVERTER COIL so that the fp trap and fc trap as shown below.





Fig.E24



MODEL		NV-D48EG	NV-D48B
FREQ.			
MARKER FREQUENCY	fs'	40.4MHz	41.5MHz
	fp	38.9MHz	39.5MHz
	f1	38.15MHz	38.6MHz
	f2	35.22MHz	35.5MHz
	fc	34.47MHz	35.07MHz
	f3	33.97MHz	34.57MHz
	fs	33.4MHz	33.5MHz
	fp'	31.9MHz	31.5MHz
SPECIFICATIONS	fp	30+-5%	25+-5%
	fc	33~55%	30~50%

Fig.E25

9. Adjust the VR of the JIG (E) so that the output of the sweep wave becomes 0.3Vp-p.

2-3-30. SIF SWEEP ADJUSTMENT

TP	ADJ.	MODE	INPUT
AUDIO OUT (TV DEMO- DULATOR PACK-12)	T711		SIF SWEEP
TAPE	M.EQ.	SPEC.	
	VIF SWEEP/ MONITOR SCOPE	A=5.5MHz (EG) A=6.0MHz (B)	

1. Set the BAND SW of the deck for as shown in Fig. E22. And adjust the SEARCH Button (+,-) so that the voltage at BT terminal of the tuner becomes 15V $\pm$ 1V.
2. Set the AFC SW of the deck for OFF mode.
3. Connect the SIF sweep generator to TP706 through the FILTER JIG (C) as shown in Fig. E21. And connect the MONITOR SCOPE to AUDIO OUT through the FILTER JIG (D) as shown in Fig. E21.
4. Set the output of the SIF sweep generator for 250mVp-p at no load.
5. Connect the JIG (E) to both points TP709 and TV Demodulator Pack-(2) as shown in Fig. E23. Adjust the VR of the JIG (E) so that the D.C. level becomes less than 3V.
6. Adjust the T711 so that the SIF waveform becomes MAXIMUM and attenuation of (A) trap becomes MINIMUM.




Fig.E26 SIF WAVEFORM

7. Confirm that the level between (A) $\pm$ 150KHz marker position is more than 0.75Vp-p.

2-3-31. AFC ADJUSTMENT

TP	ADJ.	MODE	INPUT
AFC TERMINAL OF THE TUNER	T704		CW SIGNAL
TAPE	M.EQ.	SPEC.	
	CW OSCILLA- TOR/D.V.M.	A=38.9MHz	

1. Set the BAND SW of the deck for as shown in Fig. E22. And adjust the SEARCH Button (+,-) so that the voltage at BT terminal of the tuner becomes 15V $\pm$ 1V.
2. Set the AFC SW of the deck for OFF mode.
3. Set the CW oscillator output to "A" MHz and 1Vp-p. And connect the CW oscillator output to the TUNER TEST POINT.
4. Connect the D.V.M. to the AFC terminal of the tuner.
5. Read the value "B" of the D.V.M., when the AFC SW is OFF mode.
6. Set the AFC SW for ON mode and adjust T704 for "B" $\pm$ 0.3V.
7. Change the frequency of the CW oscillator to "A"(MHz) $\pm$ 100KHz, and confirm the difference of the AFC voltage is more than $\pm$ 2V respective.

2-3-32. VIDEO FREQUENCY RESPONSE

TP	ADJ.	MODE	INPUT
VIDEO OUT (TV DEMO- DULATOR PACK-5)	VR741		VIF SWEEP
TAPE	M.EQ.	SPEC.	
	OSCILLO- SCOPE/ VIF SWEEP	A=80% (B) A=70% (EG)	

1. Connect the VIF sweep generator to the tuner unit directly after removing the connector from RF converter.
2. Set the BAND SW for as shown in Fig. E22. And tune the VIF sweep signal.
3. Set the AFC SW for ON mode.
4. Set the output of the VIF sweep generator to 800mVp-p.
5. Adjust VR741 so that the waveform at the VIDEO out (TV DEMODULATOR PACK-5) becomes as shown below.




Fig.E27

2-3-33. AUDIO LEVEL ADJUSTMENT

TP	ADJ.	MODE	INPUT
AUDIO OUT (TV DEMODU- LATOR PACK-12)	VR751		RF SIGNAL
TAPE	M.EQ.	SPEC.	
	OSCILLO- SCOPE	120+ $\pm$ 10mVp-p	

1. Set the AFC SW for ON position.
2. Supply RF signal to the RF IN terminal and tune this signal.
3. Adjust the VR751 so that the audio level becomes 120+ $\pm$ 10mVp-p.













Fig.E28







SYMBOL	TRUTH VALUE TABLE																				
INVERTER 	<table><tr><td>IN</td><td>(a)</td><td>H</td><td>L</td></tr><tr><td>OUT</td><td>(b)</td><td>L</td><td>H</td></tr></table>	IN	(a)	H	L	OUT	(b)	L	H												
IN	(a)	H	L																		
OUT	(b)	L	H																		
COMPARATOR 	<table><tr><td>IN</td><td>(a)</td><td rowspan="2">(a) > (b)</td><td rowspan="2">(a) < (b)</td></tr><tr><td></td><td>(b)</td></tr><tr><td>OUT</td><td>(c)</td><td>H</td><td>L</td></tr></table>	IN	(a)	(a) > (b)	(a) < (b)		(b)	OUT	(c)	H	L										
IN	(a)	(a) > (b)	(a) < (b)																		
	(b)																				
OUT	(c)	H	L																		
AND CIRCUIT 	<table><tr><td>IN</td><td>(a)</td><td>L</td><td>L</td><td>H</td><td>H</td></tr><tr><td></td><td>(b)</td><td>L</td><td>H</td><td>L</td><td>H</td></tr><tr><td>OUT</td><td>(c)</td><td>L</td><td>L</td><td>L</td><td>H</td></tr></table>	IN	(a)	L	L	H	H		(b)	L	H	L	H	OUT	(c)	L	L	L	H		
IN	(a)	L	L	H	H																
	(b)	L	H	L	H																
OUT	(c)	L	L	L	H																
OR CIRCUIT 	<table><tr><td>IN</td><td>(a)</td><td>L</td><td>L</td><td>H</td><td>H</td></tr><tr><td></td><td>(b)</td><td>L</td><td>H</td><td>L</td><td>H</td></tr><tr><td>OUT</td><td>(c)</td><td>L</td><td>H</td><td>H</td><td>H</td></tr></table>	IN	(a)	L	L	H	H		(b)	L	H	L	H	OUT	(c)	L	H	H	H		
IN	(a)	L	L	H	H																
	(b)	L	H	L	H																
OUT	(c)	L	H	H	H																
THREE STATES BUFFER 	<table><tr><td>IN</td><td>(a)</td><td>H</td><td>L</td><td>H or L</td></tr><tr><td></td><td>(b)</td><td>L</td><td>L</td><td>H</td></tr><tr><td>OUT</td><td>(c)</td><td>H</td><td>L</td><td>※</td></tr></table> ※ High Impedance	IN	(a)	H	L	H or L		(b)	L	L	H	OUT	(c)	H	L	※					
IN	(a)	H	L	H or L																	
	(b)	L	L	H																	
OUT	(c)	H	L	※																	
TR. SW (NPN TYPE) 	<table><tr><td>BASE</td><td>H</td><td>L</td></tr><tr><td>TR. SW</td><td>ON</td><td>OFF</td></tr></table>	BASE	H	L	TR. SW	ON	OFF														
BASE	H	L																			
TR. SW	ON	OFF																			
TR. SW (PNP TYPE) 	<table><tr><td>BASE</td><td>H</td><td>L</td></tr><tr><td>TR. SW</td><td>OFF</td><td>ON</td></tr></table>	BASE	H	L	TR. SW	OFF	ON														
BASE	H	L																			
TR. SW	OFF	ON																			
R-S TYPE FLIP-FLOP 	<table><tr><td>IN</td><td>(a)</td><td>L</td><td>L</td><td></td></tr><tr><td></td><td>(b)</td><td>L</td><td></td><td>L</td></tr><tr><td>OUT</td><td>(c)</td><td>※</td><td>L</td><td>H</td></tr><tr><td></td><td>(d)</td><td>◆</td><td>H</td><td>L</td></tr></table> ※ Initial condition is maintained. ◆ Initial condition is reversed.	IN	(a)	L	L			(b)	L		L	OUT	(c)	※	L	H		(d)	◆	H	L
IN	(a)	L	L																		
	(b)	L		L																	
OUT	(c)	※	L	H																	
	(d)	◆	H	L																	


BLOCK DIAGRAMS & SCHEMATIC DIAGRAMS

3-1. SYSTEM CONTROL & TIMER BLOCK DIAGRAM




RAMS





3-3. LUMINANCE & CHROMINANCE BLOCK DIAGRAM



INPUT SIG.

A	B	C	"ON" CHANNEL
L	L	L	Z0, Y0, X0
H	L	L	Z0, Y0, X1
L	H	L	Z0, Y1, X0
H	H	L	Z0, Y1, X1
L	L	H	Z1, Y0, X0
H	L	H	Z1, Y0, X1
L	H	H	Z1, Y1, X0
H	H	H	Z1, Y1, X1

FROM TUNER OR LINE IN

VIDEO IN

TEST

VISS

PLAYBACK SIGNAL

TEST SIGNAL GENERATOR

REG 12V

IC 9501

IC 9503

IC 9504

IC 9505

IC 9506

IC 9507

IC 9508

IC 9509

IC 9510

IC 9511

IC 9512

IC 9513

IC 9514

IC 9515

IC 9516

IC 9517

IC 9518

IC 9519

IC 9520

IC 9521

IC 9522

IC 9523

IC 9524

IC 9525

IC 9526

IC 9527

IC 9528

IC 9529

IC 9530

IC 9531

IC 9532

IC 9533

IC 9534

IC 9535

IC 9536

IC 9537

IC 9538

IC 9539

IC 9540

IC 9541

IC 9542

IC 9543

IC 9544

IC 9545

IC 9546

IC 9547

IC 9548

IC 9549

IC 9550

IC 9551

IC 9552

IC 9553

IC 9554

IC 9555

IC 9556

IC 9557

IC 9558

IC 9559

IC 9560

IC 9561

IC 9562

IC 9563

IC 9564

IC 9565

IC 9566

IC 9567

IC 9568

IC 9569

IC 9570

IC 9571

IC 9572

IC 9573

IC 9574

IC 9575

IC 9576

IC 9577

IC 9578

IC 9579

IC 9580

IC 9581

IC 9582

IC 9583

IC 9584

IC 9585

IC 9586

IC 9587

IC 9588

IC 9589

IC 9590

IC 9591

IC 9592

IC 9593

IC 9594

IC 9595

IC 9596

IC 9597

IC 9598

IC 9599

IC 9600

IC 9601

IC 9602

IC 9603

IC 9604

IC 9605

IC 9606

IC 9607

IC 9608

IC 9609

IC 9610

IC 9611

IC 9612

IC 9613

IC 9614

IC 9615

IC 9616

IC 9617

IC 9618

IC 9619

IC 9620

IC 9621

IC 9622

IC 9623

IC 9624

IC 9625

IC 9626

IC 9627

IC 9628

IC 9629

IC 9630

IC 9631

IC 9632

IC 9633

IC 9634

IC 9635

IC 9636

IC 9637

IC 9638

IC 9639

IC 9640

IC 9641

IC 9642

IC 9643

IC 9644

IC 9645

IC 9646

IC 9647

IC 9648

IC 9649

IC 9650

IC 9651

IC 9652

IC 9653

IC 9654

IC 9655

IC 9656

IC 9657

IC 9658

IC 9659

IC 9660

IC 9661

IC 9662

IC 9663

IC 9664

IC 9665

IC 9666

IC 9667

IC 9668

IC 9669

IC 9670

IC 9671

IC 9672

IC 9673

IC 9674

IC 9675

IC 9676

IC 9677

IC 9678

IC 9679

IC 9680

IC 9681

IC 9682

IC 9683

IC 9684

IC 9685

IC 9686

IC 9687

IC 9688

IC 9689

IC 9690

IC 9691

IC 9692

IC 9693

IC 9694

IC 9695

IC 9696

IC 9697

IC 9698

IC 9699

IC 9700

IC 9701

IC 9702

IC 9703

IC 9704

IC 9705

IC 9706

IC 9707

IC 9708

IC 9709

IC 9710

IC 9711

IC 9712

IC 9713

IC 9714

IC 9715

IC 9716

IC 9717

IC 9718

IC 9719

IC 9720

IC 9721

IC 9722

IC 9723

IC 9724

IC 9725

IC 9726

IC 9727

IC 9728

IC 9729

IC 9730

IC 9731

IC 9732

IC 9733

IC 9734

IC 9735

IC 9736

IC 9737

IC 9738

IC 9739

IC 9740

IC 9741

IC 9742

IC 9743

IC 9744

IC 9745

IC 9746

IC 9747

IC 9748

IC 9749

IC 9750

IC 9751

IC 9752

IC 9753

IC 9754

IC 9755

IC 9756

IC 9757

IC 9758

IC 9759


IC 9760

IC 9761

IC 9762


3-5. POWER SCHEMATIC DIAGRAM

3-6.



NOTE 1. WHEN MEASURE THE VOLTAGE OR WAVEFORM ON THE POWER TRANSFORMER CIRCUIT, SET THE GND TERMINAL OF MEASURING POINT AS FOLLOWS.
PRIMARY SIDE Q1001-(5)
SECONDARY SIDE TP GND OF MAIN C.B.A.
NOTE 2. THE DC VOLTAGE INDICATED IN PRIMARY SIDE IS SHOWN THE VOLTAGE WHEN INPUT AC IS 240V.


IC BLOCK IC1001 (STK5339A)




NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS STOP MODE.

NOTE: DO NOT USE THE PART NUMBER SHOWN ON THIS DRAWING FOR ORDERING. THE CORRECT PART NUMBER IS SHOWN IN THE PARTS LIST, AND MAY BE SLIGHTLY DIFFERENT OR AMENDED SINCE THIS DRAWING WAS PREPARED.


IMPORTANT SAFETY NOTICE:
COMPONENTS IDENTIFIED BY THE SIGN △ HAVE SPECIAL CHARACTERISTICS
IMPORTANT FOR SAFETY WHEN REPLACING ANY OF THESE COMPONENTS, USE ONLY THE SPECIFIED PARTS.





POWER C.B.A.	
Transistor	
Q1001	B-3
Q1002	B-5
Q1003	B-5
Q1004	B-5
Q1006	B-4
Transistor & Resistor	
QR1001	B-5
Integrated Circuit	
IC1001	B-5
Connector	
P1001	B-5




ADDRESS INFORMATION




POWER C.B.A.	
Transistor	
Q1001	B-3
Q1002	B-5
Q1003	B-5
Q1004	B-5
Q1006	B-4
Transistor & Resistor	
QR1001	B-5
Integrated Circuit	
IC1001	B-5
Connector	
P1001	B-5



ADDRESS INFORMATION

POWER C.B.A. (VEP01310H: NV-D48EG) (VEP01310J: NV-D48B)





3-8. SYSTEM CONTROL SCHEMATIC DIAGRAM





NOTE: DO NOT USE THE PART NUMBER SHOWN ON THIS DRAWING FOR ORDERING.
THE CORRECT PART NUMBER IS SHOWN IN THE PARTS LIST, AND MAY BE
SLIGHTLY DIFFERENT OR AMENDED SINCE THIS DRAWING WAS PREPARED.

3-9. SERVO SCHEMATIC DIAGRAM




SYSTEM CONTROL ICs VOLTAGE CHART

REF. NO.	IC6001																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
STOP	0	0	0	0	0	1.3	5.2	0	0	4.1	5.2	0	4.8	0.3	5.1	5.2	3.0	3.3	3.3	0.5
PLAY	0	0	5.3	0	0	1.6	5.3	0	0	4.1	5.3	0.1	4.8	0.3	5.1	5.2	3.0	3.4	3.4	0.5
REC	0	0	5.2	0	0	1.8	5.2	0	0	4.1	5.2	2.6	4.8	0.3	5.1	5.2	3.0	3.3	3.3	0.5
F.F	0	0	5.1	0	0	1.4	5.2	5.0	0	4.0	5.2	2.0	4.8	0.3	5.1	5.2	3.0	3.3	3.3	0.5
REW	0	0	5.1	0	0	1.4	5.2	0	0	4.0	5.2	2.0	4.8	0.3	5.1	5.2	3.0	3.3	3.3	0.5
REF. NO.	IC6001																			
MODE	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
STOP	0	2.1	2.1	2.1	2.2	5.3	5.1	0	5.4	4.6	4.8	5.2	5.1	4.8	0	0	0	5.2	1.3	1.3
PLAY	0	2.1	2.1	2.1	5.4	0	2.6	2.6	2.6	0.5	4.8	5.2	5.1	4.8	5.2	0	0	5.3	1.3	1.3
REC	0	2.1	2.1	2.1	5.4	0	2.6	2.6	2.6	0.5	4.8	5.2	5.1	4.8	5.2	0	0.1	5.3	0.1	0.1
F.F	0	2.0	2.1	2.0	2.2	5.3	2.6	0	2.7	5.1	4.8	5.1	5.0	4.8	0	0	0	5.2	1.3	1.3
REW	0	2.0	2.1	2.0	2.2	5.3	2.6	0	2.7	4.6	4.8	5.1	5.0	4.8	0	0	0	5.2	1.4	1.4
REF. NO.	IC6001																			
MODE	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60
STOP	10.0	12.3	1.7	0	0.1	5.2	5.2	0	0.1	5.0	5.3	0	0.3	0	5.0	0.1	4.4	0.1	0	0
PLAY	10.0	12.3	5.3	0	0.1	0	5.3	5.3	0.1	5.1	5.4	4.5	0.3	4.7	0.1	5.0	4.5	0.1	5.0	0
REC	0.3	0.3	5.2	0.1	0.1	0.1	5.2	5.2	0.1	5.1	5.4	4.5	5.1	4.7	5.1	0.1	4.4	0.1	0	0
F.F	10.0	12.3	5.2	0	0.1	0	5.2	5.2	0.1	5.0	5.3	0.1	0.3	0	5.0	0.1	4.4	0.1	0	0
REW	10.0	12.3	5.2	0	0.1	0	5.2	0	0.1	5.0	5.3	0.1	0.3	0	5.0	0.1	4.4	0.1	0	0
REF. NO.	IC6001																			
MODE	61	62	63	64																
STOP	5.2	2.1	2.3	5.2																
PLAY	5.3	2.1	2.3	5.3																
REC	5.3	2.1	2.3	5.3																
F.F	5.2	2.1	2.3	5.2																
REW	5.2	2.1	2.3	5.2																
REF. NO.	IC6002																			
MODE	1	2	3	4	5	6	7	8												
STOP	0	5.2	2.4	0	1.0	0.4	0.9	5.1												
PLAY	2.6	2.6	2.6	0	0.9	0.4	0.8	5.1												
REC	2.6	2.6	2.6	0	0.9	0.4	0.7	5.1												
F.F	2.6	2.6	2.6	0	0.8	0.4	0.7	5.1												
REW	2.6	2.6	2.6	0	0.9	0.4	0.8	5.1												
REF. NO.	IC6003																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16				
STOP	0	0	0	0	5.2	5.4	5.4	0	0	0	0	0	0	5.4	0.9	5.4				
PLAY	0	2.6	0	0	0	2.6	5.4	0	0	5.3	0	0	0	2.6	0.4	5.4				
REC	0	2.6	0	0	0.1	2.6	5.4	0	0	5.3	2.6	0	0	2.6	2.6	5.4				
F.F	0	1.0	0	0	0	2.7	4.8	0	0	5.2	2.0	0	0	2.0	1.2	5.4				
REW	0	1.0	0	0	0	2.7	4.8	0	0	0	2.2	0	0	2.1	1.2	5.3				
REF. NO.	IC6004																			
MODE	1	2	3																	
STOP	5.2	5.4	0																	
PLAY	5.2	5.4	0																	
REC	5.2	5.4	0																	
F.F	5.2	5.4	0																	
REW	5.2	5.4	0																	


SYSTEM CONTROL TRANSISTORS VOLTAGE CHART

REF. NO.	Q6006			Q6007			Q6009			Q6016			Q6017			Q6018		
MODE	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B
STOP	12.3	0	12.3	12.3	12.3	11.6	12.3	-0.2	12.3	14.5	15.6	15.7	0	15.6	0.1	0	0	0
PLAY	12.3	12.1	11.4	12.3	12.3	11.6	12.3	-0.2	12.3	10.7	15.3	11.9	0	15.3	0.2	0	0	0
REC	12.3	0	12.3	12.3	12.1	11.5	12.1	11.9	11.4	10.7	15.3	11.9	0	15.3	0.2	0	0	0
F.F	12.3	0	12.3	12.3	12.3	11.6	12.3	-0.2	12.3	14.5	15.6	15.7	0	15.6	0.1	0	0	0
REW	12.3	0	12.3	12.3	12.3	11.6	12.3	-0.2	12.3	14.5	15.6	15.7	0	15.6	0.1	0	0	0
REF. NO.	Q6019			Q6020														
MODE	E	C	B	E	C	B												
STOP	0.6	14.5	0.5	0	15.6	0												
PLAY	0.6	10.7	0.5	0	15.3	0												
REC	0.6	10.7	0.5	0	15.3	0												
F.F	0.6	14.4	0.5	0	15.6	0												
REW	0.6	14.4	0.5	0	15.6	0												
REF. NO.	QR6001			QR6005			QR6006			QR6008			QR6011			QR6012		
MODE	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B
STOP	0	5.1	0.3	0	12.3	0.1	5.0	4.9	0.1	5.4	0	5.4	0	15.7	0	5.0	0.6	4.4
PLAY	0	5.1	0.3	0	0.1	5.0	5.0	4.9	0.1	5.4	0	5.4	0	0.1	5.2	5.0	0.6	4.4
REC	0	5.1	0.2	0	12.3	0.1	5.1	4.9	0.1	5.4	0	5.4	0	0.1	5.2	5.1	0.6	4.5
F.F	0	5.1	0.3	0	12.3	0.1	5.0	4.9	0.1	5.4	0	5.4	0	15.7	0	5.0	0.6	4.4
REW	0	5.1	0.3	0	12.3	0.1	5.0	4.9	0.1	5.4	0	5.4	0	15.7	0	5.0	0.6	4.4



SYSTEM CONTROL Section



SERVO Section



3-10. SYSTEM CONTROL & SERVO Section In Main C.B.A. (VEP03493BE: NV-D48EG) (VEP03493BG: NV-D48B)

MECHANISM CONNECTION C.B.A. (VEK3583)





3-11. SUB MAIN PACK SCHEMATIC DIAGRAM

← CYLINDER SERVO PHASE LOOP

← CAPSTAN SERVO PHASE LOOP

← CYLINDER SERVO SPEED





SUB MAIN TRANSISTORS VOLTAGE CHART

REF. NO.	Q2108			Q2111			Q2112											
MODE	E	C	B	E	C	B	E	C	B									
PLAY	0	0	0.5	1.6	5.0	1.2	0.3	2.4	0.9									
REC	0	0	0.2	3.0	5.0	2.6	0.6	0.6	1.2									

REF. NO.	QR2101			QR2102			QR2103			QR2104			QR2105			QR2106		
MODE	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B	E	C	B
PLAY	2.5	2.5	4.6	2.5	2.6	4.6	0	0.7	0	2.5	2.5	5.1	2.6	2.6	0	2.6	2.5	5.1
REC	2.5	3.0	4.6	2.5	2.6	4.6	0	0.7	0	2.5	2.6	5.1	2.6	2.6	0	2.6	2.5	5.1

REF. NO.	Q2107																	
MODE	E	C	B															
PLAY	2.5	2.5	5.1															
REC	2.5	2.5	5.1															

SUB MAIN ICs VOLTAGE CHART

REF. NO.	IC2101																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
PLAY	2.6	0.8	5.0	5.2	5.0	2.4	0	0	2.6	2.4	2.5	5.0	1.1	0	0.2	2.5	2.6	5.0	2.5	2.5
REC	2.6	0.8	5.0	5.1	5.0	2.4	0	0	2.6	2.4	2.4	5.0	1.1	0	0.2	2.5	2.6	5.0	2.5	2.5

REF. NO.	IC2101																			
MODE	21	22	23	24	25	26	27	28												
PLAY	2.5	2.5	2.5	2.6	2.5	1.3	2.7	0												
REC	2.5	2.5	2.5	2.6	3.0	2.6	2.6	0												

REF. NO.	IC2102																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
PLAY	5.0	5.1	5.2	2.6	0	2.6	5.0	0.7	0	0	0	0	0	4.5	2.6	2.4	0.4	0	2.6	0.1
REC	5.0	5.1	5.2	2.6	0	2.6	5.0	0.7	0	0	0	0	0	0.2	2.6	2.4	0.4	0	2.6	0

REF. NO.	IC2102																			
MODE	21	22	23	24	25	26	27	28												
PLAY	2.5	2.2	5.0	0	2.4	2.5	2.6	2.5												
REC	2.5	2.2	5.0	0	2.4	2.5	2.6	2.5												

REF. NO.	IC2103																			
MODE	1	2	3	4	5	6	7	8												
PLAY	2.4	2.4	2.5	0	2.5	2.5	2.6	5.0												
REC	2.4	2.4	2.5	0	2.5	2.5	2.6	5.0												


REF. NO.	IC2104																			
MODE	1	2	3	4	5	6	7	8												
PLAY	2.4	2.4	2.5	0	2.5	2.5	2.6	5.0												
REC	2.4	2.4	2.5	0	2.5	2.5	2.6	5.0												

REF. NO.	IC2105																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14						
PLAY	2.4	2.4	2.4	2.2	0	5.0	0	5.0	0	5.0	0	5.0	0	5.0						
REC	2.4	2.4	2.4	2.2	0	5.0	0	5.0	0	5.0	0	5.0	0	5.0						

REF. NO.	IC2501																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
PLAY	1.4	0.1	1.6	0	1.8	1.8	1.9	1.9	1.9	1.9	0.4	0	5.0	3.3	2.9	2.6	4.2	4.0	0.7	0.1
REC	1.4	0.1	1.6	0	1.8	1.8	1.9	1.9	1.9	1.9	0.4	0	5.0	3.3	2.9	2.6	4.2	4.0	0.7	0.1

REF. NO.	IC2501																			
MODE	21	22	23	24																
PLAY	0	4.3	1.6	10.6																
REC	0	4.3	1.6	10.6																


REF. NO.	IC2901																			
MODE	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18		
PLAY	10.5	10.5	0.1	0.5	0	2.5	2.4	0.6	0.5	2.7	5.0	3.7	3.7	3.7	1.1	10.6	10.5	0.1		
REC	10.5	10.5	0.1	0.5	0	2.5	2.4	0.6	0.5	2.7	5.0	3.7	3.7	3.7	1.1	10.6	10.5	0.1		

IC BLOCK
IC2901 (AN3814K)



3-12. VISS PACK SCHEMATIC DIAGRAM

← ■ ■ ■ CAPSTAN SERVO PHASE LOOP

3-13. SUB MAIN




CYLINDER DRIVE C.B.A. (VEP00H22A)



SUB MAIN C.B.A. & VISS PACK C.B.A.		
Transistor		
Q2108		B-6
Q2111		B-6
Q2112		B-6
Q2801		D-6
Q2802		C-6
Q2803		D-5
Q2804		D-5
Q2805		E-7
Q2806		E-6
Transistor & Resistor		
QR2101		B-5
QR2102		B-5
QR2103		B-1
QR2104		B-6
QR2105		B-5
QR2106		B-5
QR2107		A-6
QR2801		D-6
QR2802		E-5
QR2804		E-5
Integrated Circuit		
IC2101		B-4
IC2102		B-1
IC2103		A-6
IC2104		B-8
IC2105		B-3
IC2501		B-7
IC2801		D-6
IC2802		E-6
IC2803		D-5
IC2901		E-10
Connector		
P2001		A-9
P2002		A-7
P2801		E-6
P2901		D-8
P2902		D-9



ADDRESS INFORMATION




PIN NO.	WAVEFORM	PIN NO.	WAVEFORM
1	 1.0Vp-p (REC/P.B)	22	 1.2Vp-p (REC)
2	 5.0Vp-p (REC/P.B)	23	 1.2Vp-p (P.B)
3	 0.8Vp-p (REC/P.B)	26	 0.9Vp-p (P.B)
5	 0.9Vp-p (REC)	35	 0.45Vp-p (P.B)
5	 1.0Vp-p (P.B)	37, 38	 0.8Vp-p (REC)
7, 8	 0.45Vp-p (REC) 0.55Vp-p (P.B)	37, 38	 1.0Vp-p (P.B)
11	 0.34Vp-p (REC/P.B)	39	 0.3Vp-p (PAUSE/STILL)
13, 15	 0.9Vp-p (REC/P.B)	40	 2.0Vp-p (REC) 2.5Vp-p (P.B)
16	 0.65Vp-p (REC/P.B)	41	 0.45Vp-p (REC/P.B)
17	 0.9Vp-p (REC/P.B)		

PIN NO.	WAVEFORM	PIN NO.	WAVEFORM
2	 0.15 Vp-p (REC/P.B)	17	 0.5 Vp-p (REC) 0.3 Vp-p (P.B)
3	 0.8 Vp-p (REC/P.B)	18	 1.1 Vp-p (REC) 1.2 Vp-p (P.B)
5	 0.3 Vp-p (REC/P.B)	19	 0.25 Vp-p (REC/P.B)
6	 5.0 Vp-p (REC/P.B)	28	 0.7 Vp-p (REC/P.B)
7	 0.6 Vp-p (REC) 0.4 Vp-p (P.B)	29	 1.1 Vp-p (REC/P.B)
9	 0.45 Vp-p (REC) 0.3 Vp-p (P.B)	31	 0.8 Vp-p (REC/P.B)
10	 0.9 Vp-p (REC)	32	 5.0 Vp-p (REC/P.B)
10	 1.3 Vp-p (P.B)	33	 0.45 Vp-p (REC/P.B)
11	 0.4 Vp-p (REC) 0.2 Vp-p (P.B)	34	 5.0 Vp-p (REC/P.B)
12	 0.9 Vp-p (REC/P.B)	35	 5.0 Vp-p (REC/P.B)
14	 0.3 Vp-p (REC) 0.2 Vp-p (P.B)	38	 1.2 Vp-p (P.B)
15	 0.55 Vp-p (REC)		


[illegible]





LUMINANCE & CHROMINANCE PACK C.B.A.	
Transistor	
Q301	C-3
Q302	B-5
Q303	C-5
Q304	B-3
Q804	A-5
Transistor & Resistor	
QR853	D-7
Integrated Circuit	
IC301	B-3
IC303	C-5
IC801	C-6
IC851	D-6
Adjustment	
T851	D-7
VR302	A-5
VR803	A-5

ADDRESS INFORMATION



D

C

B

A

C

B

A

3-19. HEAD AMP C.B.A. (VEP05118B)

3-20. INPUT/OUTPUT PA

Pin Chart			
Pin	V	Pin	V
17	0 (6.5)	25	2.3 (0.2)
18	0 (6.8)	26	2.4 (0)
19	0 (6.5)	27	4.8 (0.2)
20	0 (6.5)	28	5.0 (0.2)
21	0 (7.2)	29	2.9 (0)
22	0 (7.2)	30	5.0 (0.2)
23	0 (12.8)	31	0
24	0	32	2.6 (0.2)



P002 (TO CYLINDER HEAD)	
1	L
2	COM
3	R
4	L'
5	COM
6	R'
7	GND
8	GND
9	GND
10	GND

SHOWN ON THIS DRAWING FOR ORDERING.
S SHOWN IN THE PARTS LIST, AND MAY BE
DED SINCE THIS DRAWING WAS PREPARED.

7 8

HEAD AMP C.B.A.	
Transistor	
Q501	A-3
Integrated Circuit	
IC501	C-3
Test Point	
TP503	C-3
TP504	C-3
Adjustment	
VR501	C-4
VR502	C-5
Connector	
P002	A-2
P501	C-5

ADDRESS INFORMATION





3-20. INPUT/OUTPUT PACK C.B.A. (VEP03494B: NV-D48EG)

HEAD AMP C.B.A.	
Transistor	
Q501	A-3
Integrated Circuit	
IC501	C-3
Test Point	
TP503	C-3
TP504	C-3
Adjustment	
VR501	C-4
VR502	C-5
Connector	
P002	A-2
P501	C-5


ADDRESS INFORMATION

INPUT/OUTPUT C.B.A.	
Transistor	
Q3801	C-2
Q3802	A-2
Q3803	A-3
Integrated Circuit	
IC3801	B-3
IC3802	B-2


ADDRESS INFORMATION



A vertical scale with five horizontal tick marks. The marks are labeled A, B, C, D, and E from bottom to top. The labels are in a bold, sans-serif font.




0



- VIDEO MAIN SIGNAL PATH IN REC MODE
- VIDEO MAIN SIGNAL PATH IN PLAYBACK MODE
- AUDIO MAIN SIGNAL PATH IN REC MODE
- AUDIO MAIN SIGNAL PATH IN PLAYBACK MODE

IC BLOCK
IC3801 (M5202AP)




THIS DIAGRAM IS RECORD MODE

THIS DIAGRAM IS PLAYBACK MODE


NOTE: DO NOT USE THE PART NUMBER SHOWN ON THIS DRAWING FOR ORDERING. THE CORRECT PART NUMBER IS SHOWN IN THE PARTS LIST, AND MAY BE SLIGHTLY DIFFERENT OR AMENDED SINCE THIS DRAWING WAS PREPARED.

3-22. SUB DIGITAL SCHEMATIC DIAGRAM



IMPORTANT SAFETY NOTICE:
COMPONENTS IDENTIFIED WITH THE MARK  HAVE THE SPECIAL CHARACTERISTICS FOR SAFETY.
WHEN REPLACING ANY OF THESE COMPONENTS, USE ONLY THE SAME TYPE.


NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS 3-SCREEN MODE WITH
PAL COLOUR SIGNAL.




IMPORTANT SAFETY NOTICE:
COMPONENTS IDENTIFIED WITH THE MARK HAVE THE SPECIAL CHARACTERISTICS FOR SAFETY.
WHEN REPLACING ANY OF THESE COMPONENTS, USE ONLY THE SAME TYPE.

NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS 3-SCREEN MODE WITH PAL COLOUR SIGNAL.

NOTE: DO NOT USE THE PART NUMBER SHOWN ON THIS DRAWING FOR ORDERING.
THE CORRECT PART NUMBER IS SHOWN IN THE PARTS LIST, AND MAY BE SLIGHTLY DIFFERENT OR AMENDED SINCE THIS DRAWING WAS PREPARED.









SUB DIGITAL C.B.A.	
Transistor	
Q9501	A-8
Q9502	A-8
Q9503	B-7
Q9504	B-10
Q9505	B-3
Q9506	B-3
Q9508	B-6
Q9509	B-4
Q9510	A-1
Q9511	A-1
Q9512	A-2
Q9513	A-2
Q9516	B-8
Q9517	B-5
Q9518	B-6
Q9519	C-7
Q9520	A-8
Q9521	A-9
Q9522	A-10
Q9523	A-9
Q9524	A-2
Q9525	B-10
Q9526	B-9
Q9527	C-6
Q9528	A-3
Q9529	B-4
Q9530	A-4
Q9531	C-4
Q9532	B-4
Transistor & Resistor	
QR9501	A-9
QR9502	B-7
QR9503	B-7
QR9504	A-9
QR9505	A-4
QR9506	A-4
QR9507	B-4
QR9508	B-4
QR9509	A-4
QR9510	B-4
Integrated Circuit	
IC9501	B-8
IC9503	A-9
IC9504	A-7
IC9505	B-9
IC9506	B-2
IC9507	A-5
IC9508	B-4
IC9509	B-6
IC9510	B-8
Test Point	
TP9001	B-2
Adjustment	
VR9501	B-9
VR9502	A-3
VR9503	C-2
VR9504	B-1
VR9505	A-4
VR9506	A-6
VR9507	B-4
VR9508	B-5
VR9509	B-6
VR9510	B-8
Connector	
P9501	A-9
P9502	A-1

ADDRESS INFORMATION


NOTE: DO NOT
THE
SLIG




MAIN DIGITAL C.B.A.	
Transistor	
Q9001	B-7
Q9002	B-6
Q9003	B-6
Q9004	C-9
Q9005	C-9
Q9006	A-7
Transistor & Resistor	
QR9001	A-2
Integrated Circuit	
IC9001	C-3
IC9002	B-2
IC9003	B-1
IC9004	A-2
IC9005	B-4
IC9006	C-4
IC9007	C-6
IC9008	B-6
IC9009	B-7
IC9010	C-7
IC9011	A-8
IC9012	B-8
IC9013	B-4
IC9014	B-9


ADDRESS INFORMATION

NOTE: DO NOT USE THE PART NUMBER SHOWN ON THIS DRAWING FOR ORDERING. THE CORRECT PART NUMBER IS SHOWN IN THE PARTS LIST, AND MAY BE SLIGHTLY DIFFERENT OR AMENDED SINCE THIS DRAWING WAS PREPARED.





3-26. AUDIO SCHEMATIC DIAGRAM




NOTE: DO NOT USE THE PART NUMBER SHOWN ON THIS DRAWING FOR ORDERING. THE CORRECT PART NUMBER IS SHOWN IN THE PARTS LIST, AND MAY BE SLIGHTLY DIFFERENT OR AMENDED SINCE THIS DRAWING WAS PREPARED.

NOTE: THE MEASUREMENT MO
DC VOLTAGES ARE FOLL

SIGNAL PATH IN REC MODE

MAIN SIGNAL PATH IN PLAYBACK MODE





THIS DRAWING FOR ORDERING. THE CORRECT PART NUMBER IS SHOWN DIFFERENT OR AMENDED SINCE THIS DRAWING WAS PREPARED.




NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGES ARE FOLLOWING CONDITION.

- LINE IN SIGNAL LEVEL...—10dB 1kHz
- MEASUREMENT MODE
REC...BRACKETS ()
PLAY...WITHOUT BRACKETS


3-27. AUDIO Section In Main C.B.A. (VEP03493BE: NV-D48EG) (VEP03493BG: NV-D48B)




3-28. CH SELECT Section In Main C.B.A. (VEP03493BE: NV-D48EG) (VEP03493BG: NV-D48B)





3-29. CH SELECT SCHEMATIC DIAGRAM





3-30. TUNER & TV DEMODULATOR PACK SCHEMATIC DIAGRAM (NV-D48EG)






RT NUMBER IS SHOWN
WAS PREPARED.

NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS STOP MODE.

IC BLOCK IC701 (M51366SP)




IMPORTANT SAFETY NOTICE:
COMPONENTS IDENTIFIED BY THE SIGN HAVE SPECIAL CHARACTERISTICS
IMPORTANT FOR SAFETY WHEN REPLACING ANY OF THESE COMPONENTS, USE ONLY
THE SPECIFIED PARTS.

TUNER & TV DEMODULATOR PACK C.B.A. (NV-D48EG)	
Transistor	
Q703	A-1
Q710	B-3
Q712	B-1
Q713	B-4
Q714	B-4
Q771	C-3
Q772	C-2
Q773	C-1
Transistor & Resistor	
QR701	B-4
QR702	B-4
QR711	B-1
QR712	A-1
QR713	A-2
QR714	B-3
Integrated Circuit	
IC701	B-2
Test Point	
TP701	C-4
TP703	A-2
TP704	A-3
TP706	A-3
TP707	A-2
TP709	B-2
Adjustment	
T703	A-2
T704	A-1
T711	A-3
VR701	B-1
VR702	A-1
VR741	B-2
VR751	B-4

ADDRESS INFORMATION


3-32. TUNER & TV DEMODULATOR PACK C.B.A. (VEP07444E: NV-D48B)
(TUNER Section)




TUNER & TV DEMODULATOR PACK C.B.A. (NV-D48B)	
Transistor	
Q703	A-1
Q710	B-3
Q712	B-1
Q713	B-4
Q714	B-4
Q771	C-3
Transistor & Resistor	
QR701	B-4
QR702	B-4
QR713	A-2
Integrated Circuit	
IC701	B-2
Test Point	
TP701	C-4
TP704	A-2
TP706	A-3
TP707	A-2
TP709	B-2
Adjustment	
T703	A-2
T704	A-1
T711	A-3
VR701	B-1
VR741	B-2
VR751	B-4


ADDRESS INFORMATION

← VIDEO SIGNAL PATH ← AUDIO SIGNAL PATH






3-34. TIMER & OPERATION SCHEMATIC DIAGRAM




← SEGMENT CONTROL SIGNAL

← GRID CONTROL SIGNAL

← TUNE CONTROL SIGNAL



3-33. TUNER & TV DEMODULATOR PACK SCHEMATIC DIAGRAM (NV-D48B)




NOTE: DO NOT USE THE PART NUMBER SHOWN ON THIS DRAWING FOR ORDERING. THE CORRECT PART NUMBER IS SHOWN IN THE PARTS LIST, AND MAY BE SLIGHTLY DIFFERENT OR AMENDED SINCE THIS DRAWING WAS PREPARED.

NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS STOP MODE.



NOTE: THE MEASUREMENT MODE OF THE DC VOLTAGE ON THIS DIAGRAM IS STOP MODE.




IMPORTANT SAFETY NOTICE:
COMPONENTS IDENTIFIED BY THE SIGN  HAVE SPECIAL CHARACTERISTICS
IMPORTANT FOR SAFETY WHEN REPLACING ANY OF THESE COMPONENTS, USE ONLY
THE SPECIFIED PARTS.

3-34. TIMER & OPERATION SCHEMATIC DIAGRAM

← SEGMENT CONTROL SIGNAL


← GRID CONTROL SIGNAL




← SEGMENT CONTROL SIGNAL


← GRID CONTROL SIGNAL

← ■ ■ ■ TUNE CONTROL SIGNAL



3-35. TIMER C.B.A. (VEP07450C: NV-D48EG) (VEP07450B: NV-D48) & OPERATION C.B.A. (VEP06482B: NV-D48EG) (VEP06482C: NV-D48B)






ADDRESS INFORMATION




3-36. VPS PACK SCHEMATIC DIAGRAM (NV-D48EG)

3-37. VPS PACK C.B.A.




3-37. VPS PACK C.B.A. (VEP07439A: NV-D48EG)




VPS PACK C.B.A.	
Transistor	
Q7801	A-3
Q7802	A-3
Q7803	B-2
Transistor & Resistor	
QR7851	B-1
QR7852	A-2
Integrated Circuit	
IC7801	A-3
IC7802	A-2
IC7851	B-1
IC7852	A-2


ADDRESS INFORMATION



A
B
C
D
E
F
G
H



MAIN C.B.A. ADDRESS INFORMATION



POWER SUPPLY Section	
Transistor & Resistor	
QR1101	D-10
Test Point	
TP1002	F-12
TP1003	D-9
TP GND 1	E-11
Connector	
P1101	E-10

ADDRESS INFORMATION

SERVO Section	
Transistor	
Q2001	D-6
Q2002	D-7
Q2003	D-4
Q2004	D-5
Q2006	D-6
Transistor & Resistor	
QR2002	B-8
QR2007	D-5
Test Point	
TP2001	A-7
TP2002	D-4
TP2009	C-7
TP2015	B-7
TP2025	D-5
TP2026	D-6
Adjustment	
VR2001	A-8
VR2002	A-3
VR2010	E-13
VR2011	A-9
VR2013	A-10

ADDRESS INFORMATION

SYSTEM CONTROL Section	
Transistor	
Q1501	A-1
Q1502	A-2
Q6006	D-6
Q6009	E-6
Q6016	E-8
Q6017	A-4
Q6018	B-4
Q6019	B-4
Q6020	B-4
Transistor & Resistor	
QR6001	C-6
QR6005	D-6
QR6006	B-3
QR6007	E-6
QR6008	C-6
QR6011	E-7
QR6012	B-6
Integrated Circuit	
IC1501	C-2
IC6001	C-5
IC6002	B-5
IC6003	D-5
IC6004	C-5
Test Point	
TP6010	C-8
TP6011	A-7
TP GND 2	C-5
Connector	
P1504	F-2
P1505	F-2
P1506	C-1
P1507	A-1
P1508	B-2
P6001	C-4
P6002	B-6
P6003	C-3
P6004	B-6
P6005	D-6

ADDRESS INFORMATION

LUMINANCE & CHROMINANCE Section	
Transistor	
Q3002	F-13
Q3005	C-12
Q3006	D-8
Q3007	D-7
Q3011	D-12
Q3013	B-12
Transistor & Resistor	
QR3004	D-8
QR3011	C-12
QR3014	D-6
Integrated Circuit	
IC3001	D-11
IC3002	B-12
Test Point	
TP3001	D-8
TP3002	C-13
Adjustment	
VR3012	D-10
VR3020	A-12
Connector	
P3001	E-8
P3002	D-10

ADDRESS INFORMATION


AUDIO Section	
Transistor	
Q4001	C-11
Transistor & Resistor	
QR4006	C-10
QR4007	C-11
Integrated Circuit	
IC4001	C-9
Test Point	
TP4001	C-13
TP4002	B-10
TP4003	B-10
Adjustment	
VR4001	B-9
VR4002	B-10
Connector	
P4001	B-10

ADDRESS INFORMATION


CH SELECT Section	
Transistor & Resistor	
QR7551	F-11
QR7552	F-11
QR7553	F-11
QR7554	H-11
QR7556	C-3
Integrated Circuit	
IC7551	G-12
IC7552	G-11
IC7553	H-12
Test Point	
TP7504	D-4
TP7517	B-4
TP7518	B-4
TP7519	C-4
Connector	
P7401	C-3
P7402	D-3

ADDRESS INFORMATION

3-39. RF CONVERTER SCHEMATIC DIAGRAM (ENC87966: NV-D48EG)




3-40. RF CONVERTER SCHEMATIC DIAGRAM (ENC87962: NV-D48B)



3-41. DIGITAL SCANNER SCHEMATIC DIAGRAM

— UNIT NO.: VEQ0691 (NV-D48EG), VEQ0692 (NV-D48B) —



48EG)

3-41. DIGITAL SCANNER SCHEMATIC DIAGRAM

— UNIT NO.: VEQ0691 (NV-D48EG), VEQ0692 (NV-D48B) —

VTR OUT

RF OUT

C13
4P


JO-1

48B)


VTR OUT

RF OUT


JO-1



NOTE: DO NOT USE THE PART NUMBER SHOWN ON THIS DRAWING FOR ORDERING. THE CORRECT PART NUMBER IS SHOWN IN THE PARTS LIST, AND MAY BE SLIGHTLY DIFFERENT OR AMENDED SINCE THIS DRAWING WAS PREPARED.



3-42. DIGITAL SCANNER C.B.A. (VEP66039C: NV-D48EG) (VEP66039B: NV-D48B)




3-43. REMOTE CONTROLLER SCHEMATIC DIAGRAM

— UNIT NO.: VEQ0709 (NV-D48EG), VEQ0710 (NV-D48B) —


SECTION 4

EXPLODED VIEWS & PARTS LIST


4-1. EXPLODED VIEW ❶ CHASSIS PARTS SECTION (1)



② CHASSIS PARTS SECTION (2)




3 CASSETTE UP MECHANISM SECTION




4




5 PACKING PARTS SECTION



6 REMOTE CONTROLLER UNIT



7 DIGITAL SCANNER



PARTS LIST

MODEL NO: NV-D48EG/B

1.NV-D48EG/B Mechanical Replacement Parts List

※ This parts list is detachable from the manual.

Note:1.* Be sure to make your orders of replacement parts according to this list.
2.IMPORTANT SAFETY NOTICE
Components identified with the mark <1> have the special characteristics for safety. When replacing any of these components, use only the same type.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
1(1)	VHD0141	HEAD AMP SET SCREW	2	
2(1)	VMA6897	HEAD AMP MOUNT ANGLE (L)	1	
3(1)	VMA6898	HEAD AMP MOUNT ANGLE (R)	1	
5(1)	VXS0073	EARTH PLATE UNIT	1	
6(1)	VEG0479	CYLINDER UNIT	1 <1>	
7(1)	VEH0343	UPPER CYLINDER UNIT	1	
9(1)	VXA2703	MAIN HOLDER UNIT	1	
10(1)	VSC1806	CYLINDER C.B.A.SHIELD PLATE	1	
11(1)	VXL1495	TENSION ARM (1) UNIT	1	
12(1)	VMB1563	TENSION SPRING	1	
13(1)	VX20225	TENSION BAND UNIT	1	
14(1)	VXR0145	SUPPLY REEL TABLE UNIT	1	
15(1)	VMX1171	REEL WASHER (0.5mm)	2	
15(1)	VMX1239	REEL WASHER (0.3mm)	2	
15(1)	VMX1238	REEL WASHER (0.2mm)	2	
16(1)	VXL1496	TENSION RELEASE ARM(A)UNIT	1	
17(1)	VBS0038	FE HEAD	1	
18(1)	VXA2705	TENSION ARM BASE (1) UNIT	1	
19(1)	VMA6895	MOUNT ANGLE (L)	1	
20(1)	VMX1079	CUT WASHER	3	
21(1)	VXL1497	TENSION RELEASE ARM(B)UNIT	1	
22(1)	VMB1582	TENSION RELEASE SPRING	1	
23(1)	VES0350	SAFETY SW	1	
24(1)	VX20229	SUPPLY MAIN BRAKE UNIT	1	
25(1)	VX20228	SUPPLY SOFT BRAKE(1)UNIT	1	
26(1)	VMB1564	SUPPLY SOFT BRAKE SPRING	1	
27(1)	VX20231	TAKE UP MAIN BRAKE UNIT	1	
28(1)	VX20221	TAKE UP SOFT BRAKE UNIT	1	
29(1)	VMB1561	TAKE UP SOFT BRAKE SPRING	1	
30(1)	VMA6896	MOUNT ANGLE (R)	1	
31(1)	VHD0322	ADJUST SCREW	1	
32(1)	VMB1251	ADJUST SPRING	1	
33(1)	VHD0089B	AZIMUTH ADJUST SCREW	1	
34(1)	VBR0129	A/C HEAD	1	
35(1)	VHN0063	M4 NYLON NUT	1	
36(1)	VHN0050	ADJUST NUT	1	
37(1)	VXA2675	HEAD BASE UNIT	1	
38(1)	VMB1567	A/C HEAD SPRING	1	
39(1)	VXL1480	SUB LOADING ARM (1) UNIT	1	
40(1)	VMB1566	SUB POST SPRING	1	
41(1)	VXQ0006	THRUST SCREW UNIT	1	
42(1)	VHD0317	HOUSING SCREW	2	
43(1)	VMX1033	OIL SEAL	2	
44(1)	VMX1353	PINCH CAM CAP	1	
45(1)	VXL1743	PRESSURE ROLLER UNIT	1	
46(1)	VMB1568	PIN PRESSURE SPRING	1	
47(1)	VML1873	PINCH PRESSURE ARM	1	
48(1)	VMB1569	PINCH PRESSURE ARM RELEASE SPRING	1	
49(1)	VML1874	PINCH LIFT ARM	1	
50(1)	VDG0357	P5 PULL OUT SECTOR GEAR	1	
51(1)	VDG0421	PINCH CAM	1	
52(1)	VHN0023	M3 NYLON NUT	1	
53(1)	VXL1485	P5 UNIT	1	
54(1)	VMB1554	P5 SPRING	1	
55(1)	VSS0175	MODE SW	1	
56(1)	VSC1851	SHIELD PLATE	1	
57(1)	VXPO863	ROLLER POST UNIT	1	
58(1)	VXA2729	INCLIND BASE (S)(1)UNIT	1	
59(1)	VHD0133	ROLLER POST SCREW	2	
60(1)	VMD0910	POST STOPPER	2	
61(1)	VXPO764A	ROLLER POST UNIT	1	
62(1)	VXA2686	INCLIND BASE(T)(1)UNIT	1	
63(1)	VXA2687	INCLIND ADJUST PLATE UNIT	1	
64(1)	VDG0483	PINCH SPEED DOWN GEAR	1	
65(1)	VDG0332	CONNECTION GEAR	1	
66(1)	VXA2693	SOLENOID	1	
67(1)	VXA2692	KICK ROD UNIT	1	
68(1)	VML1849	SOLENOID LEVER (1) UNIT	1	
69(1)	VMB1553	KICK ROD SPRING	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
70(1)	VMB1565	MAIN BRAKE SPRING	1	
71(1)	VXR0146	TAKE UP REEL TABLE UNIT	1	
72(1)	VXD0101	HOUSING UNIT	1	
74(1)	VSC1843	HEAT SINK PLATE	1	
75(1)	VHD0329	HEAT SINK SCREW	1	
76(1)	VHD0374	HOUSING SCREW	1	
100(2)	VMX1079	CUT WASHER	9	
101(2)	VMB1583	TAKE UP SOFT BRAKE RELEASE ARM SPRING	1	
102(2)	VMB1560	MAIN LEVER SPRING	1	
103(2)	VXA2701	MAIN LEVER (1) UNIT	1	
104(2)	VMM0160	SUB LEVER	1	
105(2)	VXL1500	SS BRAKE ARM UNIT	1	
106(2)	VMB1588	SS BRAKE SPRING	1	
107(2)	VXA2707	SS BRAKE BASE (1) UNIT	1	
108(2)	VXA2674	TENSION ROLLER UNIT	1	
109(2)	VXL1632	CAM FOLLOWER ARM UNIT	1	
110(2)	VML1861	DETENT ARM	1	
111(2)	VDG0346	MAIN CAM GEAR	1	
112(2)	VDG0343	SUB CAM GEAR	1	
113(2)	VDG0348	CENTRE GEAR	1	
114(2)	VDG0422	RETAINER GEAR	1	
115(2)	VDG0345	PLANET GEAR	3	
116(2)	VDG0349	CLUTCH DISK	1	
117(2)	VMB1558	CLUTCH SPRING	1	
118(2)	VDG0350	LOCK SLIDE GEAR	1	
119(2)	VDG0335	DRIVE DISK	1	
120(2)	VDG0342	RING GEAR	1	
121(2)	VMX0967	CUT WASHER	2	
122(2)	VML1859	CHANGE LEVER	1	
123(2)	VXA2672	RELEASE LEVER (1) UNIT	1	
124(2)	VMB1557	RELEASE SPRING	1	
125(2)	VML1860	RELEASE LEVER	1	
127(2)	VXPO923	TAKE UP REEL GEAR UNIT	1	
128(2)	VDG0445	SUPPLY REEL GEAR	1	
129(2)	VML1858	RETURN LEVER (R)	1	
130(2)	VML1857	RETURN LEVER (L)	1	
131(2)	VMD0913	STOPPER BASE	1	
132(2)	VDV0169	TIMING BELT	1	
133(2)	VXPO777	ROTOR UNIT	1	
134(2)	VMA6998	ROTOR STOPPER	1	
135(2)	VEK2944	STATOR UNIT	1 <1>	
136(2)	VMA6847	SUB PLATE	1	
137(2)	VXPO917	CENTRE PULLEY UNIT	1	
138(2)	VDG0420	LOADING GEAR (T)	1	
139(2)	VMB1555	LOADING SPRING (T)	1	
140(2)	VXL1489	LOADING ARM (T)(1) UNIT	1	
141(2)	VXA3144	SECTOR GEAR UNIT	1	
142(2)	VDG0448	LOADING CAM GEAR	1	
143(2)	VDG0419	LOADING GEAR (S)	1	
144(2)	VML1855	PLAY CONTROL ARM	1	
145(2)	VXL1487	LOADING ARM (S)(1) UNIT	1	
146(2)	VDG0336	INTERMEDIATE GEAR	1	
147(2)	VXL1490	PLAY ARM UNIT	1	
148(2)	VBR0048	FG HEAD	1	
149(2)	VMB1746	LOADING SPRING(S)	1	
201(3)	VMA7223	TOP PLATE	1	
202(3)	VXA2679	CASSETTE HOLDER UNIT	1	
203(3)	VMB1573	MOUNT LEVER SPRING	1	
204(3)	VMD0919	HOLDER GUIDE (L)	1	
205(3)	VMM0163	MOUNT LEVER	1	
206(3)	VDP1077	ROLLER	2	
207(3)	VML1883	PRESSURE LEVER (L)	1	
208(3)	VMA6902	HOLDER ANGLE	1	
209(3)	VMA6901	CASSETTE HOLDER	1	
210(3)	VML1882	OPENER LEVER	1	
211(3)	VML1884	PRESSURE LEVER (R)	1	
212(3)	VMB1584	OPENER LEVER SPRING	1	
213(3)	VMD0920	HOLDER GUIDE (R)	1	
214(3)	VMB1576	RELEASE SPRING	1	
215(3)	VML1881	RELEASE LEVER	1	
216(3)	VXA2676	SIDE PLATE (L) UNIT	1	
217(3)	VMD0917	SIDE PLATE (L)	1	
218(3)	VML1880	OPENER LEVER	1	
219(3)	VXA3171	SIDE PLATE (R) UNIT	1	

To guarantee the FUNCTION,SAFETY and RELIABILITY of repaired units,only use ORIGINAL REPLACEMENT PARTS which are listed with their part numbers in this parts list section.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
220(3)	VMD0918	SIDE PLATE (R)	1		409(5)	VEQ0692	DIGITAL SCANNER	1	NV-D48B
221(3)	VSS0176	SLIDE SW	1		410(5)	VQC1159	PROGRAMME SHEET	1	NV-D48EG
222(3)	VML1886	DOWN SUPPORT LEVER	1		410(5)	VQC1186	PROGRAMME SHEET	1	NV-D48B
223(3)	VMB1575	DOWN SUPPORT SPRING	1		412(5)	VPK0834	ACCESSORIES PACKING CASE	1	
224(3)	VXA3148	RACK (A)(1) UNIT	1		414(5)	VFC0115	DIGITAL SCANNER CASE	1	
225(3)	VMB1778	CLUTCH SPRING	1		416(5)	VQF2115	CLEANING BRUSH	1	
226(3)	VMB1772	LOCK SPRING	1		450(6)	VYK2012	TOP CASE UNIT	1	NV-D48EG
227(3)	VML1885	LOCK LEVER	1		450(6)	VYK2013	TOP CASE UNIT	1	NV-D48B
228(3)	VXA3147	RACK (B) UNIT	1		451(6)	VKM1133	BOTTOM CASE	1	
229(3)	VXP0851	MAIN SHAFT UNIT	1		452(6)	VKF0971	BATTERY COVER	1	
230(3)	VMB1570	SUB WIPER SPRING (L)	1		453(6)	VKG0878	IR WINDOW	1	
231(3)	VML1878	SUB WIPER ARM	1		454(6)	VSP0356	RUBBER CONTACT	1	NV-D48EG
232(3)	VML1879	SUB WIPER ARM (R)	1		454(6)	VSP0355	RUBBER CONTACT	1	NV-D48B
233(3)	VMB1571	SUB WIPER SPRING (R)	1		455(6)	VJRO185	ELECTRODE (COMMON)	1	
234(3)	VMA6900	CASSETTE GUIDE	1		470(7)	VYK1992	TOP CASE UNIT	1	NV-D48EG
235(3)	VKF1026	BLINDER PANEL	1		470(7)	VYK1193	TOP CASE UNIT	1	NV-D48B
236(3)	VMB1258	BLINDER SPRING	1		471(7)	VGU4099	TRANSMISSION BUTTON	1	
237(3)	VMB1780	RACK (C) SPRING	1		472(7)	VGU4100	POWER SW KNOB	1	
238(3)	VMA7237	CONNECTION ROD	1		473(7)	VJRO411	ELECTRODE (+)	1	
239(3)	VMB1779	CONNECTION ROD SPRING	1		474(7)	VJRO412	ELECTRODE (-)	1	
240(3)	VMA7224	CASSETTE HOLDER ANGLE	1		475(7)	VJRO272	ELECTRODE (COM)	1	
300(4)	VYP2377	TOP PANEL UNIT	1		476(7)	VKF1024	BATTERY CASE	1	
301(4)	VHD0378	TOP PANEL SCREW	4		477(7)	VKM1331	BOTTOM CASE	1	
302(4)	VKU0283	BOTTOM PLATE UNIT	1		478(7)	VKG0940	SMOKE FILTER	1	
303(4)	VYP2331	FRONT PANEL UNIT	1	NV-D48EG	479(7)	VSQ0567	SENSOR UNIT	1	
303(4)	VYP2332	FRONT PANEL UNIT	1	NV-D48B	480(7)	VKM1332	SENSOR CAP	1	
304(4)	VYF1206	SUPPORT PANEL UNIT	1						
305(4)	VYCO274	DOOR ALUMINUM UNIT	1						
306(4)	VMO0376	EARTH SPRING	1						
307(4)	VES0457	KEY BOARD PANEL UNIT	1	NV-D48EG			JIG		
307(4)	VES0458	KEY BOARD PANEL UNIT	1	NV-D48B		VFJ8125H3F	VHS-ALIGNMENT TAPE (PAL)	1	
308(4)	VMT0212	CUSHION RUBBER	2			VPK0335	RETAINING RING REMOVER	1	
309(4)	VGP1924	DOOR BACK PANEL	1				(3mm/4mm)		
310(4)	VDG0462	DAMPER GEAR	1			VPK0387	TENSION POST ADJUSTMENT	1	
311(4)	VMO0272	RF CONVERTER BUSHING	2				PLATE		
313(4)	VXA3179	POWER SHIELD CASE(MAIN)	1			VPK0191	POST ADJUSTMENT PLATE	1	
314(4)	VSC2397	POWER SHIELD CASE(TOP)	1			VPK0190	REEL TABLE HEIGHT GAUGE	1	
315(4)	VGH1476	NAME PLATE	1			VPK0328	H-POSITION ADJ.	1	
316(4)	VGQ1377	TR. HOLDER	1				SCREWDRIVER		
317(4)	VMZ1224	INSULATION SHEET	1	<1>		VPK0329	POST ADJUSTMENT SCREWDRIVER	1	
318(4)	VMZ1140	SW BARRIER(A)	1			VPK62	FAN TYPE TENSION GAUGE	1	
319(4)	VSC2237	POWER SHIELD CASE(BOTTOM)	1			VPK0326	HEX WRENCH SET	1	
320(4)	VSC2238	HEAT SINK	1			VPK0132	BACK TENSION METER	1	
321(4)	VMO0357	HOLD SPRING(D1010)	1			VPK0343	CHECK LIGHT	1	
322(4)	VMO0364	HOLD SPRING(Q1002)	1			VPK0344	HEIGHT ADJUSTMENT JIG	1	
323(4)	VMO0326	MAIN HINGE	2			VPK27	HEAD CLEANING STICK	1	
324(4)	VMO0328	TIMER HINGE(B)	1			MOR265	MORLYTONE GREASE	1	
325(4)	VMO0334	TIMER HINGE(C)	1			VPK0283	SERVICE ALIGNMENT TOOL KIT	1	
326(4)	VMP1127	TOP HOLDER ANGLE(R)	1			VPK0341	UPPER CYLINDER REMOVER	1	
327(4)	VMP1037	TOP HOLDER ANGLE(L)	3			VEE4250	RF ADJUSTMENT CABLE (220mm)	1	
328(4)	VMP1567	MAIN C.B.A.EARTH ANGLE	1						
329(4)	VDG0437	DOOR GEAR	1						
330(4)	VMP1547	EARTH ANGLE	1						
331(4)	VKA0026	RUBBER FOOT	2						
332(4)	VHD0059	BOTTOM PLATE SCREW	8						
333(4)	VHD0141	MAIN C.B.A. SCREW	1						
334(4)	VSC2524	BCI SHIELD PLATE	1	NV-D48EG					
335(4)	VMP1735	N-FTZ EARTH ANGLE	1	NV-D48EG					
336(4)	VMO0395	DOOR HOLD SPRING	1						
400(5)	VQT2652	OPERATING INSTRUCTIONS	1	NV-D48EG<1>					
		(ENGLISH/GERMAN/ITALIAN)							
400(5)	VQT2653	OPERATING INSTRUCTIONS	1	NV-D48B<1>					
		(ENGLISH)							
400(5)	VQT2675	OPERATING INSTRUCTIONS	1	NV-D48B<1>					
		(GREEK)							
401(5)	VJA0376	DIN RF CABLE	1						
403(5)	VEQ0709	REMOTE CONTROL UNIT	1	NV-D48EG					
403(5)	VEQ0710	REMOTE CONTROL UNIT	1	NV-D48B					
404(5)	VPN2120	CUSHION (L)	1						
405(5)	VPN2119	CUSHION (R)	1						
406(5)	VPG4053	PACKING CASE	1	NV-D48EG					
406(5)	VPG4054	PACKING CASE	1	NV-D48B					
408(5)	VJA0443	AC CORD	1	NV-D48EG<1>					
408(5)	VJA0445	AC CORD	1	NV-D48B<1>					
409(5)	VEQ0691	DIGITAL SCANNER	1	NV-D48EG					

To guarantee the FUNCTION,SAFETY and RELIABILITY of repaired units,only use ORIGINAL REPLACEMENT PARTS which are listed with their part numbers in this parts list section.

2.NV-D48EG/B Electrical Replacement Parts List

Note:1.* Be sure to make your orders of replacement parts according to this list.
 2.IMPORTANT SAFETY NOTICE
 Components identified with the mark (!) have the special characteristics for safety. When replacing any of these components, use only the same type.
 3.Unless otherwise specified,
 All resistors are in OHMS, K=1,000 OHMS. All capacitors are in MICRO-FARADS(uf), P=ufF.
 4.The P.C.Board units marked with (!) show below the main assembled parts.
 5.Printed circuit board assembly with mark(NLA) is no longer available after discontinuation of the product.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
	■ VEPO3493BE	MAIN C.B.A. (POWER, SERVO, LUMINANCE & CHROMINANCE, SYSTEM CONTROL, AUDIO)	1	NV-D48EG(!)(NLA) INCLUDING THE SUB MAIN PACK C.B.A. (VEPO2316C) WITH VISS PACK C.B.A. (VEPO2315A), LUMINANCE & CHROMINANCE PACK C.B.A. (VEPO3543C), WITH SECAM PACK C.B.A. (VEPO3452B), TV DEMODULATOR C.B.A. (VEPO7466A), VPS PACK C.B.A. (VEPO7439A), INPUT SELECT PACK C.B.A. (VEPO3494A).
	■ VEPO3493BG	MAIN C.B.A. (POWER, SERVO, LUMINANCE & CHROMINANCE, SYSTEM CONTROL, AUDIO)	1	NV-D48B(!)(NLA) INCLUDING THE SUB MAIN PACK C.B.A. (VEPO2316A) WITH VISS PACK C.B.A. (VEPO2315A), LUMINANCE & CHROMINANCE PACK C.B.A. (VEPO3543D), TV DEMODULATOR C.B.A. (VEPO7444E)
	■ VEPO2316C	SUB MAIN PACK C.B.A.	1	NV-D48EG(NLA) INCLUDING THE VISS PACK C.B.A. (VEPO2315A).
	■ VEPO2316A	SUB MAIN PACK C.B.A.	1	NV-D48B(NLA) INCLUDING THE VISS PACK C.B.A. (VEPO2315A)
	■ VEPO2315A	VISS PACK C.B.A.	1	(NLA)
	■ VEPO3543C	LUMINANCE & CHROMINANCE PACK C.B.A.	1	NV-D48EG(NLA) INCLUDING THE SECAM PACK C.B.A. (VEPO3452B).
	■ VEPO3543D	LUMINANCE & CHROMINANCE PACK C.B.A.	1	NV-D48B(NLA)
	■ VEPO7466A	TV DEMODULATOR C.B.A.	1	NV-D48EG(NLA)
	■ VEPO7444E	TV DEMODULATOR C.B.A.	1	NV-D48B(NLA)

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
	■ VEPO5118B	HEAD AMP C.B.A.	1	(NLA)
	■ VEPO6482B	OPERATION C.B.A.	1	NV-D48EG(NLA)
	■ VEPO6482C	OPERATION C.B.A.	1	NV-D48B(NLA)
	■ VEPO7450C	TIMER C.B.A.	1	NV-D48EG(NLA) INCLUDING THE IR RECEIVER C.B.A. (VEPO6380E).
	■ VEPO7450B	TIMER C.B.A.	1	NV-D48B(NLA) INCLUDING THE IR RECEIVER C.B.A. (VEPO6380E).
	■ VEPO6380E	IR RECEIVER C.B.A.	1	(NLA)
	■ VEPO3528A	SUB DIGITAL C.B.A.	1	(NLA) INCLUDING THE MAIN DIGITAL C.B.A. (VEPO3527A)
	■ VEPO3527A	MAIN DIGITAL C.B.A.	1	(NLA)
	■ VEPO1310H	POWER C.B.A.	1	NV-D48EG(!)(NLA) INCLUDING THE SUB POWER C.B.A. (VEPO1311B)
	■ VEPO1310J	POWER C.B.A.	1	NV-D48B(!)(NLA) INCLUDING THE SUB POWER C.B.A. (VEPO1311B)
	■ VEPO1311B	SUB POWER C.B.A.		(NLA)
	■ VEP66039C	DIGITAL SCANNER C.B.A.	1	NV-D48EG(NLA)
	■ VEP66039B	DIGITAL SCANNER C.B.A.		NV-D48B(NLA)
	■ VEP66030C	PROGRAMMABLE REMOTE CONTROLLER C.B.A.	1	(NLA)
	■ VEK3583	MECHANISM CONNECTION C.B.A.	1	(NLA)
	■ VEK3555	REEL SENSOR C.B.A.	1	(NLA)
	■ VXAX2689	LED C.B.A.	1	(NLA)
	■ VEK3577	PHOTO TR. (T) C.B.A.	1	(NLA)

To guarantee the FUNCTION, SAFETY and RELIABILITY of repaired units, only use ORIGINAL REPLACEMENT PARTS which are listed with their part numbers in this parts list section.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
	VEK3578	PHOTO TR.(S) C.B.A.	1	(NLA)
F1001	XBA2C16TBO	FUSE 250V 1.6A	1	(1)
	VEPO3493BE	MAIN C.B.A.		NV-D48EG(!) (NLA)
		CAPACITORS		
C301	ECEA1EKN2R2	E.CAPACITOR 25V 2.2U	1	
C302	ECEA0JK220	E.CAPACITOR 6.3V 22U	1	
C303	ECUX1E1042FN	CHIP 25V 0.1U	1	
C304	ECEA0JU331	E.CAPACITOR 6.3V 330U	1	
C305	ECEA1CK100	E.CAPACITOR 16V 10U	1	
C306	ECEA1EK4R7	E.CAPACITOR 25V 4.7U	1	
C307	ECUM1H470JCN	CHIP 50V 47P	1	
C308	ECUM1H220JCN	CHIP 50V 22P	1	
C310	ECEA1CK100	E.CAPACITOR 16V 10U	1	
C311,12	ECUM1H180JCN	CHIP 50V 18P	2	
C313	ECEA1CK100	E.CAPACITOR 16V 10U	1	
C314	ECUM1H121JCN	CHIP 50V 120P	1	
C315	ECUM1H560JCN	CHIP 50V 56P	1	
C317	ECEA1AK470	E.CAPACITOR 10V 47U	1	
C319	ECUM1H471KBN	CHIP 50V 470P	1	
C320	ECUM1H270JCN	CHIP 50V 27P	1	
C321	ECEA1HK010	E.CAPACITOR 50V 1U	1	
C322	ECEA1HK2R2	E.CAPACITOR 50V 2.2U	1	
C324	ECEA1CK100	E.CAPACITOR 16V 10U	1	
C325,26	ECUM1H1032FN	CHIP 50V 0.01U	2	
C327,28	ECEA1CK100	E.CAPACITOR 16V 10U	2	
C329	ECUM1H1032FN	CHIP 50V 0.01U	1	
C331	ECUM1H1032FN	CHIP 50V 0.01U	1	
C332	ECQV1H334JZ	P.CAPACITOR 50V 0.33U	1	
C333	ECEA1HK4R7	E.CAPACITOR 50V 4.7U	1	
C334	ECUM1H1032FN	CHIP 50V 0.01U	1	
C335	ECUM1H680JCN	CHIP 50V 68P	1	
C336	ECUM1H101JCN	CHIP 50V 100P	1	
C337	ECUM1H270JCN	CHIP 50V 27P	1	
C338	ECUX1E1042FN	CHIP 25V 0.1U	1	
C339	ECUM1H680JCN	CHIP 50V 68P	1	
C340	ECEA1EK4R7	E.CAPACITOR 25V 4.7U	1	
C349	ECUM1H470JCN	CHIP 50V 47P	1	
C351	ECQV1H220JC	C.CAPACITOR 50V 22P	1	
C352	ECQB1H562JH	P.CAPACITOR 50V 5600P	1	
C353	ECUM1H560JCN	CHIP 50V 56P	1	
C701	ECQV1H104JZ	P.CAPACITOR 50V 0.1U	1	
C702	ECEA1CK100	E.CAPACITOR 16V 10U	1	
C703	ECEA1HK2R2	E.CAPACITOR 50V 2.2U	1	
C705,06	ECEA1EKS4R7	E.CAPACITOR 25V 4.7U	2	
C707	ECEA1HKS010	E.CAPACITOR 50V 1U	1	
C708	ECEA1CKS100	E.CAPACITOR 16V 10U	1	
C710	ECUX1H1032FN	CHIP 50V 0.01U	1	
C715-20	ECUX1H1032FN	CHIP 50V 0.01U	6	
C721	ECEA1HGR27	E.CAPACITOR 50V 0.27U	1	
C722	ECUX1H1032FN	CHIP 50V 0.01U	1	
C723	ECUX1H220JCN	CHIP 50V 22P	1	
C725	ECQV1H104JZ	P.CAPACITOR 50V 0.1U	1	
C727	ECUX1H080DCN	CHIP 50V 80P	1	
C728	ECUX1H1032FN	CHIP 50V 0.01U	1	
C730	ECEA1CK100	E.CAPACITOR 16V 10U	1	
C731	ECEA1CKS100	E.CAPACITOR 16V 10U	1	
C732	ECQV1H224B	M.CAPACITOR 50V 0.22U	1	
C734	ECUX1H1032FN	CHIP 50V 0.01U	1	
C735	ECUX1H070DCN	CHIP 50V 7P	1	
C736	ECQB1H103JH	P.CAPACITOR 50V 0.01U	1	
C737	ECUX1H151JCN	CHIP 50V 150P	1	
C739	ECEA1HK010	E.CAPACITOR 50V 1U	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C740	ECUX1H1032FN	CHIP 50V 0.01U	1	
C741	ECEA1CK100	E.CAPACITOR 16V 10U	1	
C742	ECUX1H030CCN	CHIP 50V 3P	1	
C743	ECUM1H270RSN	CHIP 50V 27P	1	
C744	ECEA1HGR47	E.CAPACITOR 50V 0.47U	1	
C745	ECUX1H680JFN	CHIP 50V 68P	1	
C746	ECUX1H150JCN	CHIP 50V 15P	1	
C747	ECUX1H1032FN	CHIP 50V 0.01U	1	
C748	ECEA1CK330	E.CAPACITOR 16V 33U	1	
C749	ECEA1CK100	E.CAPACITOR 16V 10U	1	
C760	ECQV1H473JZ	P.CAPACITOR 50V 0.047U	1	
C775	ECUM1H120JCN	C.CAPACITOR CH 50V 12P	1	
C781	ECUX1H220JCN	CHIP 50V 22P	1	
C782	ECUM1H060DCN	CHIP 50V 6P	1	
C783	ECQV1H104JZ	P.CAPACITOR 50V 0.1U	1	
C787	ECEA1EKS4R7	E.CAPACITOR 25V 4.7U	1	
C801	ECUM1H1032FN	CHIP 50V 0.01U	1	
C814	ECEA1AK101	E.CAPACITOR 10V 100U	1	
C815	ECQV1H154JZ	P.CAPACITOR 50V 0.15U	1	
C816	ECUX1E1042FN	CHIP 25V 0.1U	1	
C817	ECQV1H274JZ	P.CAPACITOR 50V 0.27U	1	
C818	ECUM1H471KBN	CHIP 50V 470P	1	
C819	ECUM1H820JCN	CHIP 50V 82P	1	
C820	ECEA1HK2R2	E.CAPACITOR 50V 2.2U	1	
C821	ECEA1HFS4R7	E.CAPACITOR 50V 4.7U	1	
C823	ECEA1HK2R2	E.CAPACITOR 50V 2.2U	1	
C824	ECEA1HK010	E.CAPACITOR 50V 1U	1	
C825	ECUM1H101JCN	CHIP 50V 100P	1	
C826	ECEA1AU221	E.CAPACITOR 10V 220U	1	
C827	ECUM1H050CCN	CHIP 50V 5P	1	
C828	ECUM1H102KBN	CHIP 50V 1000P	1	
C829	ECQV1H474JZ	P.CAPACITOR 50V 0.47U	1	
C830	ECEA1EK4R7	E.CAPACITOR 25V 4.7U	1	
C831,32	ECUX1E1042FN	CHIP 25V 0.1U	2	
C851	ECQF1H1032F	C.CAPACITOR 50V 0.01U	1	
C852	ECEA1CK330	E.CAPACITOR 16V 33U	1	
C853	ECEA10247	E.CAPACITOR 10V 47U	1	
C854	ECQV1H563JZ	P.CAPACITOR 50V 0.056U	1	
C855	ECEA1CK330	E.CAPACITOR 16V 33U	1	
C856	ECQF1H1032F	C.CAPACITOR 50V 0.01U	1	
C858	ECQF1H681KB	C.CAPACITOR 50V 680P	1	
C1101	ECEA1EK100	E.CAPACITOR 25V 10U	1	
C1103	ECEA0JK101	E.CAPACITOR 6.3V 100U	1	
C2022	ECEA1CK100	E.CAPACITOR 16V 10U	1	
C2023	ECEA1HGR47	E.CAPACITOR 50V 0.47U	1	
C2024	ECUM1H182KBN	CHIP 50V 1800P	1	
C2026	ECQB1H333JH	P.CAPACITOR 50V 0.033U	1	
C2027	ECEA0JK470	E.CAPACITOR 6.3V 47U	1	
C2104	ECEA1CKN100	E.CAPACITOR 16V 10U	1	
C2105	VCYD1C473MR1	S.CAPACITOR 16V 0.047U	1	
C2106	ECEA1CK100	E.CAPACITOR 16V 10U	1	
C2107	ECEA1HKN010	E.CAPACITOR 50V 1U	1	
C2108	ECEA1CK100	E.CAPACITOR 16V 10U	1	
C2109	ECEA1HKN010	E.CAPACITOR 50V 1U	1	
C2110	ECEA0JK330	E.CAPACITOR 6.3V 33U	1	
C2112	VCYD1C104MR1	S.CAPACITOR 16V 0.1U	1	
C2113	ECQV1H683JZ	P.CAPACITOR 50V 0.068U	1	
C2114	ECUM1H102KBN	CHIP 50V 1000P	1	
C2115	ECEA1HKNR33	E.CAPACITOR 50V 0.33U	1	
C2116	VCYD1C104MR1	S.CAPACITOR 16V 0.1U	1	
C2117	ECEA1HGR47	E.CAPACITOR 50V 0.47U	1	
C2118	ECUM1H472KBN	CHIP 50V 4700P	1	
C2119	ECQV1H334JZ	P.CAPACITOR 50V 0.33U	1	
C2120	ECUM1H1032FN	CHIP 50V 0.01U	1	
C2121	VCYD1C104MR1	S.CAPACITOR 16V 0.1U	1	
C2122	ECUM1H562KBN	CHIP 50V 5600P	1	
C2123	VCYD1E223KR	S.CAPACITOR 25V 0.022U	1	
C2124,25	ECEA0JK470	E.CAPACITOR 6.3V 47U	2	
C2126	ECUM1H102KBN	CHIP 50V 1000P	1	
C2127	ECUM1H332KBN	CHIP 50V 3300P	1	
C2129	ECQB1H272JH	P.CAPACITOR 50V 2700P	1	
C2130	ECEA1CKN100	E.CAPACITOR 16V 10U	1	
C2131	ECEA1HKN010	E.CAPACITOR 50V 1U	1	
C2132	ECEA1CK100	E.CAPACITOR 16V 10U	1	
C2134	ECUM1H102KBN	CHIP 50V 1000P	1	

To guarantee the FUNCTION,SAFETY and RELIABILITY of repaired units,only use ORIGINAL REPLACEMENT PARTS which are listed with their part numbers in this parts list section.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C2137	ECUM1H562KBN	CHIP 50V 5600P	1		C3803	ECEA1CK470	E.CAPACITOR 16V 47U	1	
C2138	ECEA0JK101	E. CAPACITOR 6.3V 100U	1		C3804	ECEA1HK2R2	E. CAPACITOR 50V 2.2U	1	
C2139	ECEA0JK221	E. CAPACITOR 6.3V 220U	1		C3805,06	ECEA1CK470	E. CAPACITOR 16V 47U	2	
C2140	ECEA1CK100	E. CAPACITOR 16V 10U	1		C3807	ECKF1H102KB	C. CAPACITOR 50V 1000P	1	
C2141	ECEA0JK470	E. CAPACITOR 6.3V 47U	1		C3808	ECEA0JK470	E. CAPACITOR 6.3V 47U	1	
C2142,43	ECUM1H1032FN	CHIP 50V 0.01U	2		C3809	ECEA1HK2R2	E. CAPACITOR 50V 2.2U	1	
C2146	VCYD1C104MR1	S. CAPACITOR 16V 0.1U	1		C3810	ECEA1HK3R3	E. CAPACITOR 50V 3.3U	1	
C2147	ECEA1CK100	E. CAPACITOR 16V 10U	1		C3811	ECEA1HK2R2	E. CAPACITOR 50V 2.2U	1	
C2148	ECUM1H102KBN	CHIP 50V 1000P	1		C3812	ECEA1CK330	E. CAPACITOR 16V 33U	1	
C2155	ECEA0JK101	E. CAPACITOR 6.3V 100U	1		C3813	VCYD1C104MR1	S. CAPACITOR 16V 0.1U	1	
C2156	ECUM1H1032FN	CHIP 50V 0.01U	1		C3814,15	ECEA1CK100	E. CAPACITOR 16V 10U	2	
C2158	ECUM1E103KBN	CHIP 25V 0.01U	1		C3816	ECKF1H121KB	C. CAPACITOR 50V 120P	1	
C2172	ECEA1EK3R3	E. CAPACITOR 25V 3.3U	1		C3817	ECEA1HK010	E. CAPACITOR 50V 1U	1	
C2174	ECUM1H102KBN	CHIP 50V 1000P	1		C3818	ECKF1H102KB	C. CAPACITOR 50V 1000P	1	
C2175	ECUM1E103KBN	CHIP 25V 0.01U	1		C3819	ECEA1HK010	E. CAPACITOR 50V 1U	1	
C2176	ECQV1H154JZ	P. CAPACITOR 50V 0.15U	1		C3821	ECKF1H471KB	C. CAPACITOR 50V 470P	1	
C2177	ECEA0JK470	E. CAPACITOR 6.3V 47U	1		C3822	VCYD1E103KR	S. CAPACITOR 25V 0.01U	1	
C2178	ECEA1HK22	E. CAPACITOR 50V 0.22U	1		C3823	ECKF1H102KB	C. CAPACITOR 50V 1000P	1	
C2179	ECUM1E103KBN	CHIP 25V 0.01U	1		C3824	ECEA0JK221	E. CAPACITOR 6.3V 220U	1	
C2181,82	ECEA0JK470	E. CAPACITOR 6.3V 47U	2		C3825	EOCF1H100DC	C. CAPACITOR 50V 10P	1	
C2184,85	ECUM1H332KBN	CHIP 50V 3300P	2		C3826	ECEA0JK221	E. CAPACITOR 6.3V 220U	1	
C2187	ECQV1H104JZ	P. CAPACITOR 50V 0.1U	1		C3827	EOCF1H050CC	C. CAPACITOR 50V 5P	1	
C2191,92	ECQV1H104JZ	P. CAPACITOR 50V 0.1U	2		C4001	ECQB1H153JH	P. CAPACITOR 50V 0.015U	1	
C2501-03	ECQB1H333JH	P. CAPACITOR 50V 0.033U	3		C4002	ECEA16233	E. CAPACITOR 16V 33U	1	
C2504-06	ECEA1HK2R2	E. CAPACITOR 50V 2.2U	3		C4003	ECKF1H102ZF	C. CAPACITOR 50V 1000P	1	
C2507	ECQB1H223JH	P. CAPACITOR 50V 0.022U	1		C4004	EQCP1332JZ	M. CAPACITOR 100V 3300P	1	
C2508	ECQV1H104JZ	P. CAPACITOR 50V 0.1U	1		C4005	ECCD2H121K	C. CAPACITOR 500V 120P	1	
C2511	ECEA1CK101	E. CAPACITOR 16V 100U	1		C4006	ECEA1CK470	E. CAPACITOR 16V 47U	1	
C2512-14	ECUM1H332KBN	CHIP 50V 3300P	3		C4007	ECEA1CK330	E. CAPACITOR 16V 33U	1	
C2517	ECEA1CK470	E. CAPACITOR 16V 47U	1		C4008	ECEA1HK010	E. CAPACITOR 50V 1U	1	
C2519	ECEA25247	E. CAPACITOR 25V 4.7U	1		C4009	ECEA1EK4R7	E. CAPACITOR 25V 4.7U	1	
C2524	ECQV1H274JZ	P. CAPACITOR 50V 0.27U	1		C4011	ECQB1H123JH	P. CAPACITOR 50V 0.012U	1	
C2801	ECEA1HK010	E. CAPACITOR 50V 1U	1		C4012	ECEA1CK100	E. CAPACITOR 16V 10U	1	
C2802	VCYD1E223KR	S. CAPACITOR 25V 0.022U	1		C4013	ECUM1H471KBN	CHIP 50V 470P	1	
C2803	ECEA0JK470	E. CAPACITOR 6.3V 47U	1		C4015	ECEA1CK100	E. CAPACITOR 16V 10U	1	
C2804	ECUM1H181KN	CHIP 50V 180P	1		C4016	ECUM1H102KBN	CHIP 50V 1000P	1	
C2805	ECEA1HK0N10	E. CAPACITOR 50V 1U	1		C4017	ECEA16M10	ELECTROLYTIC 16V 10U	1	
C2806	ECUM1H220JCN	CHIP 50V 22P	1		C4018	ECQB1H123JH	P. CAPACITOR 50V 0.012U	1	
C2807	ECEA0JK470	E. CAPACITOR 6.3V 47U	1		C4019	ECEA1CK100	E. CAPACITOR 16V 10U	1	
C2808	ECQV1H124JZ	P. CAPACITOR 50V 0.12U	1		C4020	ECUM1H102KBN	CHIP 50V 1000P	1	
C2809	ECEA1EK4R7	E. CAPACITOR 25V 4.7U	1		C4021	ECEA1AK470	E. CAPACITOR 10V 47U	1	
C2812,13	ECQV1H224JZ	P. CAPACITOR 50V 0.22U	2		C4022	ECUM1H102KBN	CHIP 50V 1000P	1	
C2918	ECQV1H104JZ	P. CAPACITOR 50V 0.1U	1		C4023	ECUX1H221JCN	CHIP 50V 220P	1	
C3001	ECEA1CK470	E. CAPACITOR 16V 47U	1		C4024,25	ECUM1H101JCN	CHIP 50V 100P	2	
C3002	ECEA0JU471	E. CAPACITOR 6.3V 470U	1		C4032	VCYD1C104MR1	S. CAPACITOR 16V 0.1U	1	
C3003,04	ECUM1H332KBN	CHIP 50V 3300P	2		C4038	ECEA1CK100	E. CAPACITOR 16V 10U	1	
C3007	ECEA1CK100	E. CAPACITOR 16V 10U	1		C6001	ECEA0JK220	E. CAPACITOR 6.3V 22U	1	
C3010	ECUM1H151JCN	CHIP 50V 150P	1		C6002	VCYD1C103MR1	S. CAPACITOR 16V 0.01U	1	
C3011	ECUM1H270JCN	CHIP 50V 27P	1		C6003	ECUM1H1032FN	CHIP 50V 0.01U	1	
C3012	ECUM1H681JN	CHIP 50V 680P	1		C6006	ECEA0JK330	E. CAPACITOR 6.3V 33U	1	
C3013	ECEA1HK0N10	E. CAPACITOR 50V 1U	1		C6007	VCYD1C104MR1	S. CAPACITOR 16V 0.1U	1	
C3014	ECUM1H150JCN	CHIP 50V 15P	1		C6013	ECEA1CK330	E. CAPACITOR 16V 33U	1	
C3015	VCYD1C104MR1	S. CAPACITOR 16V 0.1U	1		C6017-19	ECEA0JK470	E. CAPACITOR 6.3V 47U	3	
C3016	ECEA0JK470	E. CAPACITOR 6.3V 47U	1		C6020	ECUM1H103KBN	CHIP 50V 0.01U	1	
C3019	ECUM1H220JCN	CHIP 50V 22P	1		C6023	ECUM1H1032FN	CHIP 50V 0.01U	1	
C3050	ECEA1CK100	E. CAPACITOR 16V 10U	1		C6024-26	ECUM1H271KBN	CHIP 50V 270P	3	
C3051	ECEA1CK470	E. CAPACITOR 16V 47U	1		C6027	ECEA1HKR47	E. CAPACITOR 50V 0.47U	1	
C3053	ECEA0JK101	E. CAPACITOR 6.3V 100U	1		C6028	ECUM1H102KBN	CHIP 50V 1000P	1	
C3054	ECEA0JK470	E. CAPACITOR 6.3V 47U	1		C6029	ECUM1H1032FN	CHIP 50V 0.01U	1	
C3055	ECEA1CK330	E. CAPACITOR 16V 33U	1		C7551	ECQV1H104JZ	P. CAPACITOR 50V 0.1U	1	
C3056	ECEA1CK470	E. CAPACITOR 16V 47U	1		C7552	ECQV1H683JZ	P. CAPACITOR 50V 0.068U	1	
C3057	ECQB1H103JH	P. CAPACITOR 50V 0.01U	1		C7553	ECQV1H823JZ	P. CAPACITOR 50V 0.082U	1	
C3058	ECQB1H392JH	P. CAPACITOR 50V 3900P	1		C7554	ECQB1H273JH	P. CAPACITOR 50V 0.027U	1	
C3059	ECQB1H562JH	P. CAPACITOR 50V 5600P	1		C7555,56	ECUM1H1032FN	CHIP 50V 0.01U	2	
C3060	ECUM1H1032FN	CHIP 50V 0.01U	1		C7557	ECEA1HKA100	E. CAPACITOR 50V 10U	1	
C3061	ECQB1H272JH	P. CAPACITOR 50V 2700P	1		C7558	ECUM1H1032FN	CHIP 50V 0.01U	1	
C3062,63	ECEA1HK010	E. CAPACITOR 50V 1U	2		C7559	ECEA1CK100	E. CAPACITOR 16V 10U	1	
C3064	ECQB1H103JH	P. CAPACITOR 50V 0.01U	1		C7560-63	ECUM1H1032FN	CHIP 50V 0.01U	4	
C3067,68	ECUM1H1032FN	CHIP 50V 0.01U	2		C7564	ECEA1HK0N10	E. CAPACITOR 50V 1U	1	
C3070	ECUM1H1032FN	CHIP 50V 0.01U	1		C7565	ECUM1H1032FN	CHIP 50V 0.01U	1	
C3072	ECKF1H101KB	C. CAPACITOR 50V 100P	1		C7569	ECEA1HK0N10	E. CAPACITOR 50V 1U	1	
C3073	ECCF1H390JC	C. CAPACITOR 50V 39P	1		C7571	EECS5R5V473	E. CAPACITOR 5.5V 0.047	1	
C3075	ECQV1H104JZ	P. CAPACITOR 50V 0.1U	1		C7590	ECEA0JU221	E. CAPACITOR 6.3V 220U	1	
C3077	ECQV1H104JZ	P. CAPACITOR 50V 0.1U	1		C7591	ECUM1H102KBN	CHIP 50V 1000P	1	
C3801,02	ECEA1CK220	E. CAPACITOR 16V 22U	2		C7592	ECUM1H560JCN	CHIP 50V 56P	1	

To guarantee the FUNCTION,SAFETY and RELIABILITY of repaired units,only use ORIGINAL REPLACEMENT PARTS which are listed with their part numbers in this parts list section.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C7593, 94	ECQV1H104J2	P. CAPACITOR 50V 0.1U	2		IC2103,04	AN6562	IC	2	
C7801	ECEA1CK220	E. CAPACITOR 16V 22U	1		IC2105	UPD4069UBC	IC	1	
C7802	ECQB1H223JH	P. CAPACITOR 50V 0.022U	1		IC2501	BA6432S	IC	1	
C7803	ECQV1H683J2	P. CAPACITOR 50V 0.068U	1		IC2801	BA6305	IC	1	
C7804	ECEA1HKR47	E. CAPACITOR 50V 0.47U	1		IC2802	MC14013BCP	IC	1	
C7805	ECCF1H150JC	C. CAPACITOR 50V 15P	1		IC2803	LM393P	IC	1	
C7806	ECQB1H102JH	P. CAPACITOR 50V 1000P	1		IC3001	BA7004	IC	1	
C7807	ECKF1H471KB	C. CAPACITOR 50V 470P	1		IC3002	AN5421N	IC	1	
C7808	ECQB1H223JH	P. CAPACITOR 50V 0.022U	1		IC3801	M5202AP	IC	1	
C7809	ECKF1H271KB	C. CAPACITOR 50V 270P	1		IC3802	AN6552	IC	1	
C7810	ECCF1H101JC	C. CAPACITOR 50V 100P	1		IC4001	BA7766S	IC	1	
C7811	ECCF1H180JC	C. CAPACITOR 50V 18P	1		IC6001	MN15362VPD	IC	1	
C7812	ECCF1H820JC	C. CAPACITOR 50V 82P	1		IC6002	AN6914	IC	1	
C7814	ECKF1H102KB	C. CAPACITOR 50V 1000P	1		IC6003	MN4510B	IC	1	
C7815	VCYD1C104MR1	S. CAPACITOR 16V 0.1U	1		IC6004	MN12821	IC	1	(R)
C7816	ECEA1EK4R7	E. CAPACITOR 25V 4.7U	1		IC7551	AN5043	IC	1	
C7818	ECEA1CKN100	E. CAPACITOR 16V 10U	1		IC7552	AN6913	IC	1	
C7819, 20	ECCF1H101JC	C. CAPACITOR 50V 100P	2		IC7553	MN4066B	IC	1	
C7821	ECQB1H272JH	P. CAPACITOR 50V 2700P	1		IC7801	SAA5235	IC	1	
C7851	ECQV1H104J2	P. CAPACITOR 50V 0.1U	1		IC7802	SAF1135P	IC	1	
C7852	ECEA1AK101	E. CAPACITOR 10V 100U	1		IC7851	MN158412VNL	IC	1	
C7853, 54	ECCF1H330JC	C. CAPACITOR 50V 33P	2		IC7852	MN1280	IC	1	
C7855, 56	ECEA1HK010	E. CAPACITOR 50V 1U	2						
C7860	ECEA0JK101	E. CAPACITOR 6.3V 100U	1						
							COILS		
					L301	VLQEL05F101K	COIL 100UH	1	
					L302	VLQEL05F220K	COIL 22UH	1	
					L303,04	VLQEL05F101K	COIL 100UH	2	
					L306	VLQEL05F101K	COIL 100UH	1	
					L307	VLQEL05F151K	COIL 150UH	1	
					L308	VLQEL05F270K	COIL 27UH	1	
					L309,10	VLQEL05F101K	COIL 100UH	2	
					L311	VLQEL05F2R2K	COIL 2.2UH	1	
					L701,02	ELESP680KA	COIL 68UH	2	
					L703,04	VLQEL05F221K	COIL 220UH	2	
					L712	VLQ0305J1R2	COIL 1.2UH	1	
					L714	VLQ0305J1R2	COIL 1.2UH	1	
					L715	VLQ0213K680	COIL 68UH	1	
					L716	VLQEL05F560K	COIL 56UH	1	
					L717,18	ELESP680KA	COIL 68UH	2	
					L719	ELESP120KA	COIL 12UH	1	
					L781	ELESP680KA	COIL 68UH	1	
					L804	VLQEL05F150K	COIL 15UH	1	
					L805	VLQEL05F101K	COIL 100UH	1	
					L806	VLQEL05F681K	COIL 680UH	1	
					L808	VLQEL05F470K	COIL 47UH	1	
					L809	VLQEL05F331K	COIL 330UH	1	
					L810	VLQEL05F101K	COIL 100UH	1	
					L811	VLQEL05F470K	COIL 47UH	1	
					L812	VLQEL05F681K	COIL 680UH	1	
					L851	VLQEL05F101K	COIL 100UH	1	
					L2501	VLQEL05F102K	COIL 1000UH	1	
					L2502	VLQ0128	COIL 47UH	1	
					L3001-03	VLQEL05F101K	COIL 100UH	3	
					L3005	VLQEL05F120K	COIL 12UH	1	
					L3006	VLQEL05F5R6K	COIL 5.6UH	1	
					L3007	VLQEL05F101K	COIL 100UH	1	
					L3008	VLQEL05F3R3K	COIL 3.3UH	1	
					L3012	VLQEL05F101K	COIL 100UH	1	
					L3013	VLQEL05F390K	COIL 39UH	1	
					L3014	VLQEL05F470K	COIL 47UH	1	
					L3801	VLQEL05F101K	COIL 100UH	1	
					L3802	VLQEL05F1R0K	COIL 1UH	1	
					L3803	VLQEL06F471K	COIL 470UH	1	
					L3804	VLQEL05F2R7K	COIL 2.7UH	1	
					L3805,06	VLQEL05F1R0K	COIL 1UH	2	
					L4001	VLQEL07F822J	COIL 8200UH	1	
					L4002	VLQEL05F471K	COIL 470UH	1	
					L7551	VLQEL05F680K	COIL 68UH	1	
					L7801	VLQ0193	COIL	1	
					L7802,03	VLQEL05F101K	COIL 100UH	2	
							CONNECTORS		
					P006	VJS1902	CONNECTOR (FEMALE)	1	

To guarantee the FUNCTION,SAFETY and RELIABILITY of repaired units,only use ORIGINAL REPLACEMENT PARTS which are listed with their part numbers in this parts list section.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
P501	VJF0171T	CONNECTOR	1		QR2101,02	UN2113	TRANSISTOR-RESISTOR	2	
P1001	VJS1931T	CONNECTOR (FEMALE)	1		QR2103	UN2212	TRANSISTOR-RESISTOR	1	
P1101	VJP1931T	CONNECTOR (MALE)	1		QR2104	UN2110	TRANSISTOR-RESISTOR	1	
P2001	VJP1232T	CONNECTOR (MALE) 5P	1		QR2105	UN2117	TRANSISTOR-RESISTOR	1	
P2002	VJP1932T	CONNECTOR (MALE)	1		QR2106	UN2115	TRANSISTOR-RESISTOR	1	
P2801	VJP1244T	CONNECTOR (MALE) 4P	1		QR2107	UN2110	TRANSISTOR-RESISTOR	1	
P2901	VJS1232T	CONNECTOR (FEMALE)	1		QR2801,02	UN2213	TRANSISTOR-RESISTOR	2	
P3001	VJP1393T	CONNECTOR (MALE) 13P	1		QR2804	UN2211	TRANSISTOR-RESISTOR	1	
P3002	VJP1237T	CONNECTOR (MALE) 10P	1		QR3004	UN2111	TRANSISTOR-RESISTOR	1	
P4001	VJP1233T	CONNECTOR (MALE) 6P	1		QR3011	UN2212	TRANSISTOR-RESISTOR	1	
P6001	VJS2157W	CONNECTOR (FEMALE)	1		QR4006	UN1112	TRANSISTOR-RESISTOR	1	
P6002	VJS2149W	CONNECTOR (FEMALE)	1		QR4007	UN2211	TRANSISTOR-RESISTOR	1	
P6003	VJP1236T	CONNECTOR (MALE) 9P	1		QR6001	UN2212	TRANSISTOR-RESISTOR	1	
P6004	VJP1231T	CONNECTOR (MALE) 4P	1		QR6006	UN2111	TRANSISTOR-RESISTOR	1	
P6005	VJP1231T	CONNECTOR (MALE) 4P	1		QR6008	UN2119	TRANSISTOR-RESISTOR	1	
P6202	VJS1236T	CONNECTOR (FEMALE)	1		QR6011	UN2212	TRANSISTOR-RESISTOR	1	
P7401	VJS1475	CONNECTOR (FEMALE)	1		QR6012	UN2113	TRANSISTOR-RESISTOR	1	
P7402	VJS2157W	CONNECTOR (FEMALE)	1		QR7551-54	UN2213	TRANSISTOR-RESISTOR	4	
P9501	VJS1237T	CONNECTOR	1		QR7561	UN2211	TRANSISTOR-RESISTOR	1	
P9502	VJS1231T	CONNECTOR (FEMALE)	1		QR7851	UN1211	TRANSISTOR-RESISTOR	1	
					QR7852	UN1213	TRANSISTOR-RESISTOR	1	
		TRANSISTORS					RESISTORS		
Q301	2SB709	TRANSISTOR CHIP	1		R301	ERJ6QMYJ122	CHIP 1/16W 1.2K	1	
Q302,03	2SC2295	TRANSISTOR CHIP	2 (B,C)		R302	ERJ6QMYJ391	CHIP 1/16W 390	1	
Q304	2SD601	TRANSISTOR CHIP	1 (Q,R,S)		R303	ERJ6QMYJ103	CHIP 1/16W 10K	1	
Q703	2SD601	TRANSISTOR	1 (S,T)		R304	ERJ6QMYJ102	CHIP 1/16W 1K	1	
Q710	2SC2377	TRANSISTOR	1 (C,D)		R305	ERJ6QMYJ824	CHIP 1/16W 820K	1	
Q712	2SD638	TRANSISTOR	1		R306	ERJ6QMYJ152	CHIP 1/16W 1.5K	1	
Q713	2SD1328	TRANSISTOR	1		R307	ERJ6QMYJ102	CHIP 1/16W 1K	1	
Q714	2SD601	TRANSISTOR CHIP	1		R308	ERJ6QMYJ123	CHIP 1/16W 12K	1	
Q771	2SD601	TRANSISTOR CHIP	1		R309	ERJ6QMYJ272	CHIP 1/16W 2.7K	1	
Q772,73	2SK198	TRANSISTOR CHIP	2		R310	ERJ6QMYJ103	CHIP 1/16W 10K	1	
Q804	2SB709	TRANSISTOR CHIP	1		R311	ERJ6QMYJ272	CHIP 1/16W 2.7K	1	
Q2001	2SB709	TRANSISTOR CHIP	1		R312	ERJ6QMYJ222	CHIP 1/16W 2.2K	1	
Q2002-04	2SD601	TRANSISTOR CHIP	3		R316	ERJ6QMYJ104	CHIP 1/16W 100K	1	
Q2006	2SD1330	TRANSISTOR	1 (S,T)		R317	ERJ6QMYJ471	CHIP 1/16W 470	1	
Q2108	2SD601	TRANSISTOR CHIP	1		R325	ERJ6QMYJ151	CHIP 1/16W 150	1	
Q2111,12	2SD601	TRANSISTOR CHIP	2		R326	ERJ6QMYJ822	CHIP 1/16W 8.2K	1	
Q2801	2SD601	TRANSISTOR CHIP	1		R327	ERJ6QMYJ332	CHIP 1/16W 3.3K	1	
Q2802	2SB709	TRANSISTOR CHIP	1		R328	ERJ6QMYJ272	CHIP 1/16W 2.7K	1	
Q2803-06	2SD601	TRANSISTOR CHIP	4		R329	ERJ6QMYJ103	CHIP 1/16W 10K	1	
Q3002	2SC2295	TRANSISTOR	1		R330	ERJ6QMYJ183	CHIP 1/16W 18K	1	
Q3005	2SD601	TRANSISTOR CHIP	1		R331	ERJ6QMYJ102	CHIP 1/16W 1K	1	
Q3006	2SC2295	TRANSISTOR	1		R332	ERJ6QMYJ222	CHIP 1/16W 2.2K	1	
Q3007	2SB641	TRANSISTOR	1		R334,35	ERJ6QMYJ102	CHIP 1/16W 1K	2	
Q3011	2SB709	TRANSISTOR CHIP	1		R338	ERJ6QMYJ474	M.RESISTOR CHI/16W 470K	1	
Q3013	2SD601	TRANSISTOR CHIP	1		R339	ERJ6QMYJ101	CHIP 1/16W 100	1	
Q3014	2SA564	TRANSISTOR	1 (P,Q,R)		R707	ERJ6GEYJ223	CHIP 1/16W 22K	1	
Q3801,02	2SB641	TRANSISTOR	2 (Q,R,S)		R712	ERJ6GEYJ682	CHIP 1/16W 6.8K	1	
Q3803	2SD636	TRANSISTOR	1		R713	ERJ6GEYJ681	CHIP 1/16W 680	1	
Q4001	2SD602	TRANSISTOR	1 (R)		R714	ERD2FCG330	C.RESISTOR 2W 33	1	<1>
Q6007	2SB643	TRANSISTOR	1		R715	ERJ6GEYJ561	CHIP 1/16W 560	1	
Q6009	2SB643	TRANSISTOR	1 (R,S)		R716	ERJ6GEYJ152	CHIP 1/16W 1.5K	1	
Q6016	2SD1275	TRANSISTOR	1 (P,Q)		R717	ERJ6GEYJ332	CHIP 1/16W 3.3K	1	
Q6017	2SD893	TRANSISTOR	1		R718	ERJ6GEYJ754	CHIP 1/16W 750K	1	
Q6018	2SD973	TRANSISTOR	1 (S)		R719	ERJ6GEYJ682	CHIP 1/16W 6.8K	1	
Q6019	2SD638	TRANSISTOR	1		R720	ERJ6GEYJ822	CHIP 1/16W 8.2K	1	
Q6020	2SD973	TRANSISTOR	1 (S)		R721	ERJ6GEYJ332	CHIP 1/16W 3.3K	1	
Q7801	2SD636	TRANSISTOR	1 (Q,R,S)		R722	ERJ6GEYJ392	CHIP 1/16W 3.9K	1	
Q7802,03	2SB641	TRANSISTOR	2 (Q,R,S)		R723	ERJ6GEYJ183	CHIP 1/16W 180K	1	
					R724	ERJ6GEYJ101	CHIP 1/16W 100	1	
					R725	ERJ6GEYJ182	CHIP 1/16W 1.8K	1	
					R726	ERJ6GEYJ472	CHIP 1/16W 4.7K	1	
					R727	ERJ6GEYJ471	CHIP 1/16W 470	1	
QR701	FA114M	TRANSISTOR-RESISTOR	1		R728	VRE0040E471T	V.RESISTOR 470	1	
QR702	FA114M	TRANSISTOR-RESISTOR	1		R729,30	ERJ6GEYJ331	CHIP 1/16W 330	2	
QR711,12	FA1F4M	TRANSISTOR-RESISTOR	2		R737	ERJ6GEYJ274	CHIP 1/16W 270K	1	
QR713	FA1A4M	TRANSISTOR-RESISTOR	1		R738	ERJ6GEYJ334	CHIP 1/16W 330K	1	
QR714	FA1A4M	TRANSISTOR-RESISTOR	1		R739	ERJ6GEYJ681	CHIP 1/16W 680	1	
QR853	UN1213	TRANSISTOR-RESISTOR	1		R740	ERJ6GEYJ473	CHIP 1/16W 47K	1	
QR1101	UN2213	TRANSISTOR-RESISTOR	1		R741,42	ERJ6GEYJ272	CHIP 1/16W 2.7K	2	
QR2002	UN2212	TRANSISTOR-RESISTOR	1		R743	ERJ6GEYJ470	CHIP 1/16W 47	1	
QR2007	UN2213	TRANSISTOR-RESISTOR	1						

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R744	ERJ6GEYJ821	CHIP 1/16W 820	1	
R745	ERJ6GEYJ331	CHIP 1/16W 330	1	
R746	VR00040E181T		1	
R747	ERJ6GEYJ471	CHIP 1/16W 470	1	
R750	ERJ6GEYJ182	CHIP 1/16W 1.8K	1	
R757	ERJ6GEYJ222	CHIP 1/16W 2.2K	1	
R759	ERJ6GEYJ103	CHIP 1/16W 10K	1	
R760	ERJ6GEYJ102	CHIP 1/16W 1K	1	
R763	ERJ6GEYJ103	CHIP 1/16W 10K	1	
R764	ERJ6GEYJ822	CHIP 1/16W 8.2K	1	
R772	ERJ6GEYJ102	CHIP 1/16W 1K	1	
R773	ERJ6GEYJ103	CHIP 1/16W 10K	1	
R774	ERJ6GEYJ333	CHIP 1/16W 33K	1	
R775	ERJ6GEYJ474	CHIP 1/16W 470K	1	
R776	ERJ6GEYJ105	CHIP 1/16W 1M	1	
R777	ERJ6GEYJ184	CHIP 1/16W 180K	1	
R778	ERJ6GEYJ105	CHIP 1/16W 1M	1	
R779	ERJ6GEYJ104	CHIP 1/16W 100K	1	
R781	ERJ6GEYJ271	CHIP 1/16W 270	1	
R782	ERJ6GEYJ821	CHIP 1/16W 820	1	
R792	ERJ6GEYJ120	CHIP 1/16W 12	1	
R815	ERJ6GMVJ103	CHIP 1/16W 10K	1	
R816	ERJ6GMVJ822	CHIP 1/16W 8.2K	1	
R818	ERJ6GMVJ102	CHIP 1/16W 1K	1	
R819	ERJ6GMVJ182	CHIP 1/16W 1.8K	1	
R820	ERJ6GMVJ222	CHIP 1/16W 2.2K	1	
R821, 22	ERJ6GMVJ103	CHIP 1/16W 10K	2	
R823	ERJ6GMVJ271	CHIP 1/16W 270	1	
R824	ERJ6GMVJ102	CHIP 1/16W 1K	1	
R825	ERJ6GMVJ182	CHIP 1/16W 1.8K	1	
R826	ERJ6GMVJ681	CHIP 1/16W 680	1	
R851	ERDS2TJ 223	C.RESISTOR 1/4W 22K	1	
R852	ERDS2TJ 390	C.RESISTOR 1/4W 39	1	
R853	ERDS2TJ 154	C.RESISTOR 1/4W 150K	1	
R854	ERDS2TJ 222	C.RESISTOR 1/4W 2.2K	1	
R855	ERDS2TJ 102	C.RESISTOR 1/4W 1K	1	
R856	ERDS2TJ 103	C.RESISTOR 1/4W 10K	1	
R858	ERDS2TJ 561	C.RESISTOR 1/4W 560	1	
R1101	ERJ6GMVJ561	CHIP 1/16W 560	1	
R2007	ERJ6GMVJ472	CHIP 1/16W 4.7K	1	
R2008	ERJ6GMVJ682	CHIP 1/16W 6.8K	1	
R2009	ERJ6GMVJ472	CHIP 1/16W 4.7K	1	
R2010	ERJ6GMVJ223	CHIP 1/16W 22K	1	
R2011	ERJ6GMVJ561	CHIP 1/16W 560	1	
R2029	ERJ6GMVJ683	CHIP 1/16W 68K	1	
R2030	ERJ6GMVJ333	CHIP 1/16W 33K	1	
R2031	ERJ6GMVJ473	CHIP 1/16W 47K	1	
R2032	ERJ6GMVJ124	CHIP 1/16W 120K	1	
R2033	ERJ6GMVJ683	CHIP 1/16W 68K	1	
R2034	ERJ6GMVJ391	CHIP 1/16W 390	1	
R2037	ERJ6GMVJ103	CHIP 1/16W 10K	1	
R2038	ERJ6GMVJ104	CHIP 1/16W 100K	1	
R2046	ERJ6GMVJ153	CHIP 1/16W 15K	1	
R2047, 48	ERJ6GMVJ154	CHIP 1/16W 150K	2	
R2049	ERJ6GMVJ273	CHIP 1/16W 27K	1	
R2050	ERJ6GMVJ102	CHIP 1/16W 1K	1	
R2051	ERJ6GMVJ222	CHIP 1/16W 2.2K	1	
R2054	ERJ6GMYOR00	CHIP 1/16W 0	1	
R2056	ERDS2TJ 471	C.RESISTOR 1/4W 470	1	
R2106	ERJ6GMVJ392	CHIP 1/16W 3.9K	1	
R2108	ERJ6GMVJ222	CHIP 1/16W 2.2K	1	
R2109	ERJ6GMVJ682	CHIP 1/16W 6.8K	1	
R2110	ERJ6GMVJ274	CHIP 1/16W 270K	1	
R2111	ERJ6GMVJ563	CHIP 1/16W 56K	1	
R2112, 13	ERJ6GMVJ154	CHIP 1/16W 150K	2	
R2114	ERJ6GMVJ224	CHIP 1/16W 220K	1	
R2115	ERJ6GMVJ272	CHIP 1/16W 2.7K	1	
R2117	ERJ6GMVJ683	CHIP 1/16W 68K	1	
R2119	ERJ6GMVJ333	CHIP 1/16W 33K	1	
R2120	ERJ6GMVJ274	CHIP 1/16W 270K	1	
R2121	ERJ6GMYOR00	CHIP 1/16W 0	1	
R2122, 23	ERJ6GMVJ332	CHIP 1/16W 3.3K	2	
R2124	ERJ6GMVJ561	CHIP 1/16W 560	1	
R2125	ERJ6GMVJ222	CHIP 1/16W 2.2K	1	
R2131	ERJ6GMVJ152	CHIP 1/16W 1.5K	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R2132,33	ERJ6QMYJ563	CHIP 1/16W 56K	2	
R2134	ERJ6QMYJ472	CHIP 1/16W 4.7K	1	
R2135	ERJ6QMYJ333	CHIP 1/16W 33K	1	
R2136, 37	ERJ6QMYJ154	CHIP 1/16W 150K	2	
R2138	ERJ6QMYJ124	CHIP 1/16W 120K	1	
R2139	ERJ6QMYJ392	CHIP 1/16W 3.9K	1	
R2140	ERJ6QMYG333	CHIP 1/16W 33K	1	
R2141	ERJ6QMYJ684	CHIP 1/16W 680K	1	
R2142	ERJ6QMYJ154	CHIP 1/16W 150K	1	
R2143	ERJ6QMYJ683	CHIP 1/16W 68K	1	
R2144, 45	ERJ6QMYJ223	CHIP 1/16W 22K	2	
R2146	ERJ6QMYJ103	CHIP 1/16W 10K	1	
R2147	ERJ6QMYJ392	CHIP 1/16W 3.9K	1	
R2148	ERJ6QMYJ223	CHIP 1/16W 22K	1	
R2149	ERJ6QMYG472	M.RESISTOR CH1/16W 4.7K	1	
R2150	ERJ6QMYJ821	CHIP 1/16W 820	1	
R2151	ERJ6QMYJ824	CHIP 1/16W 820K	1	
R2153	ERJ6QMYJ684	CHIP 1/16W 680K	1	
R2156	ERJ6QMYJ123	CHIP 1/16W 12K	1	
R2157	ERJ6QMYJ562	CHIP 1/16W 5.6K	1	
R2158	ERJ6QMYJ683	CHIP 1/16W 68K	1	
R2159, 60	ERJ6QMYJ223	CHIP 1/16W 22K	2	
R2161	ERJ6QMYJ183	CHIP 1/16W 18K	1	
R2166, 67	ERJ6QMYJ563	CHIP 1/16W 56K	2	
R2168, 69	ERJ6QMYJ562	CHIP 1/16W 5.6K	2	
R2174	ERJ6QMYJ103	CHIP 1/16W 10K	1	
R2175	ERJ6QMYJ334	CHIP 1/16W 330K	1	
R2177	ERJ6QMYJ681	CHIP 1/16W 680	1	
R2178	ERJ6QMYJ104	CHIP 1/16W 100K	1	
R2179	ERJ6QMYJ683	CHIP 1/16W 68K	1	
R2181	ERJ6QMYJ472	CHIP 1/16W 4.7K	1	
R2182	ERJ6QMYJ473	CHIP 1/16W 47K	1	
R2183	ERJ6QMYJ103	CHIP 1/16W 10K	1	
R2184	ERJ6QMYJ102	CHIP 1/16W 1K	1	
R2185	ERJ6QMYJ223	CHIP 1/16W 22K	1	
R2186, 87	ERJ6QMYJ222	CHIP 1/16W 2.2K	2	
R2188	ERJ6QMYJ223	CHIP 1/16W 22K	1	
R2189	ERJ6QMYJ222	CHIP 1/16W 2.2K	1	
R2190	ERJ6QMYJ821	CHIP 1/16W 820	1	
R2191	ERJ6QMYJ105	CHIP 1/16W 1M	1	
R2192	ERJ6QMYJ472	CHIP 1/16W 4.7K	1	
R2501-03	ERDS2TJ330	C.RESISTOR 1/4W 33	3	
R2504	ERDS1TJ1R0	C.RESISTOR 1/2W 1.0	1	
R2505	ERJ6QMYJ102	CHIP 1/16W 1K	1	
R2506	ERJ6QMYG512	CHIP 1/16W 5.1K	1	
R2518	ERJ6QMYJ330	CHIP 1/16W 33	1	
R2801, 02	ERJ6QMYJ103	CHIP 1/16W 10K	2	
R2803	ERJ6QMYJ561	CHIP 1/16W 560	1	
R2804	ERJ6QMYJ393	CHIP 1/16W 39K	1	
R2805	ERJ6QMYJ332	CHIP 1/16W 3.3K	1	
R2806	ERJ6QMYJ221	CHIP 1/16W 220	1	
R2807	ERJ6QMYJ823	M.RESISTOR CH1/16W 82K	1	
R2808	ERJ6QMYJ103	CHIP 1/16W 10K	1	
R2809	ERJ6QMYJ750	CHIP 1/16W 75	1	
R2810	ERJ6QMYJ124	CHIP 1/16W 120K	1	
R2811	ERJ6QMYG113	M.RESISTOR CH1/16W 11K	1	
R2812	ERJ6QMYJ153	CHIP 1/16W 15K	1	
R2813	ERJ6QMYJ221	CHIP 1/16W 220	1	
R2814	ERJ6QMYJ102	CHIP 1/16W 1K	1	
R2815, 16	ERJ6QMYJ473	CHIP 1/16W 47K	2	
R2817	ERJ6QMYJ223	CHIP 1/16W 22K	1	
R2818	ERJ6QMYJ102	CHIP 1/16W 1K	1	
R2819	ERJ6QMYJ124	CHIP 1/16W 120K	1	
R2820	ERJ6QMYJ221	CHIP 1/16W 220	1	
R2821	ERJ6QMYJ103	CHIP 1/16W 10K	1	
R2822	ERJ6QMYJ124	CHIP 1/16W 120K	1	
R2823	ERJ6QMYJ473	CHIP 1/16W 47K	1	
R2824	ERJ6QMYJ103	CHIP 1/16W 10K	1	
R2825	ERJ6QMYJ473	CHIP 1/16W 47K	1	
R2831	ERJ6QMYJ272	CHIP 1/16W 2.7K	1	
R2832	ERJ6QMYJ822	CHIP 1/16W 8.2K	1	
R2833	ERJ6QMYJ103	CHIP 1/16W 10K	1	
R3001, 02	ERJ6QMYJ103	CHIP 1/16W 10K	2	
R3006	ERJ6QMYJ473	CHIP 1/16W 47K	1	
R3009	ERJ6QMYJ152	CHIP 1/16W 1.5K	1	

To guarantee the FUNCTION, SAFETY and RELIABILITY of repaired units, only use ORIGINAL REPLACEMENT PARTS which are listed with their part numbers in this parts list section.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R3010	ERJ6GMYJ392	CHIP 1/16W 3.9K	1	
R3011	ERJ6GMYJ102	CHIP 1/16W 1K	1	
R3022, 23	ERJ6GMYJ821	CHIP 1/16W 820	2	
R3028	ERJ6GMYJ102	CHIP 1/16W 1K	1	
R3029	ERJ6GMYJ272	CHIP 1/16W 2.7K	1	
R3030	ERJ6GMYJ750	CHIP 1/16W 75	1	
R3032	ERJ6GMYJ104	CHIP 1/16W 100K	1	
R3033	ERJ6GMYJ183	CHIP 1/16W 18K	1	
R3042	ERJ6GMYJ102	CHIP 1/16W 1K	1	
R3054	ERJ6GMYOR00	CHIP 1/16W 0	1	
R3055	ERJ6GMYJ101	CHIP 1/16W 100	1	
R3056	ERJ6GMYJ152	CHIP 1/16W 1.5K	1	
R3062	ERJ6GMYJ223	CHIP 1/16W 22K	1	
R3063	ERJ6GMYJ332	CHIP 1/16W 3.3K	1	
R3064	ERJ6GMYJ152	CHIP 1/16W 1.5K	1	
R3065	ERJ6GMYJ561	CHIP 1/16W 560	1	
R3066	ERJ6GMYJ222	CHIP 1/16W 2.2K	1	
R3067	ERJ6GMYJ472	CHIP 1/16W 4.7K	1	
R3068	ERJ6GMYJ562	CHIP 1/16W 5.6K	1	
R3069	ERJ6GMYJ151	CHIP 1/16W 150	1	
R3070	ERJ6GMYJ562	CHIP 1/16W 5.6K	1	
R3071	ERJ6GMYJ104	CHIP 1/16W 100K	1	
R3072	ERJ6GMYJ393	CHIP 1/16W 39K	1	
R3073	ERJ6GMYJ222	CHIP 1/16W 2.2K	1	
R3074	ERJ6GMYJ822	CHIP 1/16W 8.2K	1	
R3075	ERJ6GMYJ332	CHIP 1/16W 3.3K	1	
R3076	ERJ6GMYJ393	CHIP 1/16W 39K	1	
R3077	ERJ6GMYJ122	CHIP 1/16W 1.2K	1	
R3081	ERJ6GMYJ273	CHIP 1/16W 27K	1	
R3084	ERJ6GMYJ222	CHIP 1/16W 2.2K	1	
R3085	ERJ6GMYJ221	CHIP 1/16W 220	1	
R3087, 88	ERJ6GMYJ222	CHIP 1/16W 2.2K	2	
R3801, 02	ERDS2TJ124	C.RESISTOR 1/4W 120K	2	
R3803	ERDS2TJ223	C.RESISTOR 1/4W 22K	1	
R3804	ERDS2TJ222	C.RESISTOR 1/4W 2.2K	1	
R3805	ERGLANJ820	M.RESISTOR 1W 82	1	
R3806	ERDS2TJ103	C.RESISTOR 1/4W 10K	1	
R3807	ERDS2TJ473	C.RESISTOR 1/4W 47K	1	
R3808	ERDS2TJ753	C.RESISTOR 1/4W 75K	1	
R3809	ERDS2TJ183	C.RESISTOR 1/4W 18K	1	
R3810, 11	ERDS2TJ474	C.RESISTOR 1/4W 470K	2	
R3812	ERDS2TJ102	C.RESISTOR 1/4W 1K	1	
R3813	ERDS2TJ471	C.RESISTOR 1/4W 470	1	
R3814-16	ERDS2TJ750	C.RESISTOR 1/4W 75	3	
R3817	ERDS2TJ333	C.RESISTOR 1/4W 33K	1	
R3818	ERDS2TJ183	C.RESISTOR 1/4W 18K	1	
R3819	ERDS2TJ750	C.RESISTOR 1/4W 75	1	
R3820	ERDS2TJ101	C.RESISTOR 1/4W 100	1	
R3821, 22	ERDS2TJ242	C.RESISTOR 1/4W 2.4K	2	
R3824	ERDS2TJ471	C.RESISTOR 1/4W 470	1	
R3825	ERDS2TJ222	C.RESISTOR 1/4W 2.2K	1	
R3826	ERDS2TJ101	C.RESISTOR 1/4W 100	1	
R4001	ERJ6GMYJ183	CHIP 1/16W 18K	1	
R4002	ERJ6GMYJ100	CHIP 1/16W 10	1	
R4003	ERJ6GMYJ203	CHIP 1/16W 2K	1	
R4004	ERJ6GMYJ562	CHIP 1/16W 5.6K	1	
R4005	ERJ6GMYOR00	CHIP 1/16W 0	1	
R4006	ERJ6GMYJ151	CHIP 1/16W 150	1	
R4007	ERJ6GMYJ221	CHIP 1/16W 220	1	
R4008	ERJ6GMYJ122	CHIP 1/16W 1.2K	1	
R4009	ERJ6GMYJ104	CHIP 1/16W 100K	1	
R4010	ERJ6GMYJ683	CHIP 1/16W 68K	1	
R4012	ERJ6GMYJ331	CHIP 1/16W 330	1	
R4013	ERJ6GMYJ334	CHIP 1/16W 330K	1	
R4014	ERJ6GMYJ103	CHIP 1/16W 10K	1	
R4015	ERJ6GMYOR00	CHIP 1/16W 0	1	
R4016	ERJ6GMYJ105	CHIP 1/16W 1M	1	
R4017	ERJ6GMYJ272	CHIP 1/16W 2.7K	1	
R4018	ERJ6GMYJ223	CHIP 1/16W 22K	1	
R4019	ERJ6GMYJ562	CHIP 1/16W 5.6K	1	
R4020	ERJ6GMYJ563	CHIP 1/16W 56K	1	
R4021	ERJ6GMYJ562	CHIP 1/16W 5.6K	1	
R4022	ERJ6GMYJ104	CHIP 1/16W 100K	1	
R4023	ERJ6GMYG473	CHIP 1/16W 47K	1	
R4024, 25	ERJ6GMYG104	CHIP 1/16W 100K	2	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R4051	ERJ6GMYJ123	CHIP 1/16W 12K	1	
R4052	ERJ6GMYJ153	CHIP 1/16W 15K	1	
R4054	ERJ6GMYJ102	CHIP 1/16W 1K	1	
R4055	ERJ6GMYJ681	CHIP 1/16W 680	1	
R6001	ERDS1TJ470	C.RESISTOR 1/2W 47	1	
R6002	ERJ6GMYJ473	CHIP 1/16W 47K	1	
R6006	ERD2FCVG220	C.RESISTOR 2W 22	1	<1>
R6007	ERJ6GMYJ122	CHIP 1/16W 1.2K	1	
R6008	ERJ6GMYJ181	CHIP 1/16W 180	1	
R6009	ERJ6GMYJ561	CHIP 1/16W 560	1	
R6010	ERJ6GMYJ102	CHIP 1/16W 1K	1	
R6011	ERJ6GMYJ221	CHIP 1/16W 220	1	
R6014	ERJ6GMYJ392	CHIP 1/16W 3.9K	1	
R6017	ERJ6GMYJ223	CHIP 1/16W 22K	1	
R6023	ERJ6GMYJ683	CHIP 1/16W 68K	1	
R6024	ERJ6GMYJ223	CHIP 1/16W 22K	1	
R6027	ERJ6GMYJ223	CHIP 1/16W 22K	1	
R6028	ERJ6GMYJ184	CHIP 1/16W 180K	1	
R6029	ERJ6GMYJ561	CHIP 1/16W 560	1	
R6030, 31	ERJ6GMYJ153	CHIP 1/16W 15K	2	
R6032	ERJ6GMYJ332	CHIP 1/16W 3.3K	1	
R6033, 34	ERJ6GMYJ333	CHIP 1/16W 33K	2	
R6035-37	ERJ6GMYJ101	CHIP 1/16W 100	3	
R6038	ERJ6GMYJ272	CHIP 1/16W 2.7K	1	
R6041	ERJ6GMYJ391	CHIP 1/16W 390	1	
R6046	ERJ6GMYJ152	CHIP 1/16W 1.5K	1	
R6050	ERJ6GMYJ562	CHIP 1/16W 5.6K	1	
R6051	ERJ6GMYJ332	CHIP 1/16W 3.3K	1	
R6060	ERJ6GMYJ822	CHIP 1/16W 8.2K	1	
R6067	ERJ6GMYJ101	CHIP 1/16W 100	1	
R6068	ERDS1TJ332	C.RESISTOR 1/2W 3.3K	1	
R6069	ERJ6GMYJ103	CHIP 1/16W 10K	1	
R6070	ERJ6GMYJ471	CHIP 1/16W 470	1	
R6071	ERJ6GMYJ152	CHIP 1/16W 1.5K	1	
R6072	ERJ6GMYJ562	CHIP 1/16W 5.6K	1	
R6073	ERJ6GMYJ131	CHIP 1/16W 130	1	
R6074	ERJ6GMYJ221	CHIP 1/16W 220	1	
R6075	ERG3SJ220	M.RESISTOR 3W 22	1	
R6079	ERJ6GMYJ103	CHIP 1/16W 10K	1	
R6083	ERJ6GMYJ104	CHIP 1/16W 100K	1	
R6084, 85	ERJ6GMYJ561	CHIP 1/16W 560	2	
R6087-89	ERJ6GMYJ272	CHIP 1/16W 2.7K	3	
R6090	ERJ6GMYJ821	CHIP 1/16W 820	1	
R6091	ERJ6GMYJ103	CHIP 1/16W 10K	1	
R6093	ERDS2TJ562	C.RESISTOR 1/4W 5.6K	1	
R6095	ERDS2TJ222	C.RESISTOR 1/4W 2.2K	1	
R6096	ERJ6GMYJ681	CHIP 1/16W 680	1	
R6098	ERJ6GMYJ101	CHIP 1/16W 100	1	
R6099	ERJ6GMYJ201	CHIP 1/16W 200	1	
R7551, 52	ERJ6GMYJ473	CHIP 1/16W 47K	2	
R7553	ERJ6GMYJ104	CHIP 1/16W 100K	1	
R7554	ERJ6GMYJ124	CHIP 1/16W 120K	1	
R7555	ERJ6GMYJ103	CHIP 1/16W 10K	1	
R7556	ERGLSJ152	M.RESISTOR 1W 1.5K	1	
R7557	ERJ6GMYJ103	CHIP 1/16W 10K	1	
R7558	ERJ6GMYJ332	CHIP 1/16W 3.3K	1	
R7561, 62	ERJ6GMYJ473	CHIP 1/16W 47K	2	
R7563	ERJ6GMYJ563	CHIP 1/16W 56K	1	
R7564	ERJ6GMYJ393	CHIP 1/16W 39K	1	
R7565	ERJ6GMYJ103	CHIP 1/16W 10K	1	
R7566	ERJ6GMYJ562	CHIP 1/16W 5.6K	1	
R7567	ERJ6GMYJ682	CHIP 1/16W 6.8K	1	
R7568	ERJ6GMYJ332	CHIP 1/16W 3.3K	1	
R7577	ERDS2TJ100	C.RESISTOR 1/4W 10	1	
R7578	ERJ6GMYJ223	CHIP 1/16W 22K	1	
R7583	ERJ6GMYJ103	CHIP 1/16W 10K	1	
R7595	ERJ6GMYJ181	CHIP 1/16W 180	1	
R7597	ERJ6GMYJ102	CHIP 1/16W 1K	1	
R7803, 04	ERDS2TJ103	C.RESISTOR 1/4W 10K	2	
R7809	ERDS2TJ683	C.RESISTOR 1/4W 68K	1	
R7810	ERDS2TJ223	C.RESISTOR 1/4W 22K	1	
R7811	ERDS2TJ332	C.RESISTOR 1/4W 3.3K	1	
R7812	ERDS2TJ152	C.RESISTOR 1/4W 1.5K	1	
R7813-15	ERDS2TJ102	C.RESISTOR 1/4W 1K	3	
R7816	ERDS2TJ472	C.RESISTOR 1/4W 4.7K	1	

To guarantee the FUNCTION, SAFETY and RELIABILITY of repaired units, only use ORIGINAL REPLACEMENT PARTS which are listed with their part numbers in this parts list section.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R7817	ERDS2TJ103	C.RESISTOR 1/4W 10K	1		C304	ECEA0J0331	E.CAPACITOR 6.3V 330U	1	
R7818	ERDS2TJ221	C.RESISTOR 1/4W 220	1		C305	ECEA1CK100	E.CAPACITOR 16V 10U	1	
R7851	ERDS2TJ103	C.RESISTOR 1/4W 10K	1		C306	ECEA1EK4R7	E.CAPACITOR 25V 4.7U	1	
R7860	ERDS2TJ471	C.RESISTOR 1/4W 470	1		C307	ECUM1H470JCN	CHIP 50V 47P	1	
					C308	ECUM1H220JCN	CHIP 50V 22P	1	
		SWITCH			C310	ECEA1CK100	E.CAPACITOR 16V 10U	1	
SW3801	VSS0226	SWITCH	1		C311,12	ECUM1H180JCN	CHIP 50V 18P	2	
					C313	ECEA1CK100	E.CAPACITOR 16V 10U	1	
					C314	ECUM1H121JCN	CHIP 50V 120P	1	
		TRANSFORMERS			C315	ECUM1H560JCN	CHIP 50V 56P	1	
T703	EIV5ECO13A	TRANSFORMER	1		C317	ECEA1AK470	E.CAPACITOR 10V 47U	1	
T704	EIV5ECO06A	TRANSFORMER	1		C319	ECUM1H471KBN	CHIP 50V 470P	1	
T710	EULBEFO22	TRANSFORMER	1		C320	ECUM1H270JCN	CHIP 50V 27P	1	
T711	EIS5ECO04A	TRANSFORMER	1		C321	ECEA1HK010	E.CAPACITOR 50V 1U	1	
T851	ELM7Q207A	TRANSFORMER	1		C322	ECEA1HK2R2	E.CAPACITOR 50V 2.2U	1	
T4001	EIQ7QF014Q	TRANSFORMER	1		C324	ECEA1CK100	E.CAPACITOR 16V 10U	1	
					C325,26	ECUM1H1032FN	CHIP 50V 0.01U	2	
					C327,28	ECEA1CK100	E.CAPACITOR 16V 10U	2	
					C329	ECUM1H1032FN	CHIP 50V 0.01U	1	
					C331	ECUM1H1032FN	CHIP 50V 0.01U	1	
		VARIABLE RESISTORS			C332	ECQV1H334JZ	P.CAPACITOR 50V 0.33U	1	
VR302	EVN3ACA00B14	V.RESISTOR 10K	1		C333	ECEA1HK4R7	E.CAPACITOR 50V 4.7U	1	
VR701,02	EVN4LGA00B23	V.RESISTOR 2K	2		C334	ECUM1H1032FN	CHIP 50V 0.01U	1	
VR741	EVNDRAA00B14	V.RESISTOR 10K	1		C335	ECUM1H680JCN	CHIP 50V 68P	1	
VR751	EVNDRAA00B53	V.RESISTOR 5K	1		C336	ECUM1H101JCN	CHIP 50V 100P	1	
VR803	EVNDRAA00B14	V.RESISTOR 10K	1		C337	ECUM1H270JCN	CHIP 50V 27P	1	
VR2001	EVNDRAA00B54	V.RESISTOR 50K	1		C338	ECUX1E1042FN	CHIP 25V 0.1U	1	
VR2002	EVNDRAA00B15	V.RESISTOR 100K	1		C339	ECUM1H680JCN	CHIP 50V 68P	1	
VR2010	EVL51MA00B25	V.RESISTOR 200K	1		C340	ECEA1EK4R7	E.CAPACITOR 25V 4.7U	1	
VR2011	EVNDRAA00B15	V.RESISTOR 100K	1		C349	ECUM1H470JCN	CHIP 50V 47P	1	
VR2013	EVNDRAA00B23	V.RESISTOR 2K	1		C351	ECQV1H220JC	C.CAPACITOR 50V 22P	1	
VR3012	EVNDRAA00B52	V.RESISTOR 500	1		C352	ECQB1H562JH	P.CAPACITOR 50V 5600P	1	
VR3020	EVN38CA00B23	V.RESISTOR 2K	1		C353	ECUM1H560JCN	CHIP 50V 56P	1	
VR4001	EVNDRAA00B14	V.RESISTOR 10K	1		C701,02	ECEA1CK100	E.CAPACITOR 16V 10U	2	
VR4002	EVNDRAA00B25	V.RESISTOR 200K	1		C703	ECEA1HK2R2	E.CAPACITOR 50V 2.2U	1	
					C706	ECQV1H823JZ	P.CAPACITOR 50V 0.082U	1	
					C707	ECEA1HKS010	E.CAPACITOR 50V 1U	1	
		CRYSTAL OSCILLATOR & FILTER			C710	ECUX1H1032FN	CHIP 50V 0.01U	1	
X301	VSX0225	CRYSTAL OSCILLATOR	1		C715-20	ECUX1H1032FN	CHIP 50V 0.01U	6	
X710	EPCH38MSP1	SAW FILTER	1		C721	ECEA1HKR27	E.CAPACITOR 50V 0.27U	1	
X711	EFCS5R5M5	FILTER	1		C722	ECUX1H1032FN	CHIP 50V 0.01U	1	
X712	EFCS5R5M5	FILTER	1		C723	ECUM1H120JCN	C.CAPACITOR CH 50V 12P	1	
X715	ELB5A043	FILTER	1		C725	ECQV1H104JZ	P.CAPACITOR 50V 0.1U	1	
X716	EFCA40R40M1	FILTER	1		C728	ECUX1H1032FN	CHIP 50V 0.01U	1	
X717	ELB5A048	TRANSFORMER	1		C730	ECEA1CK100	E.CAPACITOR 16V 10U	1	
X801	VSX0162A	CRYSTAL OSCILLATOR	1		C731	ECEA1CKS100	E.CAPACITOR 16V 10U	1	
X3001	VSX0099	CRYSTAL OSCILLATOR	1		C732	ECQV1H224B	M.CAPACITOR 50V 0.22U	1	
X6001	VSX0204	CRYSTAL OSCILLATOR	1		C734	ECUX1H1032FN	CHIP 50V 0.01U	1	
X7504	VSQ0565	SENSOR	1		C735	ECUX1H070DCN	CHIP 50V 7P	1	
X7801	VSX0173	CRYSTAL OSCILLATOR	1		C736	ECQB1H103JH	P.CAPACITOR 50V 0.01U	1	
X7851	EFOA4ROM03C2	CRYSTAL OSCILLATOR	1		C737	ECUX1H151JCN	CHIP 50V 150P	1	
					C739	ECEA1HK010	E.CAPACITOR 50V 1U	1	
					C740	ECUX1H1032FN	CHIP 50V 0.01U	1	
					C741	ECEA1CK100	E.CAPACITOR 16V 10U	1	
		MISCELLANEOUS			C742	ECUX1H030CCN	CHIP 50V 3P	1	
	VSC1068	HEAT SINK	1	FOR IC6003	C743	ECUM1H270RSN	CHIP 50V 27P	1	
	VWJ0228	FLEXIBLE CABLE	13P	P7502-P7401	C744	ECEA1HKR47	E.CAPACITOR 50V 0.47U	1	
	VEJ0643	REAR JACK	1		C745	ECUX1H680JPN	CHIP 50V 68P	1	
	ENC87966	RF CONVERTER UNIT	1	<1>	C746	ECUX1H150JCN	CHIP 50V 15P	1	
	TNV57481F1	TUNER	1	<1>	C747	ECUX1H1032FN	CHIP 50V 0.01U	1	
	VMCO075	HEAT SINK SPRING	1	FORIC2501	C748	ECEA1CK330	E.CAPACITOR 16V 33U	1	
	VSC1689	HEAT SINK	1	FORIC2501	C749	ECEA1CK100	E.CAPACITOR 16V 10U	1	
	VJF0215	BINDER	1		C760	ECQV1H473JZ	P.CAPACITOR 50V 0.047U	1	
	VSC2232	SHIELD CASE (TOP)	1	FOR TV DEMODU.PACK	C781	ECUX1H390JCN	CHIP 50V 39P	1	
	VSC2233	SHIELD CASE (MAIN)	1	FOR TV DEMODU.PACK	C782	ECUM1H060DCN	CHIP 50V 6P	1	
	VSC2396	SHIELD CASE (BOTTOM)	1	FOR TV DEMODU.PACK	C801	ECUM1H1032FN	CHIP 50V 0.01U	1	
					C814	ECEA1AK101	E.CAPACITOR 10V 100U	1	
					C815	ECQV1H154JZ	P.CAPACITOR 50V 0.15U	1	
					C816	ECUX1E1042FN	CHIP 25V 0.1U	1	
	VEP03493BG	MAIN C.B.A.		NV-D48B<1>(NLA)	C817	ECQV1H274JZ	P.CAPACITOR 50V 0.27U	1	
		CAPACITORS			C818	ECUM1H471KBN	CHIP 50V 470P	1	
C301	ECEA1EKN2R2	E.CAPACITOR 25V 2.2U	1		C819	ECUM1H820JCN	CHIP 50V 82P	1	
C302	ECEA0JK220	E.CAPACITOR 6.3V 22U	1		C820	ECEA1HK2R2	E.CAPACITOR 50V 2.2U	1	
C303	ECUX1E1042FN	CHIP 25V 0.1U	1		C821	ECEA1HFS4R7	E.CAPACITOR 50V 4.7U	1	
					C823	ECEA1HK2R2	E.CAPACITOR 50V 2.2U	1	

To guarantee the FUNCTION,SAFETY and RELIABILITY of repaired units,only use ORIGINAL REPLACEMENT PARTS which are listed with their part numbers in this parts list section.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C824	ECEA1HK010	E. CAPACITOR 50V 1U	1		C2804	ECUM1H181KN	CHIP 50V 180P	1	
C825	ECUM1H101JCN	CHIP 50V 100P	1		C2805	ECEA1HK010	E. CAPACITOR 50V 1U	1	
C826	ECEA1AU221	E. CAPACITOR 10V 220U	1		C2806	ECUM1H220JCN	CHIP 50V 22P	1	
C827	ECUM1H050CCN	CHIP 50V 5P	1		C2807	ECEA0JK470	E. CAPACITOR 6.3V 47U	1	
C828	ECUM1H102KBN	CHIP 50V 1000P	1		C2808	ECQV1H124JZ	P. CAPACITOR 50V 0.12U	1	
C829	ECQV1H474JZ	P. CAPACITOR 50V 0.47U	1		C2809	ECEA1EK4R7	E. CAPACITOR 25V 4.7U	1	
C831, 32	ECUX1E1042FN	CHIP 25V 0.1U	2		C2812, 13	ECQV1H224JZ	P. CAPACITOR 50V 0.22U	2	
C1101	ECEA1EK100	E. CAPACITOR 25V 10U	1		C2918	ECQV1H104JZ	P. CAPACITOR 50V 0.1U	1	
C1103	ECEA0JK101	E. CAPACITOR 6.3V 100U	1		C3001	ECEA1CK470	E. CAPACITOR 16V 47U	1	
C2022	ECEA1CK100	E. CAPACITOR 16V 10U	1		C3002	ECEA0JU471	E. CAPACITOR 6.3V 470U	1	
C2023	ECEA1HKR47	E. CAPACITOR 50V 0.47U	1		C3003, 04	ECUM1H332KBN	CHIP 50V 3300P	2	
C2024	ECUM1H182KBN	CHIP 50V 1800P	1		C3007	ECEA1CK100	E. CAPACITOR 16V 10U	1	
C2026	ECQB1H333JH	P. CAPACITOR 50V 0.033U	1		C3010	ECUM1H151JCN	CHIP 50V 150P	1	
C2027	ECEA0JK470	E. CAPACITOR 6.3V 47U	1		C3011	ECUM1H270JCN	CHIP 50V 27P	1	
C2104	ECEA1CKN100	E. CAPACITOR 16V 10U	1		C3012	ECUM1H681JN	CHIP 50V 680P	1	
C2105	VCYD1C473MR1	S. CAPACITOR 16V 0.047U	1		C3013	ECEA1HK010	E. CAPACITOR 50V 1U	1	
C2106	ECEA1CK100	E. CAPACITOR 16V 10U	1		C3014	ECUM1H150JCN	CHIP 50V 15P	1	
C2107	ECEA1HK010	E. CAPACITOR 50V 1U	1		C3015	VCYD1C104MR1	S. CAPACITOR 16V 0.1U	1	
C2108	ECEA1CK100	E. CAPACITOR 16V 10U	1		C3016	ECEA0JK470	E. CAPACITOR 6.3V 47U	1	
C2109	ECEA1HK010	E. CAPACITOR 50V 1U	1		C3019	ECUM1H220JCN	CHIP 50V 22P	1	
C2110	ECEA0JK330	E. CAPACITOR 6.3V 33U	1		C3050	ECEA1CK100	E. CAPACITOR 16V 10U	1	
C2112	VCYD1C104MR1	S. CAPACITOR 16V 0.1U	1		C3051	ECEA1CK470	E. CAPACITOR 16V 47U	1	
C2113	ECQV1H683JZ	P. CAPACITOR 50V 0.068U	1		C3053	ECEA0JK101	E. CAPACITOR 6.3V 100U	1	
C2114	ECUM1H102KBN	CHIP 50V 1000P	1		C3054	ECEA0JK470	E. CAPACITOR 6.3V 47U	1	
C2115	ECEA1HKNR33	E. CAPACITOR 50V 0.33U	1		C3055	ECEA1CK330	E. CAPACITOR 16V 33U	1	
C2116	VCYD1C104MR1	S. CAPACITOR 16V 0.1U	1		C3056	ECEA1CK470	E. CAPACITOR 16V 47U	1	
C2117	ECEA1HKR47	E. CAPACITOR 50V 0.47U	1		C3057	ECQB1H103JH	P. CAPACITOR 50V 0.01U	1	
C2118	ECUM1H472KBN	CHIP 50V 4700P	1		C3058	ECQB1H392JH	P. CAPACITOR 50V 3900P	1	
C2119	ECQV1H334JZ	P. CAPACITOR 50V 0.33U	1		C3059	ECQB1H562JH	P. CAPACITOR 50V 5600P	1	
C2120	ECUM1H1032FN	CHIP 50V 0.01U	1		C3060	ECUM1H1032FN	CHIP 50V 0.01U	1	
C2121	VCYD1C104MR1	S. CAPACITOR 16V 0.1U	1		C3061	ECQB1H272JH	P. CAPACITOR 50V 2700P	1	
C2122	ECUM1H562KBN	CHIP 50V 5600P	1		C3062, 63	ECEA1HK010	E. CAPACITOR 50V 1U	2	
C2123	VCYD1E223KR	S. CAPACITOR 25V 0.022U	1		C3064	ECQB1H103JH	P. CAPACITOR 50V 0.01U	1	
C2124, 25	ECEA0JK470	E. CAPACITOR 6.3V 47U	2		C3067, 68	ECUM1H1032FN	CHIP 50V 0.01U	2	
C2126	ECUM1H102KBN	CHIP 50V 1000P	1		C3070	ECUM1H1032FN	CHIP 50V 0.01U	1	
C2127	ECUM1H332KBN	CHIP 50V 3300P	1		C3073	ECCF1H390JC	C. CAPACITOR 50V 39P	1	
C2129	ECQB1H272JH	P. CAPACITOR 50V 2700P	1		C3074	ECEA1CK470	E. CAPACITOR 16V 47U	1	
C2130	ECEA1CKN100	E. CAPACITOR 16V 10U	1		C3075	ECQV1H104JZ	P. CAPACITOR 50V 0.1U	1	
C2131	ECEA1HK010	E. CAPACITOR 50V 1U	1		C3077	ECQV1H104JZ	P. CAPACITOR 50V 0.1U	1	
C2132	ECEA1CK100	E. CAPACITOR 16V 10U	1		C4001	ECQB1H153JH	P. CAPACITOR 50V 0.015U	1	
C2134	ECUM1H102KBN	CHIP 50V 1000P	1		C4002	ECEA16233	E. CAPACITOR 16V 33U	1	
C2137	ECUM1H562KBN	CHIP 50V 5600P	1		C4003	ECKF1H102ZF	C. CAPACITOR 50V 1000P	1	
C2138	ECEA0JK101	E. CAPACITOR 6.3V 100U	1		C4004	ECQP1332JZ	M. CAPACITOR 100V 3300P	1	
C2139	ECEA0JK221	E. CAPACITOR 6.3V 220U	1		C4005	ECCD2H121K	C. CAPACITOR 500V 120P	1	
C2140	ECEA1CK100	E. CAPACITOR 16V 10U	1		C4006	ECEA1CK470	E. CAPACITOR 16V 47U	1	
C2141	ECEA0JK470	E. CAPACITOR 6.3V 47U	1		C4007	ECEA1CK330	E. CAPACITOR 16V 33U	1	
C2142, 43	ECUM1H1032FN	CHIP 50V 0.01U	2		C4008	ECEA1HK010	E. CAPACITOR 50V 1U	1	
C2146	VCYD1C104MR1	S. CAPACITOR 16V 0.1U	1		C4009	ECEA1EK4R7	E. CAPACITOR 25V 4.7U	1	
C2147	ECEA1CK100	E. CAPACITOR 16V 10U	1		C4011	ECQB1H123JH	P. CAPACITOR 50V 0.012U	1	
C2148	ECUM1H102KBN	CHIP 50V 1000P	1		C4012	ECEA1CK100	E. CAPACITOR 16V 10U	1	
C2155	ECEA0JK101	E. CAPACITOR 6.3V 100U	1		C4013	ECUM1H471KBN	CHIP 50V 470P	1	
C2156	ECUM1H1032FN	CHIP 50V 0.01U	1		C4015	ECEA1CKL100	E. CAPACITOR 16V 10U	1	
C2158	ECUM1E103KBN	CHIP 25V 0.01U	1		C4016	ECUM1H102KBN	CHIP 50V 1000P	1	
C2172	ECEA1EK3R3	E. CAPACITOR 25V 3.3U	1		C4017	ECEA16M10	ELECTROLYTIC 16V 10U	1	
C2174	ECUM1H102KBN	CHIP 50V 1000P	1		C4018	ECQB1H123JH	P. CAPACITOR 50V 0.012U	1	
C2175	ECUM1E103KBN	CHIP 25V 0.01U	1		C4019	ECEA1CK100	E. CAPACITOR 16V 10U	1	
C2176	ECQV1H154JZ	P. CAPACITOR 50V 0.15U	1		C4020	ECUM1H102KBN	CHIP 50V 1000P	1	
C2177	ECEA0JK470	E. CAPACITOR 6.3V 47U	1		C4021	ECEA1AK470	E. CAPACITOR 10V 47U	1	
C2178	ECEA1HKR22	E. CAPACITOR 50V 0.22U	1		C4022	ECUM1H102KBN	CHIP 50V 1000P	1	
C2179	ECUM1E103KBN	CHIP 25V 0.01U	1		C4023	ECUX1H221JCN	CHIP 50V 220P	1	
C2181, 82	ECEA0JK470	E. CAPACITOR 6.3V 47U	2		C4024, 25	ECUM1H101JCN	CHIP 50V 100P	2	
C2184	ECUM1H332KBN	CHIP 50V 3300P	1		C4032	VCYD1C104MR1	S. CAPACITOR 16V 0.1U	1	
C2191, 92	ECQV1H104JZ	P. CAPACITOR 50V 0.1U	2		C4038	ECEA1CK100	E. CAPACITOR 16V 10U	1	
C2501-03	ECQB1H333JH	P. CAPACITOR 50V 0.033U	3		C4039	VCYD1E103KR	S. CAPACITOR 25V 0.01U	1	
C2504-06	ECEA1HK2R2	E. CAPACITOR 50V 2.2U	3		C6001	ECEA0JK220	E. CAPACITOR 6.3V 22U	1	
C2507	ECQB1H223JH	P. CAPACITOR 50V 0.022U	1		C6002	VCYD1C103MR1	S. CAPACITOR 16V 0.01U	1	
C2508	ECQV1H104JZ	P. CAPACITOR 50V 0.1U	1		C6003	ECUM1H1032FN	CHIP 50V 0.01U	1	
C2511	ECEA1CK101	E. CAPACITOR 16V 100U	1		C6006	ECEA0JK330	E. CAPACITOR 6.3V 33U	1	
C2512-14	ECUM1H332KBN	CHIP 50V 3300P	3		C6007	VCYD1C104MR1	S. CAPACITOR 16V 0.1U	1	
C2517	ECEA1CK470	E. CAPACITOR 16V 47U	1		C6013	ECEA1CK330	E. CAPACITOR 16V 33U	1	
C2519	ECEA25247	E. CAPACITOR 25V 4.7U	1		C6017-19	ECEA0JK470	E. CAPACITOR 6.3V 47U	3	
C2524	ECQV1H274JZ	P. CAPACITOR 50V 0.27U	1		C6020	ECUM1H103KBN	CHIP 50V 0.01U	1	
C2801	ECEA1HK010	E. CAPACITOR 50V 1U	1		C6023	ECUM1H1032FN	CHIP 50V 0.01U	1	
C2802	VCYD1E223KR	S. CAPACITOR 25V 0.022U	1		C6024-26	ECUM1H271KBN	CHIP 50V 270P	3	
C2803	ECEA0JK470	E. CAPACITOR 6.3V 47U	1		C6027	ECEA1HKR47	E. CAPACITOR 50V 0.47U	1	

To guarantee the FUNCTION, SAFETY and RELIABILITY of repaired units, only use ORIGINAL REPLACEMENT PARTS which are listed with their part numbers in this parts list section.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C6028	ECUM1H102KBN	CHIP 50V 1000P	1		IC7551	AN5043	IC	1	
C6029	ECUM1H1032FN	CHIP 50V 0.01U	1		IC7552	AN6913	IC	1	
C7551	ECQV1H683JZ	P. CAPACITOR 50V 0.1U	1		IC7553	MN4066B	IC	1	
C7552	ECQV1H683JZ	P. CAPACITOR 50V 0.068U	1						
C7553	ECQV1H823JZ	P. CAPACITOR 50V 0.082U	1						
C7554	ECQB1H273JH	P. CAPACITOR 50V 0.027U	1				COILS		
C7555, 56	ECUM1H1032FN	CHIP 50V 0.01U	2		L301	VLQEL05F101K	COIL 100UH	1	
C7557	ECEA1HKA100	E. CAPACITOR 50V 10U	1		L302	VLQEL05F220K	COIL 22UH	1	
C7558	ECUM1H1032FN	CHIP 50V 0.01U	1		L303, 04	VLQEL05F101K	COIL 100UH	2	
C7559	ECEA1CK100	E. CAPACITOR 16V 10U	1		L306	VLQEL05F101K	COIL 100UH	1	
C7560	ECUM1H1032FN	CHIP 50V 0.01U	1		L307	VLQEL05F151K	COIL 150UH	1	
C7564	ECEA1HKN010	E. CAPACITOR 50V 1U	1		L308	VLQEL05F270K	COIL 27UH	1	
C7565	ECUM1H1032FN	CHIP 50V 0.01U	1		L309, 10	VLQEL05F101K	COIL 100UH	2	
C7569	ECEA1HKN010	E. CAPACITOR 50V 1U	1		L311	VLQEL05F2R2K	COIL 2.2UH	1	
C7571	EECS5R5V473	E. CAPACITOR 5.5V 0.047	1		L702	ELESP680KA	COIL 68UH	1	
C7590	ECEA0JU221	E. CAPACITOR 6.3V 220U	1		L711	VLQ0305J1R2	COIL 1.2UH	1	
C7591	ECUM1H102KBN	CHIP 50V 1000P	1		L712	VLQ0305JR82T	COIL 0.82UH	1	
					L713	VLQ0305JR56T	COIL 0.56UH	1	
					L714	VLQ0305J1R2	COIL 1.2UH	1	
		DIODES			L715	VLQ0213K680	COIL 68UH	1	
D301	MA4091M	DIODE	1		L717, 18	ELESP680KA	COIL 68UH	2	
D710	MA3100L	DIODE	1		L719	ELESP120KA	COIL 12UH	1	
D712	MA28W	DIODE	1		L781	ELESP330KA	COIL 33H	1	
D1101	MA165	DIODE	1		L804	VLQEL05F150K	COIL 15UH	1	
D2007	MA165	DIODE	1		L805	VLQEL05F101K	COIL 100UH	1	
D2014	MA165	DIODE	1		L806	VLQEL05F681K	COIL 680UH	1	
D2101-05	MA165	DIODE	5		L808	VLQEL05F470K	COIL 47UH	1	
D2801-04	MA165	DIODE	4		L809	VLQEL05F331K	COIL 330UH	1	
D3008, 09	MA165	DIODE	2		L810	VLQEL05F101K	COIL 100UH	1	
D3011	MA165	DIODE	1		L811	VLQEL05F470K	COIL 47UH	1	
D4001	MA165	DIODE	1		L812	VLQEL05F681K	COIL 680UH	1	
D4050	MA165	DIODE	1		L2501	VLQEL05F102K	COIL 1000UH	1	
D6001	ERA15-01	DIODE	1		L2502	VLQ0128	COIL 47UH	1	
D6002	MA165	DIODE	1		L3001-03	VLQEL05F101K	COIL 100UH	3	
D6004	MA165	DIODE	1		L3005	VLQEL05F120K	COIL 12UH	1	
D6017	ERA15-01	DIODE	1		L3006	VLQEL05F5R6K	COIL 5.6UH	1	
D6019	MA4150M	DIODE	1		L3007	VLQEL05F101K	COIL 100UH	1	
D6023, 24	MA165	DIODE	2		L3008	VLQEL05F3R3K	COIL 3.3UH	1	
D6028, 29	MA165	DIODE	2		L3012	VLQEL05F101K	COIL 100UH	1	
D6030	MA4056L	DIODE	1		L3013	VLQEL05F390K	COIL 39UH	1	
D6032	MA165	DIODE	1		L3014	VLQEL05F470K	COIL 47UH	1	
D7551-53	MA165	DIODE	3		L4001	VLQEL07F822J	COIL 8200UH	1	
					L4002	VLQEL05F471K	COIL 470UH	1	
					L7551	VLQEL05F680K	COIL 68UH	1	
		DELAY							
DL802	VLDO148	DELAY	1				CONNECTORS		
					P006	VJS1902	CONNECTOR (FEMALE)	1	
					P501	VJFO171T	CONNECTOR	1	
		FILTERS			P1001	VJS1931T	CONNECTOR (FEMALE)	1	
FL301	ELB4M022	FILTER	1		P1101	VJP1931T	CONNECTOR (MALE)	1	
FL302	VLFO499	FILTER	1		P2001	VJP1232T	CONNECTOR (MALE) 5P	1	
FL303	VLFO567	FILTER	1		P2002	VJP1932T	CONNECTOR (MALE)	1	
FL801	VLFO299	FILTER	1		P2801	VJP1244T	CONNECTOR (MALE) 4P	1	
					P2901	VJS1232T	CONNECTOR (FEMALE)	1	
					P3001	VJP1393T	CONNECTOR (MALE) 13P	1	
		ICS			P3002	VJP1237T	CONNECTOR (MALE) 10P	1	
IC301	VEFH03D	HIC	1		P4001	VJP1233T	CONNECTOR (MALE) 6P	1	
IC303	MSM6965-3RS	IC	1		P6001	VJS2157W	CONNECTOR (FEMALE)	1	
IC701	ME1366SP	IC	1		P6002	VJS2149W	CONNECTOR (FEMALE)	1	
IC801	VEFH04A	HIC	1		P6003	VJP1236T	CONNECTOR (MALE) 9P	1	
IC2101	UPD6160CA606	IC	1		P6004	VJP1231T	CONNECTOR (MALE) 4P	1	
IC2102	MN15312VPL	IC	1		P6005	VJP1231T	CONNECTOR (MALE) 4P	1	
IC2103, 04	AN6562	IC	2		P6202	VJS1236T	CONNECTOR (FEMALE)	1	
IC2105	UPD4069UBC	IC	1		P7401	VJS1475	CONNECTOR (FEMALE)	1	
IC2501	BA6432S	IC	1		P7402	VJS2157W	CONNECTOR (FEMALE)	1	
IC2801	BA6305	IC	1		P9501	VJS1237T	CONNECTOR	1	
IC2802	MC14013BCP	IC	1		P9502	VJS1231T	CONNECTOR (FEMALE)	1	
IC2803	LM393P	IC	1						
IC3001	BA7004	IC	1				TRANSISTORS		
IC3002	AN5421N	IC	1		Q301	2SB709	TRANSISTOR CHIP	1	
IC4001	BA7766S	IC	1		Q302, 03	2SC2295	TRANSISTOR CHIP	2 (B.C)	
IC6001	MN15362VPD	IC	1		Q304	2SD601	TRANSISTOR CHIP	1 (Q,R,S)	
IC6002	AN6914	IC	1		Q703	2SD601	TRANSISTOR	1 (S.T)	
IC6003	MN4510B	IC	1						
IC6004	MN12821	IC	1 (R)						

To guarantee the FUNCTION, SAFETY and RELIABILITY of repaired units, only use ORIGINAL REPLACEMENT PARTS which are listed with their part numbers in this parts list section.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
Q710	2SC2377	TRANSISTOR	1	(C,D)	R317	ERJ6GMJ471	CHIP 1/16W 470	1	
Q712	2SD638	TRANSISTOR	1		R325	ERJ6GMJ151	CHIP 1/16W 150	1	
Q713	2SD1328	TRANSISTOR	1		R326	ERJ6GMJ822	CHIP 1/16W 8.2K	1	
Q714	2SD601	TRANSISTOR CHIP	1		R327	ERJ6GMJ332	CHIP 1/16W 3.3K	1	
Q771	2SD601	TRANSISTOR CHIP	1		R328	ERJ6GMJ272	CHIP 1/16W 2.7K	1	
Q804	2SB709	TRANSISTOR CHIP	1		R329	ERJ6GMJ103	CHIP 1/16W 10K	1	
Q2001	2SB709	TRANSISTOR CHIP	1		R330	ERJ6GMJ183	CHIP 1/16W 18K	1	
Q2002-04	2SD601	TRANSISTOR CHIP	3		R331	ERJ6GMJ102	CHIP 1/16W 1K	1	
Q2006	2SD1330	TRANSISTOR	1	(S,T)	R332	ERJ6GMJ222	CHIP 1/16W 2.2K	1	
Q2108	2SD601	TRANSISTOR CHIP	1		R334, 35	ERJ6GMJ102	CHIP 1/16W 1K	2	
Q2111, 12	2SD601	TRANSISTOR CHIP	2		R338	ERJ6GMJ474	M.RESISTOR CHI/16W 470K	1	
Q2801	2SD601	TRANSISTOR CHIP	1		R339	ERJ6GMJ101	CHIP 1/16W 100	1	
Q2802	2SB709	TRANSISTOR CHIP	1		R707	ERJ6GEYJ103	CHIP 1/16W 10K	1	
Q2803-06	2SD601	TRANSISTOR CHIP	4		R712	ERJ6GEYJ682	CHIP 1/16W 6.8K	1	
Q3002	2SC2295	TRANSISTOR	1		R713	ERJ6GEYJ681	CHIP 1/16W 680	1	
Q3005	2SD601	TRANSISTOR CHIP	1		R714	ERD2PCG330	C.RESISTOR 2W 33	1	<1>
Q3006	2SC2295	TRANSISTOR	1		R715	ERJ6GEYJ271	CHIP 1/16W 270	1	
Q3007	2SB641	TRANSISTOR	1		R716	ERJ6GEYJ272	CHIP 1/16W 2.7K	1	
Q3011	2SB709	TRANSISTOR CHIP	1		R717	ERJ6GEYJ332	CHIP 1/16W 3.3K	1	
Q3013	2SD601	TRANSISTOR CHIP	1		R718	ERJ6GEYJ754	CHIP 1/16W 750K	1	
Q3014	2SA564	TRANSISTOR	1	(P,Q,R)	R719	ERJ6GEYJ682	CHIP 1/16W 6.8K	1	
Q4001	2SD602	TRANSISTOR	1	(R)	R720	ERJ6GEYJ822	CHIP 1/16W 8.2K	1	
Q6006	2SB641	TRANSISTOR	1		R721	ERJ6GEYJ332	CHIP 1/16W 3.3K	1	
Q6007	2SB643	TRANSISTOR	1		R723	ERJ6GEYJ183	CHIP 1/16W 180K	1	
Q6009	2SB643	TRANSISTOR	1	(R,S)	R724	ERJ6GEYJ101	CHIP 1/16W 100	1	
Q6016	2SD1275	TRANSISTOR	1	(P,Q)	R725	ERJ6GEYJ182	CHIP 1/16W 1.8K	1	
Q6017	2SD893	TRANSISTOR	1		R726	ERJ6GEYJ472	CHIP 1/16W 4.7K	1	
Q6018	2SD973	TRANSISTOR	1	(S)	R727	ERJ6GEYJ471	CHIP 1/16W 470	1	
Q6019	2SD638	TRANSISTOR	1		R728	VRE0040E471T	V.RESISTOR 470	1	
Q6020	2SD973	TRANSISTOR	1	(S)	R729, 30	ERJ6GEYJ331	CHIP 1/16W 330	2	
					R737	ERJ6GEYJ274	CHIP 1/16W 270K	1	
					R738	ERJ6GEYJ334	CHIP 1/16W 330K	1	
					R739	ERJ6GEYJ681	CHIP 1/16W 680	1	
		COMBINATION PARTS			R740	ERJ6GEYJ473	CHIP 1/16W 47K	1	
QR701,02	UN2213	TRANSISTOR-RESISTOR	2		R741, 42	ERJ6GEYJ272	CHIP 1/16W 2.7K	2	
QR713	UN2211	TRANSISTOR-RESISTOR	1		R743	ERJ6GEYJ470	CHIP 1/16W 47	1	
QR1101	UN2213	TRANSISTOR-RESISTOR	1		R744	ERJ6GEYJ821	CHIP 1/16W 820	1	
QR2002	UN2212	TRANSISTOR-RESISTOR	1		R745	ERJ6GEYJ331	CHIP 1/16W 330	1	
QR2007	UN2213	TRANSISTOR-RESISTOR	1		R746	VRE0040E181T		1	
QR2101,02	UN2113	TRANSISTOR-RESISTOR	2		R750	ERJ6GEYJ182	CHIP 1/16W 1.8K	1	
QR2103	UN2212	TRANSISTOR-RESISTOR	1		R757	ERJ6GEYJ222	CHIP 1/16W 2.2K	1	
QR2104	UN2110	TRANSISTOR-RESISTOR	1		R759	ERJ6GEYJ103	CHIP 1/16W 10K	1	
QR2105	UN2117	TRANSISTOR-RESISTOR	1		R760	ERJ6GEYJ102	CHIP 1/16W 1K	1	
QR2106	UN2115	TRANSISTOR-RESISTOR	1		R763	ERJ6GEYJ103	CHIP 1/16W 10K	1	
QR2107	UN2110	TRANSISTOR-RESISTOR	1		R764	ERJ6GEYJ822	CHIP 1/16W 8.2K	1	
QR2801,02	UN2213	TRANSISTOR-RESISTOR	2		R772	ERJ6GEYJ102	CHIP 1/16W 1K	1	
QR2804	UN2211	TRANSISTOR-RESISTOR	1		R773	ERJ6GEYJ103	CHIP 1/16W 10K	1	
QR3004	UN2111	TRANSISTOR-RESISTOR	1		R781	ERJ6GEYJ681	CHIP 1/16W 680	1	
QR3011	UN2212	TRANSISTOR-RESISTOR	1		R782	ERJ6GEYJ471	CHIP 1/16W 470	1	
QR4006	UN1112	TRANSISTOR-RESISTOR	1		R792	ERJ6GEYJ120	CHIP 1/16W 12	1	
QR4007	UN2211	TRANSISTOR-RESISTOR	1		R815	ERJ6GMJ103	CHIP 1/16W 10K	1	
QR6001	UN2212	TRANSISTOR-RESISTOR	1		R816	ERJ6GMJ822	CHIP 1/16W 8.2K	1	
QR6005	UN2213	TRANSISTOR-RESISTOR	1		R818	ERJ6GMJ102	CHIP 1/16W 1K	1	
QR6006	UN2111	TRANSISTOR-RESISTOR	1		R819	ERJ6GMJ182	CHIP 1/16W 1.8K	1	
QR6008	UN2119	TRANSISTOR-RESISTOR	1		R820	ERJ6GMJ222	CHIP 1/16W 2.2K	1	
QR6011	UN2212	TRANSISTOR-RESISTOR	1		R821, 22	ERJ6GMJ103	CHIP 1/16W 10K	2	
QR6012	UN2113	TRANSISTOR-RESISTOR	1		R823	ERJ6GMJ271	CHIP 1/16W 270	1	
QR7551-54	UN2213	TRANSISTOR-RESISTOR	4		R824	ERJ6GMJ102	CHIP 1/16W 1K	1	
QR7561	UN2211	TRANSISTOR-RESISTOR	1		R825	ERJ6GMJ182	CHIP 1/16W 1.8K	1	
					R826	ERJ6GMJ681	CHIP 1/16W 680	1	
					R1101	ERJ6GMJ561	CHIP 1/16W 560	1	
		RESISTORS			R2007	ERJ6GMJ472	CHIP 1/16W 4.7K	1	
R301	ERJ6GMJ122	CHIP 1/16W 1.2K	1		R2008	ERJ6GMJ682	CHIP 1/16W 6.8K	1	
R302	ERJ6GMJ391	CHIP 1/16W 390	1		R2009	ERJ6GMJ472	CHIP 1/16W 4.7K	1	
R303	ERJ6GMJ103	CHIP 1/16W 10K	1		R2010	ERJ6GMJ223	CHIP 1/16W 22K	1	
R304	ERJ6GMJ102	CHIP 1/16W 1K	1		R2011	ERJ6GMJ561	CHIP 1/16W 560	1	
R305	ERJ6GMJ824	CHIP 1/16W 820K	1		R2029	ERJ6GMJ683	CHIP 1/16W 68K	1	
R306	ERJ6GMJ152	CHIP 1/16W 1.5K	1		R2030	ERJ6GMJ333	CHIP 1/16W 33K	1	
R307	ERJ6GMJ102	CHIP 1/16W 1K	1		R2031	ERJ6GMJ473	CHIP 1/16W 47K	1	
R308	ERJ6GMJ123	CHIP 1/16W 12K	1		R2032	ERJ6GMJ124	CHIP 1/16W 120K	1	
R309	ERJ6GMJ272	CHIP 1/16W 2.7K	1		R2033	ERJ6GMJ683	CHIP 1/16W 68K	1	
R310	ERJ6GMJ103	CHIP 1/16W 10K	1		R2034	ERJ6GMJ391	CHIP 1/16W 390	1	
R311	ERJ6GMJ272	CHIP 1/16W 2.7K	1		R2037	ERJ6GMJ103	CHIP 1/16W 10K	1	
R312	ERJ6GMJ222	CHIP 1/16W 2.2K	1		R2038	ERJ6GMJ104	CHIP 1/16W 100K	1	
R316	ERJ6GMJ104	CHIP 1/16W 100K	1		R2046	ERJ6GMJ153	CHIP 1/16W 15K	1	

To guarantee the FUNCTION,SAFETY and RELIABILITY of repaired units,only use ORIGINAL REPLACEMENT PARTS which are listed with their part numbers in this parts list section.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R2047, 48	ERJ6GMYJ154	CHIP 1/16W 150K	2		R2809	ERJ6GMYJ750	CHIP 1/16W 75	1	
R2049	ERJ6GMYJ273	CHIP 1/16W 27K	1		R2810	ERJ6GMYJ124	CHIP 1/16W 120K	1	
R2050	ERJ6GMYJ102	CHIP 1/16W 1K	1		R2811	ERJ6GMYG113	M.RESISTOR CHI/16W 11K	1	
R2051	ERJ6GMYJ222	CHIP 1/16W 2.2K	1		R2812	ERJ6GMYJ153	CHIP 1/16W 15K	1	
R2054	ERJ6GMYOR00	CHIP 1/16W 0	1		R2813	ERJ6GMYJ221	CHIP 1/16W 220	1	
R2056	ERDS2TJ471	C.RESISTOR 1/4W 470	1		R2814	ERJ6GMYJ102	CHIP 1/16W 1K	1	
R2106	ERJ6GMYJ392	CHIP 1/16W 3.9K	1		R2815, 16	ERJ6GMYJ473	CHIP 1/16W 47K	2	
R2108	ERJ6GMYJ222	CHIP 1/16W 2.2K	1		R2817	ERJ6GMYJ223	CHIP 1/16W 22K	1	
R2109	ERJ6GMYJ682	CHIP 1/16W 6.8K	1		R2818	ERJ6GMYJ102	CHIP 1/16W 1K	1	
R2110	ERJ6GMYJ274	CHIP 1/16W 270K	1		R2819	ERJ6GMYJ124	CHIP 1/16W 120K	1	
R2111	ERJ6GMYJ563	CHIP 1/16W 56K	1		R2820	ERJ6GMYJ221	CHIP 1/16W 220	1	
R2112, 13	ERJ6GMYJ154	CHIP 1/16W 150K	2		R2821	ERJ6GMYJ103	CHIP 1/16W 10K	1	
R2114	ERJ6GMYJ224	CHIP 1/16W 220K	1		R2822	ERJ6GMYJ124	CHIP 1/16W 120K	1	
R2115	ERJ6GMYJ272	CHIP 1/16W 2.7K	1		R2823	ERJ6GMYJ473	CHIP 1/16W 47K	1	
R2117	ERJ6GMYJ683	CHIP 1/16W 68K	1		R2824	ERJ6GMYJ103	CHIP 1/16W 10K	1	
R2119	ERJ6GMYJ333	CHIP 1/16W 33K	1		R2825	ERJ6GMYJ473	CHIP 1/16W 47K	1	
R2120	ERJ6GMYJ274	CHIP 1/16W 270K	1		R2831	ERJ6GMYJ272	CHIP 1/16W 2.7K	1	
R2121	ERJ6GMYOR00	CHIP 1/16W 0	1		R2832	ERJ6GMYJ822	CHIP 1/16W 8.2K	1	
R2122, 23	ERJ6GMYJ332	CHIP 1/16W 3.3K	2		R2833	ERJ6GMYJ103	CHIP 1/16W 10K	1	
R2124	ERJ6GMYJ561	CHIP 1/16W 560	1		R3001, 02	ERJ6GMYJ103	CHIP 1/16W 10K	2	
R2125	ERJ6GMYJ222	CHIP 1/16W 2.2K	1		R3006	ERJ6GMYJ473	CHIP 1/16W 47K	1	
R2131	ERJ6GMYJ152	CHIP 1/16W 1.5K	1		R3009	ERJ6GMYJ152	CHIP 1/16W 1.5K	1	
R2132, 33	ERJ6GMYJ563	CHIP 1/16W 56K	2		R3010	ERJ6GMYJ392	CHIP 1/16W 3.9K	1	
R2134	ERJ6GMYJ472	CHIP 1/16W 4.7K	1		R3011	ERJ6GMYJ102	CHIP 1/16W 1K	1	
R2135	ERJ6GMYJ333	CHIP 1/16W 33K	1		R3022, 23	ERJ6GMYJ821	CHIP 1/16W 820	2	
R2136, 37	ERJ6GMYJ154	CHIP 1/16W 150K	2		R3028	ERJ6GMYJ102	CHIP 1/16W 1K	1	
R2138	ERJ6GMYJ124	CHIP 1/16W 120K	1		R3029	ERJ6GMYJ272	CHIP 1/16W 2.7K	1	
R2139	ERJ6GMYJ392	CHIP 1/16W 3.9K	1		R3030	ERJ6GMYJ750	CHIP 1/16W 75	1	
R2140	ERJ6GMYG333	CHIP 1/16W 33K	1		R3032	ERJ6GMYJ104	CHIP 1/16W 100K	1	
R2141	ERJ6GMYJ684	CHIP 1/16W 680K	1		R3033	ERJ6GMYJ183	CHIP 1/16W 18K	1	
R2142	ERJ6GMYJ154	CHIP 1/16W 150K	1		R3034	ERJ6GMYJ333	CHIP 1/16W 33K	1	
R2143	ERJ6GMYJ683	CHIP 1/16W 68K	1		R3035	ERJ6GMYJ222	CHIP 1/16W 2.2K	1	
R2144, 45	ERJ6GMYJ223	CHIP 1/16W 22K	2		R3036	ERJ6GMYJ183	CHIP 1/16W 18K	1	
R2146	ERJ6GMYJ103	CHIP 1/16W 10K	1		R3040	ERJ6GMYJ750	CHIP 1/16W 75	1	
R2147	ERJ6GMYJ392	CHIP 1/16W 3.9K	1		R3042	ERJ6GMYJ102	CHIP 1/16W 1K	1	
R2148	ERJ6GMYJ223	CHIP 1/16W 22K	1		R3050, 51	ERJ6GMYJ750	CHIP 1/16W 75	2	
R2149	ERJ6GMYG472	M.RESISTOR CHI/16W 4.7K	1		R3054	ERJ6GMYOR00	CHIP 1/16W 0	1	
R2150	ERJ6GMYJ821	CHIP 1/16W 820	1		R3055	ERJ6GMYJ101	CHIP 1/16W 100	1	
R2151	ERJ6GMYJ824	CHIP 1/16W 820K	1		R3056	ERJ6GMYJ152	CHIP 1/16W 1.5K	1	
R2153	ERJ6GMYJ684	CHIP 1/16W 680K	1		R3062	ERJ6GMYJ223	CHIP 1/16W 22K	1	
R2156	ERJ6GMYJ123	CHIP 1/16W 12K	1		R3063	ERJ6GMYJ332	CHIP 1/16W 3.3K	1	
R2157	ERJ6GMYJ562	CHIP 1/16W 5.6K	1		R3064	ERJ6GMYJ152	CHIP 1/16W 1.5K	1	
R2158	ERJ6GMYJ683	CHIP 1/16W 68K	1		R3065	ERJ6GMYJ561	CHIP 1/16W 560	1	
R2159, 60	ERJ6GMYJ223	CHIP 1/16W 22K	2		R3066	ERJ6GMYJ222	CHIP 1/16W 2.2K	1	
R2161	ERJ6GMYJ183	CHIP 1/16W 18K	1		R3067	ERJ6GMYJ472	CHIP 1/16W 4.7K	1	
R2166, 67	ERJ6GMYJ563	CHIP 1/16W 56K	2		R3068	ERJ6GMYJ562	CHIP 1/16W 5.6K	1	
R2168, 69	ERJ6GMYJ562	CHIP 1/16W 5.6K	2		R3069	ERJ6GMYJ151	CHIP 1/16W 150	1	
R2174	ERJ6GMYJ103	CHIP 1/16W 10K	1		R3070	ERJ6GMYJ562	CHIP 1/16W 5.6K	1	
R2175	ERJ6GMYJ334	CHIP 1/16W 330K	1		R3071	ERJ6GMYJ104	CHIP 1/16W 100K	1	
R2177	ERJ6GMYJ681	CHIP 1/16W 680	1		R3072	ERJ6GMYJ393	CHIP 1/16W 39K	1	
R2178	ERJ6GMYJ104	CHIP 1/16W 100K	1		R3073	ERJ6GMYJ222	CHIP 1/16W 2.2K	1	
R2179	ERJ6GMYJ683	CHIP 1/16W 68K	1		R3074	ERJ6GMYJ822	CHIP 1/16W 8.2K	1	
R2181	ERJ6GMYJ472	CHIP 1/16W 4.7K	1		R3075	ERJ6GMYJ332	CHIP 1/16W 3.3K	1	
R2182	ERJ6GMYJ473	CHIP 1/16W 47K	1		R3076	ERJ6GMYJ393	CHIP 1/16W 39K	1	
R2183	ERJ6GMYJ103	CHIP 1/16W 10K	1		R3077	ERJ6GMYJ122	CHIP 1/16W 1.2K	1	
R2184	ERJ6GMYJ102	CHIP 1/16W 1K	1		R3081	ERJ6GMYJ273	CHIP 1/16W 27K	1	
R2185	ERJ6GMYJ223	CHIP 1/16W 22K	1		R3084	ERJ6GMYJ222	CHIP 1/16W 2.2K	1	
R2186, 87	ERJ6GMYJ222	CHIP 1/16W 2.2K	2		R3085	ERJ6GMYJ221	CHIP 1/16W 220	1	
R2188	ERJ6GMYJ223	CHIP 1/16W 22K	1		R3087, 88	ERJ6GMYJ222	CHIP 1/16W 2.2K	2	
R2189	ERJ6GMYJ222	CHIP 1/16W 2.2K	1		R4001	ERJ6GMYJ183	CHIP 1/16W 18K	1	
R2190	ERJ6GMYJ821	CHIP 1/16W 820	1		R4002	ERJ6GMYJ100	CHIP 1/16W 10	1	
R2191	ERJ6GMYJ105	CHIP 1/16W 1M	1		R4003	ERJ6GMYJ203	CHIP 1/16W 2K	1	
R2192	ERJ6GMYJ472	CHIP 1/16W 4.7K	1		R4004	ERJ6GMYJ562	CHIP 1/16W 5.6K	1	
R2501-03	ERDS2TJ330	C.RESISTOR 1/4W 33	3		R4005	ERJ6GMYOR00	CHIP 1/16W 0	1	
R2504	ERDS1TJ1R0	C.RESISTOR 1/2W 1.0	1		R4006	ERJ6GMYJ151	CHIP 1/16W 150	1	
R2505	ERJ6GMYJ102	CHIP 1/16W 1K	1		R4007	ERJ6GMYJ221	CHIP 1/16W 220	1	
R2506	ERJ6GMYG512	CHIP 1/16W 5.1K	1		R4008	ERJ6GMYJ122	CHIP 1/16W 1.2K	1	
R2518	ERJ6GMYJ330	CHIP 1/16W 33	1		R4009	ERJ6GMYJ104	CHIP 1/16W 100K	1	
R2801, 02	ERJ6GMYJ103	CHIP 1/16W 10K	2		R4010	ERJ6GMYJ683	CHIP 1/16W 68K	1	
R2803	ERJ6GMYJ561	CHIP 1/16W 560	1		R4012	ERJ6GMYJ331	CHIP 1/16W 330	1	
R2804	ERJ6GMYJ393	CHIP 1/16W 39K	1		R4013	ERJ6GMYJ334	CHIP 1/16W 330K	1	
R2805	ERJ6GMYJ332	CHIP 1/16W 3.3K	1		R4014	ERJ6GMYJ103	CHIP 1/16W 10K	1	
R2806	ERJ6GMYJ221	CHIP 1/16W 220	1		R4015	ERJ6GMYOR00	CHIP 1/16W 0	1	
R2807	ERJ6GMYJ823	M.RESISTOR CHI/16W 82K	1		R4016	ERJ6GMYJ105	CHIP 1/16W 1M	1	
R2808	ERJ6GMYJ103	CHIP 1/16W 10K	1		R4017	ERJ6GMYJ272	CHIP 1/16W 2.7K	1	

To guarantee the FUNCTION, SAFETY and RELIABILITY of repaired units, only use ORIGINAL REPLACEMENT PARTS which are listed with their part numbers in this parts list section.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
R4018	ERJ6GMYJ223	CHIP 1/16W 22K	1		R7595	ERJ6GMYJ181	CHIP 1/16W 180	1	
R4019	ERJ6GMYJ562	CHIP 1/16W 5.6K	1		R7597	ERJ6GMYJ102	CHIP 1/16W 1K	1	
R4020	ERJ6GMYJ563	CHIP 1/16W 56K	1						
R4021	ERJ6GMYJ562	CHIP 1/16W 5.6K	1				TRANSFORMERS		
R4022	ERJ6GMYJ104	CHIP 1/16W 100K	1		T703	EIV5ECO05A	TRANSFORMER	1	
R4023	ERJ6GMYG473	CHIP 1/16W 47K	1		T704	EIV5ECO07A	TRANSFORMER	1	
R4024, 25	ERJ6GMYG104	CHIP 1/16W 100K	2		T711	EIS5ECO08A	TRANSFORMER	1	
R4051	ERJ6GMYJ123	CHIP 1/16W 12K	1		T4001	EIQ7QF014Q	TRANSFORMER	1	
R4052	ERJ6GMYJ153	CHIP 1/16W 15K	1						
R4054	ERJ6GMYJ102	CHIP 1/16W 1K	1						
R4055	ERJ6GMYJ681	CHIP 1/16W 680	1				VARIABLE RESISTORS		
R6001	ERDS1TJ470	C.RESISTOR 1/2W 47	1		VR302	EVN3ACA00B14	V.RESISTOR 10K	1	
R6002	ERJ6GMYJ473	CHIP 1/16W 47K	1		VR701	EVNDRAA00B23	V.RESISTOR 2K	1	
R6006	ERD2FCVG220	C.RESISTOR 2W 22	1 <1>		VR741	EVNDRAA00B14	V.RESISTOR 10K	1	
R6007	ERJ6GMYJ122	CHIP 1/16W 1.2K	1		VR751	EVNDRAA00B53	V.RESISTOR 5K	1	
R6008	ERJ6GMYJ181	CHIP 1/16W 180	1		VR803	EVNDXAA00B14	V.RESISTOR 10K	1	
R6009	ERJ6GMYJ561	CHIP 1/16W 560	1		VR2001	EVNDRAA00B54	V.RESISTOR 50K	1	
R6010	ERJ6GMYJ102	CHIP 1/16W 1K	1		VR2002	EVNDRAA00B15	V.RESISTOR 100K	1	
R6011	ERJ6GMYJ221	CHIP 1/16W 220	1		VR2010	EVN51MA00B25	V.RESISTOR 200K	1	
R6014	ERJ6GMYJ392	CHIP 1/16W 3.9K	1		VR2011	EVNDRAA00B15	V.RESISTOR 100K	1	
R6017	ERJ6GMYJ223	CHIP 1/16W 22K	1		VR2013	EVNDRAA00B23	V.RESISTOR 2K	1	
R6023	ERJ6GMYJ683	CHIP 1/16W 68K	1		VR3012	EVNDRAA00B52	V.RESISTOR 500	1	
R6024	ERJ6GMYJ223	CHIP 1/16W 22K	1		VR3020	EVN38CA00B23	V.RESISTOR 2K	1	
R6027	ERJ6GMYJ223	CHIP 1/16W 22K	1		VR4001	EVNDRAA00B14	V.RESISTOR 10K	1	
R6028	ERJ6GMYJ184	CHIP 1/16W 180K	1		VR4002	EVNDRAA00B25	V.RESISTOR 200K	1	
R6029	ERJ6GMYJ561	CHIP 1/16W 560	1						
R6030, 31	ERJ6GMYJ153	CHIP 1/16W 15K	2				CRYSTAL OSCILLATOR & FILTER		
R6032	ERJ6GMYJ332	CHIP 1/16W 3.3K	1		X301	VSX0225	CRYSTAL OSCILLATOR	1	
R6033, 34	ERJ6GMYJ333	CHIP 1/16W 3.3K	2		X710	EFCH39MSP3	CRYSTAL OSCILLATOR	1	
R6035-37	ERJ6GMYJ101	CHIP 1/16W 100	3		X711	EFCS6ROMW5	CRYSTAL OSCILLATOR	1	
R6038	ERJ6GMYJ272	CHIP 1/16W 2.7K	1		X712	EFCS6ROMS5	CRYSTAL OSCILLATOR	1	
R6041	ERJ6GMYJ391	CHIP 1/16W 390	1		X801	VSX0162A	CRYSTAL OSCILLATOR	1	
R6042	ERJ6GMYJ332	CHIP 1/16W 3.3K	1		X3001	VSX0099	CRYSTAL OSCILLATOR	1	
R6045	ERJ6GMYJ562	CHIP 1/16W 5.6K	1		X6001	VSX0204	CRYSTAL OSCILLATOR	1	
R6046	ERJ6GMYJ152	CHIP 1/16W 1.5K	1		X7504	VSQ0565	SENSOR	1	
R6050	ERJ6GMYJ562	CHIP 1/16W 5.6K	1						
R6051	ERJ6GMYJ332	CHIP 1/16W 3.3K	1						
R6060	ERJ6GMYJ822	CHIP 1/16W 8.2K	1						
R6067	ERJ6GMYJ101	CHIP 1/16W 100	1				MISCELLANEOUS		
R6068	ERDS1TJ332	C.RESISTOR 1/2W 3.3K	1			VSC1068	HEAT SINK	1	FOR IC6003
R6069	ERJ6GMYJ103	CHIP 1/16W 10K	1			VWJ0228	FLEXIBLE CABLE 13P	1	P7502-P7401
R6070	ERJ6GMYJ471	CHIP 1/16W 470	1			VEJ0644	REAR JACK	1	
R6071	ERJ6GMYJ152	CHIP 1/16W 1.5K	1			ENC87962	RF CONVERTER UNIT	1	<1>
R6072	ERJ6GMYJ562	CHIP 1/16W 5.6K	1			ENV87806F2	TUNER	1	<1>
R6073	ERJ6GMYJ131	CHIP 1/16W 130	1			VMO0075	HEAT SINK SPRING	1	FOR IC2501
R6074	ERJ6GMYJ221	CHIP 1/16W 220	1			VSC1689	HEAT SINK	1	FOR IC2501
R6075	ERG3SJ220	M.RESISTOR 3W 22	1			VJF0215	BINDER	1	
R6079, 80	ERJ6GMYJ103	CHIP 1/16W 10K	2			VSC2232	SHIELD CASE (TOP)	1	FOR TV DEMODU.PACK
R6083	ERJ6GMYJ104	CHIP 1/16W 100K	1			VSC2233	SHIELD CASE (MAIN)	1	FOR TV DEMODU.PACK
R6084, 85	ERJ6GMYJ561	CHIP 1/16W 560	2			VSC2396	SHIELD CASE (BOTTOM)	1	FOR TV DEMODU.PACK
R6087-89	ERJ6GMYJ272	CHIP 1/16W 2.7K	3						
R6090	ERJ6GMYJ821	CHIP 1/16W 820	1						
R6091	ERJ6GMYJ103	CHIP 1/16W 10K	1						
R6093	ERDS2TJ562	C.RESISTOR 1/4W 5.6K	1			VEPO5118B	HEAD AMP C.B.A.		(NLA)
R6095	ERDS2TJ222	C.RESISTOR 1/4W 2.2K	1						
R6096	ERJ6GMYJ681	CHIP 1/16W 680	1				CAPACITORS		
R6098	ERJ6GMYJ101	CHIP 1/16W 100	1		C501	ECUX1H1032FN	CHIP 50V 0.01U	1	
R6099	ERJ6GMYJ201	CHIP 1/16W 200	1		C502	ECUX1H820JCN	CHIP 50V 82P	1	
R7551, 52	ERJ6GMYJ473	CHIP 1/16W 47K	2		C503	ECUM1H181JN	C.CAPACITOR CH 50V 180P	1	
R7553	ERJ6GMYJ104	CHIP 1/16W 100K	1		C504	ECUX1H330JCN	CHIP 50V 33P	1	
R7554	ERJ6GMYJ124	CHIP 1/16W 120K	1		C505	ECUX1H1032FN	CHIP 50V 0.01U	1	
R7555	ERJ6GMYJ103	CHIP 1/16W 10K	1		C506	ECUX1E1042FN	CHIP 25V 0.1U	1	
R7556	ERG1SJ152	M.RESISTOR 1W 1.5K	1		C507	ECEA1CK100	E.CAPACITOR 16V 10U	1	
R7557	ERJ6GMYJ103	CHIP 1/16W 10K	1		C508	ECEA1HK010	E.CAPACITOR 50V 1U	1	
R7558	ERJ6GMYJ332	CHIP 1/16W 3.3K	1		C509	ECUX1E1042FN	CHIP 25V 0.1U	1	
R7561, 62	ERJ6GMYJ473	CHIP 1/16W 47K	2		C512	VCYD1C104MR1	S.CAPACITOR 16V 0.1U	1	
R7563	ERJ6GMYJ563	CHIP 1/16W 56K	1		C514	ECEA1CK100	E.CAPACITOR 16V 10U	1	
R7564	ERJ6GMYJ393	CHIP 1/16W 39K	1		C515, 16	ECUX1E1042FN	CHIP 25V 0.1U	2	
R7565	ERJ6GMYJ103	CHIP 1/16W 10K	1		C517, 18	ECEA1CK100	E.CAPACITOR 16V 10U	2	
R7566	ERJ6GMYJ562	CHIP 1/16W 5.6K	1		C519, 20	ECUX1E1042FN	CHIP 25V 0.1U	2	
R7567	ERJ6GMYJ682	CHIP 1/16W 6.8K	1		C521	ECEA1CK100	E.CAPACITOR 16V 10U	1	
R7568	ERJ6GMYJ332	CHIP 1/16W 3.3K	1						
R7577	ERDS2TJ100	C.RESISTOR 1/4W 10	1						
R7578	ERJ6GMYJ223	CHIP 1/16W 22K	1						
R7583	ERJ6GMYJ153	CHIP 1/16W 15K	1						

To guarantee the FUNCTION, SAFETY and RELIABILITY of repaired units, only use ORIGINAL REPLACEMENT PARTS which are listed with their part numbers in this parts list section.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C522	ECEA1HK010	E. CAPACITOR 50V 1U	1	
C523-26	ECUX1H470JCN	CHIP 50V 47P	4	
C527, 28	ECUX1H102KBN	CHIP 50V 1000P	2	
C529	ECUX1H560JCN	CHIP 50V 56P	1	
C531, 32	ECUX1H1032FN	CHIP 50V 0.01U	2	
C533	ECUX1H102KBN	CHIP 50V 1000P	1	
C534	ECUX1E1042FN	CHIP 25V 0.1U	1	
C535	ECEAOJK470	E. CAPACITOR 6.3V 47U	1	
C539	ECUX1H560JCN	CHIP 50V 56P	1	
C541	ECQV1H104JZ	P. CAPACITOR 50V 0.1U	1	
C542	ECCF1H010CC	C. CAPACITOR 50V 1P	1	
C543	ECQV1H104JZ	P. CAPACITOR 50V 0.1U	1	
		IC		
IC501	BA7254S	IC	1	
		COILS		
L501	VLQEL05F101K	COIL 100UH	1	
L502	VLQEL05F820K	COIL 82UH	1	
L503	VLQEL05F151K	COIL 150UH	1	
L505	VLQEL05F101K	COIL 100UH	1	
L506	VLQEL05F270K	COIL 27UH	1	
		CONNECTORS		
P002	VJS1927	CONNECTOR (FEMALE)	1	
P501	VJP1393T	CONNECTOR (MALE) 13P	1	
		TRANSISTOR		
Q501	2SB709	TRANSISTOR CHIP	1 (Q,R,S)	
		RESISTORS		
R501	ERJ6GMYJ561	CHIP 1/16W 560	1	
R502	ERJ6GMYJ102	CHIP 1/16W 1K	1	
R503	ERJ6GMYJ222	CHIP 1/16W 2.2K	1	
R504	ERJ6GMYJ331	CHIP 1/16W 330	1	
R505	ERJ6GMYJ330	CHIP 1/16W 33	1	
R506	ERJ6GMYJ680	CHIP 1/16W 68	1	
R507	ERJ6GMYJ471	CHIP 1/16W 470	1	
R512	ERJ6GMYJ561	CHIP 1/16W 560	1	
R513, 14	ERJ6GMYOR00	CHIP 1/16W 0	2	
R515	ERJ6GMYJ561	CHIP 1/16W 560	1	
R516	ERJ6GMYJ821	CHIP 1/16W 820	1	
R517, 18	ERJ6GMYJ100	CHIP 1/16W 10	2	
R519	ERJ6GMYJ821	CHIP 1/16W 820	1	
R520	ERJ6GMYJ391	CHIP 1/16W 390	1	
R521	ERJ6GMYJ102	CHIP 1/16W 1K	1	
R522	ERJ6GMYJ204	M. RESISTOR CH1/16W 200K	1	
R523	ERJ6GMYJ223	CHIP 1/16W 22K	1	
R524	ERJ6GMYJ152	CHIP 1/16W 1.5K	1	
R525	ERJ6GMYOR00	CHIP 1/16W 0	1	
R526-29	ERJ6GMYJ222	CHIP 1/16W 2.2K	4	
R531	ERJ6GMYOR00	CHIP 1/16W 0	1	
R532	ERJ6GMYJ392	CHIP 1/16W 3.9K	1	
R533	ERJ6GMYJ821	CHIP 1/16W 820	1	
		VARIABLE RESISTORS		
VR501	EVND1AA00B23	V. RESISTOR 2K	1	
VR502	EVND1AA00B22	V. RESISTOR 200	1	
		MISCELLANEOUS		
	VSC1834	SHIELD CASE (BOTTOM)		
	VSC1833	SHIELD CASE (MAIN)		
	VSC2352	SHIELD CASE (TOP)		

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
	VEP06482B	OPERATION C.B.A.		NV-D48EG(NLA)
	VEP06482C			NV-D48B(NLA)
		DIODES		
D6201	LN28RCPP	LED	1	
D6202	LN38GCPPSVT	LED	1	
D6203, 04	MA165	DIODE	2	
		CONNECTORS		
P6201	VJS1837	CONNECTOR (FEMALE)	1	
P6202	VJP1249T	CONNECTOR (MALE) 9P	1	
		RESISTORS		
R6201, 02	ERJ6GMYJ181	CHIP 1/16W 180	2	
R6203	ERJ6GMYJ102	CHIP 1/16W 1K	1	
		SWITCHES		
SW6201, 02	EVQGS307K	SWITCH	2	
SW6203	ESD14314	SWITCH	1	
SW6205	EVQGS307K	SWITCH	1	
SW6206	EVQGS307K	SWITCH	1	NV-D48EG
SW6207-12	EVQGS307K	SWITCH	6	
SW6213	EVQGS307K	SWITCH	1	NV-D48EG
		VARIABLE RESISTORS		
VR2007, 08	EVUFSAECA4B15	V. RESISTOR 1M	2	
VR3004	EVUJ16EC4B24	V. RESISTOR 20K	1	
		MISCELLANEOUS		
	VGU3364	SWITCH KNOB	2	
	VMD0504	LED HOLDER	2	
		TIMER C.B.A.		
	VEP07450C			NV-D48EG(NLA)
	VEP07450B			NV-D48B(NLA)
		CAPACITORS		
C6701	ECEAOJK470	E. CAPACITOR 6.3V 47U	1	
C6702	ECKF1H102KB	C. CAPACITOR 50V 1000P	1	
C6703	ECEA1HK010	E. CAPACITOR 50V 1U	1	
C6704	ECEA1HK3R3	E. CAPACITOR 50V 3.3U	1	
C7501	ECRHA030E41	TRIMER 30P	1	
C7502	ECUM1H080DCN	C. CAPACITOR CH 50V 8P	1	
C7503	ECUX1H1042FN	CHIP 50V 0.1U	1	
C7504	ECEAOJK221	E. CAPACITOR 6.3V 220U	1	
C7505	ECUM1H220JCN	CHIP 50V 22P	1	
C7506	ECUM1H330JCN	C. CAPACITOR CH 50V 33P	1	
C7507	ECEA1HK220	E. CAPACITOR 50V 22U	1	
C7508	ECEAOJK470	E. CAPACITOR 6.3V 47U	1	
C7509	ECUM1H331KBN	CHIP 50V 330P	1	
C7510	ECUX1H1042FN	CHIP 50V 0.1U	1	
C7511	ECUM1H1032FN	CHIP 50V 0.01U	1	
C7520	ECEA1HKR22	E. CAPACITOR 50V 0.22U	1	
C7521	ECUM1H102KBN	CHIP 50V 1000P	1	
		DIODES		
D6701	PN323B	PHOTO DIODE	1	
D7501	ERA15-01	DIODE	1	
D7502	MA165	DIODE	1	
D7503	MA4075H	DIODE	1	
D7506-13	MA165	DIODE	8	
D7521	MA165	DIODE	1	NV-D48B
D7522	MA165	DIODE	1	NV-D48EG

To guarantee the FUNCTION, SAFETY and RELIABILITY of repaired units, only use ORIGINAL REPLACEMENT PARTS which are listed with their part numbers in this parts list section.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
D7524, 25	MA165	DIODE	2	NV-D48B
D7526	MA165	DIODE	2	
D7527	MA165	DIODE	1	NV-D48EG
D7531, 32	MA165	DIODE	2	NV-D48B
D7534-36	MA165	DIODE	3	
D7538	MA165	DIODE	1	
		DISPLAY TUBE		
DP7501	VSL0113A	DISPLAY TUBE	1	
		ICS		
IC6701	UPC1490HA	IC	1	
IC7501	MN15283VPY	IC	1	
IC7502	MN1226	IC	1	
IC7503	MN1280P	IC	1	
IC7505	MN1280	IC	1	
		COIL		
L7501	VLQEL05F221K	COIL 220UH	1	
		CONNECTORS		
P7501	VJS1903	CONNECTOR	1	
P7502	VJS1491	CONNECTOR (FEMALE)	1	
P7504	VJS1937	CONNECTOR (FEMALE)	1	
		TRANSISTOR		
Q7501	2SD601	TRANSISTOR CHIP	1	
		COMBINATION PARTS		
QR7501	UN2112	TRANSISTOR-RESISTOR	1	
QR7509	UN2113	TRANSISTOR-RESISTOR	1	
QR7510, 11	UN2213	TRANSISTOR-RESISTOR	2	
		RESISTORS		
R6701	ERDS2TJ154	C. RESISTOR 1/4W 150K	1	
R6702	ERDS2TJ8R2	C. RESISTOR 1/4W 8.2	1	
R7501	ERJ6GMYJ122	CHIP 1/16W 1.2K	1	
R7502	ERJ6GMYJ224	CHIP 1/16W 220K	1	
R7503	ERJ6GMYJ473	CHIP 1/16W 47K	1	
R7504	ERJ6GMYJ103	CHIP 1/16W 10K	1	
R7505	ERJ6GMYJ473	CHIP 1/16W 47K	1	
R7509	ERJ6GMYJ223	CHIP 1/16W 22K	1	
R7510	ERJ6GMYJ102	CHIP 1/16W 1K	1	
R7511-14	ERJ6GMYJ182	CHIP 1/16W 1.8K	4	
R7515	ERJ6GMYJ102	CHIP 1/16W 1K	1	
R7519	ERJ6GMYJ104	CHIP 1/16W 100K	1	
R7520-22	ERJ6GMYJ103	CHIP 1/16W 10K	3	
R7523	ERDS1TJ120	C. RESISTOR 1/2W 12	1	
R7530	ERJ6GMYJ332	CHIP 1/16W 3.3K	1	
R7532	ERJ6GMYJ473	CHIP 1/16W 47K	1	
R7538	ERJ6GMYJ221	CHIP 1/16W 220	1	
R7540	ERJ6GMYJ473	CHIP 1/16W 47K	1	
R7543	ERJ6GMYJ102	CHIP 1/16W 1K	1	
		SWITCH		
SW7539	EVQGS307K	SWITCH	1	
		VARIABLE RESISTOR		
VR6701	EVMLGGA00B15	V. RESISTOR 100K	1	
		CRYSTAL OSCILLATORS		
X7501	VXS0140A	CRYSTAL OSCILLATOR	1	
X7502	VXS0094A	CRYSTAL OSCILLATOR	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
		MISCELLANEOUS		
	VJF0398	FIP HOLDER	1	
	VEP03528A	SUB DIGITAL C.B.A.		(NLA)
		CAPACITORS		
C9001	ECEA1HK4R7	E. CAPACITOR 50V 4.7U	1	
C9003	ECEA0JK101	E. CAPACITOR 6.3V 100U	1	
C9004, 05	ECUX1H104ZFN	CHIP 50V 0.1U	2	
C9006	ECEA0JK101	E. CAPACITOR 6.3V 100U	1	
C9007	ECEA1HK4R7	E. CAPACITOR 50V 4.7U	1	
C9009	ECEA0JK101	E. CAPACITOR 6.3V 100U	1	
C9010, 11	ECUX1H104ZFN	CHIP 50V 0.1U	2	
C9012	ECEA0JK101	E. CAPACITOR 6.3V 100U	1	
C9013-15	ECUX1H104ZFN	CHIP 50V 0.1U	3	
C9016	ECEA0JK470	E. CAPACITOR 6.3V 47U	1	
C9017	ECUX1H104ZFN	CHIP 50V 0.1U	1	
C9018-20	ECEA0JK470	E. CAPACITOR 6.3V 47U	3	
C9021	ECUX1H104ZFN	CHIP 50V 0.1U	1	
C9022, 23	ECUM1H221KBN	C. CAPACITOR CH 50V 220P	2	
C9024	ECUX1H104ZFN	CHIP 50V 0.1U	1	
C9025	ECEA1HK0R1	E. CAPACITOR 50V 0.1U	1	
C9026	ECUX1H104ZFN	CHIP 50V 0.1U	1	
C9027, 28	ECUM1H221KBN	C. CAPACITOR CH 50V 220P	2	
C9029	ECUX1H104ZFN	CHIP 50V 0.1U	1	
C9030	ECEA1HK0R1	E. CAPACITOR 50V 0.1U	1	
C9031	ECEA0JK101	E. CAPACITOR 6.3V 100U	1	
C9032	ECEA0JK221	E. CAPACITOR 6.3V 220U	1	
C9033, 34	ECUX1H104ZFN	CHIP 50V 0.1U	2	
C9035	ECEA1HK0R1	E. CAPACITOR 50V 0.1U	1	
C9036	ECEA0JK470	E. CAPACITOR 6.3V 47U	1	
C9037	ECUX1H104ZFN	CHIP 50V 0.1U	1	
C9038	ECEA1CK100	E. CAPACITOR 16V 10U	1	
C9039	ECEA0JK330	E. CAPACITOR 6.3V 33U	1	
C9040, 41	ECUX1H104ZFN	CHIP 50V 0.1U	2	
C9042	ECEA1CK100	E. CAPACITOR 16V 10U	1	
C9043	ECUX1H104ZFN	CHIP 50V 0.1U	1	
C9044	ECEA0JK221	E. CAPACITOR 6.3V 220U	1	
C9045-53	ECUX1H104ZFN	CHIP 50V 0.1U	9	
C9054	ECEA0JK470	E. CAPACITOR 6.3V 47U	1	
C9055	ECUM1H103KBN	CHIP 50V 0.01U	1	
C9056, 57	ECUM1H221KBN	C. CAPACITOR CH 50V 220P	2	
C9058	ECEA0JK221	E. CAPACITOR 6.3V 220U	1	
C9501	ECEA0JK470	E. CAPACITOR 6.3V 47U	1	
C9502	ECUM1H152KBN	CHIP 50V 1500P	1	
C9503	ECUM1H221KBN	C. CAPACITOR CH 50V 220P	1	
C9504	ECEA1HK010	E. CAPACITOR 50V 1U	1	
C9507	ECEA1EKN3R3	ELECTROLYTIC 25V 3.3U	1	
C9508	ECEA1CK470	E. CAPACITOR 16V 47U	1	
C9509	ECUX1H104ZFN	CHIP 50V 0.1U	1	
C9510	ECUM1H332KBN	CHIP 50V 3300P	1	
C9511	ECUM1H1032FN	CHIP 50V 0.01U	1	
C9512	ECEA1EK3R3	E. CAPACITOR 25V 3.3U	1	
C9513	ECEA1HK2R2	E. CAPACITOR 50V 2.2U	1	
C9514	ECEA1EK3R3	E. CAPACITOR 25V 3.3U	1	
C9515	ECEA0JK470	E. CAPACITOR 6.3V 47U	1	
C9516	ECUX1H104ZFN	CHIP 50V 0.1U	1	
C9517	ECEA1HKR22	E. CAPACITOR 50V 0.22U	1	
C9519	ECUM1H220JCN	CHIP 50V 22P	1	
C9520, 21	ECUM1H151JCN	CHIP 50V 150P	2	
C9522	ECEA1HK2R2	E. CAPACITOR 50V 2.2U	1	
C9523	ECEA1EK3R3	E. CAPACITOR 25V 3.3U	1	
C9524	ECEA1HK010	E. CAPACITOR 50V 1U	1	
C9525	ECUM1H100DCN	CHIP 50V 10P	1	
C9527	ECUM1H1032FN	CHIP 50V 0.01U	1	
C9528, 29	ECUM1H221KBN	C. CAPACITOR CH 50V 220P	2	
C9530, 31	ECUM1H1032FN	CHIP 50V 0.01U	2	
C9532	ECUX1H104ZFN	CHIP 50V 0.1U	1	
C9533	ECUM1H1032FN	CHIP 50V 0.01U	1	

To guarantee the FUNCTION, SAFETY and RELIABILITY of repaired units, only use ORIGINAL REPLACEMENT PARTS which are listed with their part numbers in this parts list section.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
C9534-36	ECUX1H1042FN	CHIP 50V 0.1U	3		FL9016	VLFO523	FILTER	1	
C9537	ECEA1HKR47	E. CAPACITOR 50V 0.47U	1		FL9017	VLFO526	FILTER	1	
C9538	ECUX1H1042FN	CHIP 50V 0.1U	1		FL9018-22	ELXTS101GA	FILTER	5	
C9539	ECEA1EKN3R3	ELECTROLYTIC 25V 3.3U	1		FL9023	VLFO523	FILTER	1	
C9540	ECUM1H331KBN	CHIP 50V 330P	1		FL9025	VLFO523	FILTER	1	
C9541	ECEA0JK470	E. CAPACITOR 6.3V 47U	1		FL9026, 27	ELXTS101GA	FILTER	2	
C9542, 43	ECUM1H391KBN	CHIP 50V 390P	2		FL9028	VLFO523	FILTER	1	
C9544, 45	ECEA1HK2R2	E. CAPACITOR 50V 2.2U	2		FL9501	ELB4T023	FILTER	1	
C9546	ECQB1H102JH	P. CAPACITOR 50V 1000P	1						
C9547	ECQV1H473JZ	P. CAPACITOR 50V 0.047U	1						
C9548	ECQB1H152JH	P. CAPACITOR 50V 1500P	1				ICS		
C9549	ECEA1EK4R7	E. CAPACITOR 25V 4.7U	1		IC9001	MN52040VZS	IC	1	
C9550	ECQV1H683JZ	P. CAPACITOR 50V 0.068U	1		IC9002, 03	TMS446112SDL	IC	2	
C9551	ECQB1H103JH	P. CAPACITOR 50V 0.01U	1		IC9004	MN15522VPG	IC	1	
C9552	ECQV1H104JZ	P. CAPACITOR 50V 0.1U	1		IC9005-07	MN65523A	IC	3	
C9554	ECEA1HK010	E. CAPACITOR 50V 1U	1		IC9008, 09	MN74HC4066S	IC	2	
C9555	ECQB1H103JH	P. CAPACITOR 50V 0.01U	1		IC9010	UPD6951C	IC	1	
C9556	ECQP1H562JZ	P. CAPACITOR 50V 5600P	1		IC9011, 12	MN6790	IC	2	
C9557	ECEA1CK470	E. CAPACITOR 16V 47U	1		IC9013	MN1280	IC	1	
C9558	ECQB1H102JH	P. CAPACITOR 50V 1000P	1		IC9014	AN78L05	IC	1	
C9559	ECQV1H473JZ	P. CAPACITOR 50V 0.047U	1		IC9501	BA7044N	IC	1	
C9560	ECQB1H152JH	P. CAPACITOR 50V 1500P	1		IC9503	MN4066BS	IC	1	
C9561	ECEA1EK4R7	E. CAPACITOR 25V 4.7U	1		IC9504	MN4053BS	IC	1	
C9562	ECQV1H683JZ	P. CAPACITOR 50V 0.068U	1		IC9505	AN3211S	IC	1	
C9563	ECQB1H103JH	P. CAPACITOR 50V 0.01U	1		IC9506	AN3171S	IC	1	
C9564	ECQV1H104JZ	P. CAPACITOR 50V 0.1U	1		IC9507, 08	LA7800	IC	2	
C9566	ECEA1HK010	E. CAPACITOR 50V 1U	1		IC9509	AN3171S	IC	1	
C9567	ECQB1H103JH	P. CAPACITOR 50V 0.01U	1		IC9510	AN3181S	IC	1	
C9568	ECQP1H562JZ	P. CAPACITOR 50V 5600P	1						
C9569	ECEA1CK470	E. CAPACITOR 16V 47U	1						
C9572	ECEA0JK470	E. CAPACITOR 6.3V 47U	1				COILS		
C9573	ECUX1H1042FN	CHIP 50V 0.1U	1		L9002, 03	VLQEL05F101K	COIL 100UH	2	
C9574	ECUM1H220JCN	CHIP 50V 22P	1		L9004, 05	VLQEL05F271K	COIL 270UH	2	
C9575	ECUM1H221KBN	C. CAPACITOR CH 50V 220P	1		L9006-08	VLPO054	COIL	3	
C9576	ECUM1H1032FN	CHIP 50V 0.01U	1		L9501, 02	VLQEL05F101K	COIL 100UH	2	
C9577, 78	ECUM1H151JCN	CHIP 50V 150P	2		L9503	VLQEL05F560K	COIL 56UH	1	
C9579	ECUM1H100DCN	CHIP 50V 10P	1		L9504	VLQEL05F331K	COIL 330UH	1	
C9580, 81	ECUM1H1032FN	CHIP 50V 0.01U	2		L9505	EIK7EN011B	COIL 10H	1	
C9582	ECEA1EK3R3	E. CAPACITOR 25V 3.3U	1		L9506	EIK7EN012B	COIL 100H	1	
C9583-85	ECUX1H1042FN	CHIP 50V 0.1U	3		L9507, 08	VLQEL05F681K	COIL 680UH	2	
C9586	ECEA1HKR47	E. CAPACITOR 50V 0.47U	1		L9509-12	VLQEL05F101K	COIL 100UH	4	
C9587	ECUX1H1042FN	CHIP 50V 0.1U	1		L9513	VLQEL05F560K	COIL 56UH	1	
C9588	ECEA1EKN3R3	ELECTROLYTIC 25V 3.3U	1		L9514	VLQEL05F331K	COIL 330UH	1	
C9589, 90	ECUM1H221KBN	C. CAPACITOR CH 50V 220P	2		L9515	VLQEL05F560K	COIL 56UH	1	
C9591	ECUM1H331KBN	CHIP 50V 330P	1		L9517, 18	VLQEL05F101K	COIL 100UH	2	
C9593-95	ECUX1H1042FN	CHIP 50V 0.1U	3						
C9596	ECEA1HK010	E. CAPACITOR 50V 1U	1						
C9597	ECEA1CK100	E. CAPACITOR 16V 10U	1				CONNECTORS		
C9598	ECUM1H220JCN	CHIP 50V 22P	1		P9501	VJP1250T	CONNECTOR (MALE) 10P	1	
C9599, 00	ECUM1H223KBN	C. CAPACITOR CH 50V 0.022U	2		P9502	VJP1244T	CONNECTOR (MALE) 4P	1	
C9601	ECEA0JK470	E. CAPACITOR 6.3V 47U	1						
C9602	ECEA1CK100	E. CAPACITOR 16V 10U	1						
C9603	ECEA1CK470	E. CAPACITOR 16V 47U	1				TRANSISTORS		
C9606	ECUM1H331JCN	C. CAPACITOR CH 50V 330P	1		Q9001-03	2SD601	TRANSISTOR CHIP	3	
C9610	ECEA1HK010	E. CAPACITOR 50V 1U	1		Q9004-06	2SB709	TRANSISTOR CHIP	3	
C9611	ECUM1H181JCN	C. CAPACITOR CH 50V 180P	1		Q9501, 02	2SD601	TRANSISTOR CHIP	2	
C9612	ECUM1H030DCN	CHIP 50V 3P	1		Q9503	2SC2295	TRANSISTOR	1	
					Q9504, 05	2SB709	TRANSISTOR CHIP	2	
					Q9506	2SD601	TRANSISTOR CHIP	1	
					Q9508, 09	2SB709	TRANSISTOR CHIP	2	
		DIODES			Q9510	2SC2295	TRANSISTOR	1	
D9001	MA165	DIODE	1		Q9511	2SD601	TRANSISTOR CHIP	1	
D9501, 02	MA178	DIODE	2		Q9512, 13	2SB709	TRANSISTOR CHIP	2	
					Q9516	2SB709	TRANSISTOR CHIP	1	
					Q9517	2SD601	TRANSISTOR CHIP	1	
		DELAY			Q9518-21	2SB709	TRANSISTOR CHIP	4	
DL9501	EFDEN645A31F	DELAY	1		Q9522	2SD601	TRANSISTOR CHIP	1	
					Q9523, 24	2SB709	TRANSISTOR CHIP	2	
					Q9525, 26	2SD601	TRANSISTOR CHIP	2	
		FILTERS			Q9527-29	2SB709	TRANSISTOR CHIP	3	
FL9001	ELB4S030	FILTER	1		Q9530	2SD601	TRANSISTOR CHIP	1	
FL9002-05	ELXTS101GA	FILTER	4		Q9531	2SB709	TRANSISTOR CHIP	1	
FL9006-08	VLFO526	FILTER	3		Q9532	2SD601	TRANSISTOR CHIP	1	
FL9009	VLFO523	FILTER	1						
FL9010, 11	ELXTS101GA	FILTER	2						
FL9013-15	VLFO526	FILTER	3						

To guarantee the FUNCTION, SAFETY and RELIABILITY of repaired units, only use ORIGINAL REPLACEMENT PARTS which are listed with their part numbers in this parts list section.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
		COMBINATION PARTS							
QR9001	UN2212	TRANSISTOR-RESISTOR	1		R9547	ERJ6GMXJ182	CHIP 1/16W 1.8K	1	
QR9501	UN2111	TRANSISTOR-RESISTOR	1		R9548	ERJ6GMXJ102	CHIP 1/16W 1K	1	
QR9502,03	UN2213	TRANSISTOR-RESISTOR	2		R9549	ERJ6GMXJ182	CHIP 1/16W 1.8K	1	
QR9504	UN2212	TRANSISTOR-RESISTOR	1		R9550	ERJ6GMXJ102	CHIP 1/16W 1K	1	
QR9505	UN2211	TRANSISTOR-RESISTOR	1		R9551	ERJ6GMXJ103	CHIP 1/16W 10K	1	
QR9506	UN2111	TRANSISTOR-RESISTOR	1		R9552	ERJ6GMXJ221	CHIP 1/16W 220	1	
QR9507	UN2211	TRANSISTOR-RESISTOR	1		R9553	ERJ6GMXJ334	CHIP 1/16W 330K	1	
QR9508	UN2111	TRANSISTOR-RESISTOR	1		R9554	ERJ6GMXJ822	CHIP 1/16W 8.2K	1	
QR9509,10	UN2213	TRANSISTOR-RESISTOR	2		R9555	ERJ6GMXJ123	CHIP 1/16W 12K	1	
					R9556	ERJ6GMXJ103	CHIP 1/16W 10K	1	
					R9557,58	ERJ6GMXJ224	CHIP 1/16W 220K	2	
					R9559	ERJ6GMXJ222	CHIP 1/16W 2.2K	1	
					R9560,61	ERJ6GMXJ123	CHIP 1/16W 12K	2	
		RESISTORS			R9562	ERJ6GMXJ563	CHIP 1/16W 56K	1	
R9001	ERJ6GMXJ470	M.RESISTOR CH1/16W 47	1		R9563	ERJ6GMXJ102	CHIP 1/16W 1K	1	
R9002	ERJ6GMXJ561	CHIP 1/16W 560	1		R9564	ERJ6GMXJ103	CHIP 1/16W 10K	1	
R9003	ERJ6GMXJ470	M.RESISTOR CH1/16W 47	1		R9565	ERJ6GMXJ221	CHIP 1/16W 220	1	
R9004-07	ERJ6GMXJ561	CHIP 1/16W 560	4		R9566	ERJ6GMXJ334	CHIP 1/16W 330K	1	
R9008	ERJ6GMXJ182	CHIP 1/16W 1.8K	1		R9567	ERJ6GMXJ822	CHIP 1/16W 8.2K	1	
R9009	ERJ6GMXJ332	CHIP 1/16W 3.3K	1		R9568	ERJ6GMXJ123	CHIP 1/16W 12K	1	
R9010	EROS2CKG1800	M.RESISTOR 1/4W 180	1		R9569	ERJ6GMXJ103	CHIP 1/16W 10K	1	
R9011,12	EROS2CKG68R0	M.RESISTOR 1/4W 68.0	2		R9570,71	ERJ6GMXJ224	CHIP 1/16W 220K	2	
R9013	EROS2CKG82R0	M.RESISTOR 1/4W 82.0	1		R9572	ERJ6GMXJ222	CHIP 1/16W 2.2K	1	
R9014-18	ERJ6GMXJ821	CHIP 1/16W 820	5		R9573,74	ERJ6GMXJ123	CHIP 1/16W 12K	2	
R9019	ERJ6GMXJ391	CHIP 1/16W 390	1		R9575	ERJ6GMXJ563	CHIP 1/16W 56K	1	
R9020	ERJ6GMXG202	M.RESISTOR CH1/16W 2K	1		R9576	ERJ6GMXJ102	CHIP 1/16W 1K	1	
R9021	ERJ6GMXJ102	CHIP 1/16W 1K	1		R9582,83	ERJ6GMXJ102	CHIP 1/16W 1K	2	
R9022	ERDS2TJ102	C.RESISTOR 1/4W 1K	1		R9584	ERJ6GMXJ222	CHIP 1/16W 2.2K	1	
R9023	ERDS1TJ470	C.RESISTOR 1/2W 47	1		R9585	ERJ6GMXJ331	CHIP 1/16W 330	1	
R9024-32	ERJ6GMXJ101	CHIP 1/16W 100	9		R9586	ERJ6GMXJ683	CHIP 1/16W 68K	1	
R9034-42	ERJ6GMXJ101	CHIP 1/16W 100	9		R9587	ERJ6GMXJ102	CHIP 1/16W 1K	1	
R9044	ERJ6GMXJ333	CHIP 1/16W 33K	1		R9588,89	ERJ6GMXJ222	CHIP 1/16W 2.2K	2	
R9045	ERJ6GMXJ183	CHIP 1/16W 18K	1		R9590	ERJ6GMXJ471	CHIP 1/16W 470	1	
R9046,47	ERJ6GMXJ103	CHIP 1/16W 10K	2		R9591	ERJ6GMXJ331	CHIP 1/16W 330	1	
R9048,49	ERJ6GMXJ101	CHIP 1/16W 100	2		R9592	ERJ6GMXJ224	CHIP 1/16W 220K	1	
R9501	ERJ6GMXJ123	CHIP 1/16W 12K	1		R9593	ERJ6GMXJ103	CHIP 1/16W 10K	1	
R9502	ERJ6GMXJ272	CHIP 1/16W 2.7K	1		R9594	ERJ6GMXJ124	CHIP 1/16W 120K	1	
R9503	ERJ6GMXJ182	CHIP 1/16W 1.8K	1		R9595	ERJ6GMXJ223	CHIP 1/16W 22K	1	
R9505	ERJ6GMXJ223	CHIP 1/16W 22K	1		R9596	ERJ6GMXJ392	CHIP 1/16W 3.9K	1	
R9506	ERJ6GMXJ103	CHIP 1/16W 10K	1		R9597	ERJ6GMXJ562	CHIP 1/16W 5.6K	1	
R9507	ERJ6GMXJ222	CHIP 1/16W 2.2K	1		R9598	ERJ6GMXJ153	CHIP 1/16W 15K	1	
R9508	ERJ6GMXJ152	CHIP 1/16W 1.5K	1		R9599	ERJ6GMXJ221	CHIP 1/16W 220	1	
R9509	ERJ6GMXJ681	CHIP 1/16W 680	1		R9600	ERJ6GMXJ102	CHIP 1/16W 1K	1	
R9510	ERJ6GMXJ102	CHIP 1/16W 1K	1		R9601	ERJ6GMXJ273	CHIP 1/16W 27K	1	
R9511	ERJ6GMXJ222	CHIP 1/16W 2.2K	1		R9602	ERJ6GMXJ223	CHIP 1/16W 22K	1	
R9512	ERJ6GMXJ562	CHIP 1/16W 5.6K	1		R9603	ERJ6GMXJ222	CHIP 1/16W 2.2K	1	
R9513,14	ERJ6GMXJ223	CHIP 1/16W 22K	2		R9604	ERJ6GMXJ152	CHIP 1/16W 1.5K	1	
R9515	ERJ6GMXJ152	CHIP 1/16W 1.5K	1		R9605	ERJ6GMXG103	CHIP 1/16W 10K	1	
R9516	ERJ6GMXJ102	CHIP 1/16W 1K	1		R9606	ERJ6GMXG123	M.RESISTOR CH1/16W 12K	1	
R9517	ERJ6GMXJ122	CHIP 1/16W 1.2K	1		R9607-09	ERJ6GMXJ332	CHIP 1/16W 3.3K	3	
R9518	ERJ6GMXJ272	CHIP 1/16W 2.7K	1		R9610	ERDS1TJ391	C.RESISTOR 1/2W 390	1	
R9519	ERJ6GMXJ392	CHIP 1/16W 3.9K	1		R9611	ERJ6GMXJ104	CHIP 1/16W 100K	1	
R9520	ERJ6GMXJ332	CHIP 1/16W 3.3K	1		R9612	ERJ6GMXJ103	CHIP 1/16W 10K	1	
R9522	ERJ6GMXJ152	CHIP 1/16W 1.5K	1		R9613	ERJ6GMXJ273	CHIP 1/16W 27K	1	
R9523	ERJ6GMXJ102	CHIP 1/16W 1K	1		R9614	ERJ6GMXJ102	CHIP 1/16W 1K	1	
R9524	ERJ6GMXJ821	CHIP 1/16W 820	1		R9615	ERJ6GMXJ221	CHIP 1/16W 220	1	
R9525,26	ERJ6GMXJ102	CHIP 1/16W 1K	2		R9616	ERJ6GMXJ102	CHIP 1/16W 1K	1	
R9527	ERJ6GMXJ222	CHIP 1/16W 2.2K	1		R9617	ERJ6GMXJ681	CHIP 1/16W 680	1	
R9528	ERJ6GMXJ331	CHIP 1/16W 330	1		R9618	ERJ6GMXJ471	CHIP 1/16W 470	1	
R9529	ERJ6GMXJ683	CHIP 1/16W 68K	1		R9619	ERJ6GMXJ123	CHIP 1/16W 12K	1	
R9530,31	ERJ6GMXJ223	CHIP 1/16W 22K	2		R9620	ERJ6GMXJ272	CHIP 1/16W 2.7K	1	
R9532	ERJ6GMXJ103	CHIP 1/16W 10K	1		R9621	ERJ6GMXJ182	CHIP 1/16W 1.8K	1	
R9533	ERJ6GMXJ332	CHIP 1/16W 3.3K	1		R9622	ERJ6GMXJ221	CHIP 1/16W 220	1	
R9534	ERJ6GMXJ102	CHIP 1/16W 1K	1		R9623	ERJ6GMXJ152	CHIP 1/16W 1.5K	1	
R9535	ERJ6GMXJ221	CHIP 1/16W 220	1		R9624	ERJ6GMXJ472	CHIP 1/16W 4.7K	1	
R9537	ERJ6GMXJ122	CHIP 1/16W 1.2K	1		R9625	ERJ6GMXJ562	CHIP 1/16W 5.6K	1	
R9538	ERJ6GMXJ391	CHIP 1/16W 390	1		R9626	ERJ6GMXJ222	CHIP 1/16W 2.2K	1	
R9539	ERJ6GMXJ471	CHIP 1/16W 470	1		R9627	ERJ6GMXJ560	M.RESISTOR CH1/16W 56	1	
R9540	ERJ6GMXJ224	CHIP 1/16W 220K	1		R9628	ERJ6GMXJ562	CHIP 1/16W 5.6K	1	
R9541	ERJ6GMXJ103	CHIP 1/16W 10K	1		R9629	ERJ6GMXJ222	CHIP 1/16W 2.2K	1	
R9542	ERJ6GMXJ223	CHIP 1/16W 22K	1		R9630	ERJ6GMXJ560	M.RESISTOR CH1/16W 56	1	
R9543	ERJ6GMXJ124	CHIP 1/16W 120K	1		R9631	ERQ12HJ1R2P	FUSE 1/2W 1.2	1	
R9544	ERJ6GMXJ392	CHIP 1/16W 3.9K	1						
R9545	ERJ6GMXJ562	CHIP 1/16W 5.6K	1						
R9546	ERJ6GMXJ153	CHIP 1/16W 15K	1				VARIABLE RESISTORS		

To guarantee the FUNCTION, SAFETY and RELIABILITY of repaired units, only use ORIGINAL REPLACEMENT PARTS which are listed with their part numbers in this parts list section.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
VR9501	EVND4AA00B54	V.RESISTOR	50K	1					
VR9502	EVND4AA00B14	V.RESISTOR	10K	1					
VR9503	EVN38CA00B14	V.RESISTOR	10K	1			COILS		
VR9504	EVND4AA00B13	V.RESISTOR	1K	1	L1001	ELF18D221F	COIL	1	NV-D48EG
VR9505	EVN38CA00B25	V.RESISTOR	200K	1	L1001	ELF18D290A	COIL	1	NV-D48B
VR9506	EVN38CA00B53	V.RESISTOR	5K	1	L1002	ELC07D220	COIL	22U	1
VR9507	EVN38CA00B25	V.RESISTOR	200K	1					
VR9508	EVN38CA00B53	V.RESISTOR	5K	1			CONNECTOR		
VR9509	EVN38CA00B14	V.RESISTOR	10K	1	P1001	VJP1929T	CONNECTOR (MALE)	1	
VR9510	EVND4AA00B13	V.RESISTOR	1K	1					
							TRANSISTORS		
		CRYSTAL OSCILLATORS			Q1001	STRD1806E	TRANSISTOR	1	<1>
X9001	EFOFC3584A5	CRYSTAL OSCILLATOR	1		Q1002	2SD1856DUA	TRANSISTOR	1	
X9501	VSK0265	CRYSTAL OSCILLATOR	1		Q1003	2SD1275	TRANSISTOR	1	
X9502,03	VSK0225	CRYSTAL OSCILLATOR	2		Q1004	2SD1330	TRANSISTOR	1	
					Q1006	2SD1330	TRANSISTOR	1	(S,T)
	■ VEP01310H	POWER C.B.A.		NV-D48EG<1>(NLA)			COMBINATION PARTS		
	■ VEP01310J			NV-D48B<1>(NLA)	QR1001	DTA143	TRANSISTOR-RESISTOR	1	
							RESISTORS		
		CAPACITORS			R1001	ERC12GM334	S.RESISTOR 1/2W 330K	1	<1>
C1001	ECQU2A224MNB	P.CAPACITOR 100V 0.22U	1	NV-D48EG	R1002	ERG1SJ823	M.RESISTOR 1W 82K	1	
C1001	ECQU2A683MNB	P.CAPACITOR 100V 0.068U	1	NV-D48B	R1003	ERG2SJ823	M.RESISTOR 2W 82K	1	
C1002	ECQU2A104MNB	M.CAPACITOR 100V 0.01U	1		R1004	ERW2PMR39	WIRE WOUND 2W 0.39	1	
C1003	ECEA2AG6D10	E.CAPACITOR 100V 1U	1		R1005,06	ERDS2TJ563	C.RESISTOR 1/4W 56K	2	
C1004,05	VCC0016	CAPACITOR	2		R1007	ERDS2TJ100	C.RESISTOR 1/4W 10	1	
C1006-08	VCC0021	CAPACITOR	3		R1008	ERG2SJ181	M.RESISTOR 2W 180	1	
C1009	ECOS2GU820B	E.CAPACITOR 400V 82U	1		R1012	ERG3ANJ683	M.RESISTOR 3W 68K	1	
C1010	ECKD3D331KB	C.CAPACITOR 2KV 330P	1		R1013	ERF2AK2R2	W.RESISTOR 2W 2.2	1	
C1011	ECQE6473M2	P.CAPACITOR 630V 0.047U	1		R1014	ERDS2TJ153	C.RESISTOR 1/4W 15K	1	
C1012	ECEA1CGE470	E.CAPACITOR 16V 47U	1		R1015,16	ERDS2TJ102	C.RESISTOR 1/4W 1K	2	
C1013	ECEA1AGE470	E.CAPACITOR 10V 47U	1		R1017	ERDS2TJ103	C.RESISTOR 1/4W 10K	1	
C1014	ECQB1H472KH	P.CAPACITOR 50V 4700P	1		R1018	ERDS2TJ562	C.RESISTOR 1/4W 5.6K	1	
C1016	ECQP1101T404	M.CAPACITOR 100V 100P	1		R1019	ERG12ANJ332	M.RESISTOR 1/2W 3.3K	1	
C1017	ECEA1DF26812	E.CAPACITOR 20V 680U	1		R1021	ERX1SJR20	M.RESISTOR 1W 0.20	1	
C1018	ECEA1HGE100	E.CAPACITOR 50V 10U	1		R1022	ERDS2TJ681	C.RESISTOR 1/4W 680	1	
C1019	ECEA1AFZ331	E.CAPACITOR 10V 330U	1		R1023	ERDS2TJ103	C.RESISTOR 1/4W 10K	1	
C1020	ECEA0JEE331	E.CAPACITOR 6.3V 330U	1						
C1021	ECEA1HGE101	E.CAPACITOR 50V 100U	1				TRANSFORMER		
C1022	ECEA1DF26812	E.CAPACITOR 20V 680U	1		T1001	VLT0508	TRANSFORMER	1	<1>
C1023-25	ECKP1H1032F	C.CAPACITOR 50V 0.01U	3						
C1026	ECEA1HGE100	E.CAPACITOR 50V 10U	1				■ VEP66039C	DIGITAL SCANNER C.B.A.	NV-D48EG(NLA)
C1027	ECKP1H1032F	C.CAPACITOR 50V 0.01U	1				■ VEP66039B		NV-D48B(NLA)
C1028	ECEA1CGE100	E.CAPACITOR 16V 10U	1						
C1029	ECEA1AGE101	E.CAPACITOR 10V 100U	1						
C1031	ECKP1H1032F	C.CAPACITOR 50V 0.01U	1						
C1032	ECEA1CGE100	E.CAPACITOR 16V 10U	1						
C1033	ECEA1CGE101	E.CAPACITOR 16V 100U	1						
C1034	ECEA1AGE101	E.CAPACITOR 10V 100U	1						
C1035	ECQV1H474J2	P.CAPACITOR 50V 0.47U	1						
							CAPACITORS		
		DIODES			CO1	ECEV1CA470P	E.CAPACITOR 16V 47U	1	
D1001	ENB461D-05A	SURGE ABSORBER 460V	1		CO2	ECEV1HAN010R	E.CAPACITOR 50V 1U	1	
D1002	MA178	DIODE	1		CO3,04	ECUX1E1042FM	CHIP 25V 0.1U	2	
D1004	S1WBA60	DIODE	1		CO5	ECSE1CY1052R	TANTALUM 16V 1U	1	
D1007	11EFS4	DIODE	1		CO6	ECEV1CA470P	E.CAPACITOR 16V 47U	1	
D1008	RL42LF	DIODE	1		CO7,08	ECUX1H330JCN	CHIP 50V 33P	2	
D1009	MA185	DIODE	1		CO9-12	ECUX1H1032FN	CHIP 50V 0.01U	4	
D1010	FMG14	DIODE	1						
D1011	AKO4V2	DIODE	1						
D1012	MA2200B	ZENER	1				DIODES		
D1013	MA4130L	DIODE	1		DO1	MA151WK	DIODE	1	
D1014	VSD0002	DIODE	1		DO4	MA151WK	DIODE	1	
D1015	AP01CV2	DIODE	1		DO5	MA153	DIODE	1	
D1016	MA4062H	DIODE	1		DO6	SE303ACY	DIODE	1	
D1017	SV03YS	DIODE	1						
							ICS		
IC1001	STK5339A	IC	1		IC01	MN158453VPB	IC	1	

To guarantee the FUNCTION,SAFETY and RELIABILITY of repaired units,only use ORIGINAL REPLACEMENT PARTS which are listed with their part numbers in this parts list section.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
IC02	UPC324G2	IC	1			■ VEP66030C	PROGRAMMABLE REMOTE CONTROLLER C.B.A.		(NLA)
IC03	RC78L02UAA1	IC	1						
		COIL							
LO1	ELT3K017B	COIL	1				CAPACITORS		
		LCD			C1	ECEA0GKS101	E.CAPACITOR 4V 100U	1	
LCD01	VSL0131A	LCD	1		C2,C3	ECKF1H121KB	C.CAPACITOR 50V 120P	2	
		TRANSISTORS			C4	EQQB1H222KH	P.CAPACITOR 50V 2200P	1	
Q01,02	2SB710	TRANSISTOR CHIP	2 (Q,R,S)				DIODES		
Q03	2SB709	TRANSISTOR CHIP	1 (Q,R,S)		D1	LN66	DIODE	1	
Q05	2SB709	TRANSISTOR CHIP	1 (Q,R,S)		D2-D9	MA165	DIODE	8	
		COMBINATION PART			D10,11	MA165	DIODE	2	
QR04	FALL4Z	TRANSISTOR-RESISTOR	1				IC		
		RESISTORS			IC1	MN6011M	IC	1	
R01	ERJ6GMYJ560	CHIP 1/16W 56	1				COMBINATION PART		
R02	ERJ6GMYJ102	CHIP 1/16W 1K	1		QR1	UN1231	TRANSISTOR-RESISTOR	1	
R03	ERJ6GMYJ153	CHIP 1/16W 15K	1				RESISTOR		
R04	ERJ6GMYJ332	CHIP 1/16W 3.3K	1		R1	ERDS2TJ1R0	C.RESISTOR 1/4W 1.0	1	
R05	ERJ6GMYJ202	CHIP 1/16W 2K	1				CRYSTAL OSCILLATOR		
R06	ERJ6GMYJ244	CHIP 1/16W 240K	1		X1	VSX0201	CRYSTAL OSCILLATOR	1	
R07	ERJ6GMYJ162	CHIP 1/16W 1.6K	1				MISCELLANEOUS		
R08	ERJ6GMYJ224	CHIP 1/16W 220K	1			VJR0253	ELECTRODE (+)	1	
R09	ERJ6GMYJ474	CHIP 1/16W 470K	1			VJR0254	ELECTRODE (-)	1	
R10	ERJ6GMYK106	CHIP 1/16W 10M	1			■ VEK3583	MECHANISM CONNECTION C.B.A.		(NLA)
R11	ERJ6GMYJ105	CHIP 1/16W 1M	1				CONNECTORS		
R12	ERJ6GMYK106	CHIP 1/16W 10M	1		P1504	VJS2342	CONNECTOR	1	
R13	ERJ6GMYJ361	CHIP 1/16W 360	1		P1505	VJP1242T	CONNECTOR	1	
R14	ERJ6GMYJ682	CHIP 1/16W 6.8K	1				RESISTORS		
R15	ERJ6GMYJ332	CHIP 1/16W 3.3K	1		R1501	ERDS2TJ223	C.RESISTOR 1/4W 22K	1	
R16,17	ERJ6GMYJ682	CHIP 1/16W 6.8K	2		R1502	ERDS2TJ223	C.RESISTOR 1/4W 22K	1	
R18	ERJ8GCYJ120	CHIP 1/8W 12	1				REEL SENSOR C.B.A.		(NLA)
R19	ERJ6GMYJ474	CHIP 1/16W 470K	1				INTEGRATED CIRCUIT		
R21	ERJ6GMYJ474	CHIP 1/16W 470K	1		IC1501	ON2170	IC	1	
R23	ERJ6GMYJ682	CHIP 1/16W 6.8K	1				CONNECTOR		
R24	ERJ6GMYJ102	CHIP 1/16W 1K	1		P1506	VJP1242T	CONNECTOR	1	
R29	ERJ8GCYJ150	CHIP 1/8W 15	1				LED C.B.A.		(NLA)
		SENSOR							
SN01	VSQ0567	SENSOR	1						
		SWITCHES							
SW01	VSS0126	SWITCH	1						
SW02	EVQ0FV02K	SWITCH	1						
		VARIABLE RESISTOR							
VR09	EVND4KA00B35	V.RESISTOR 300K	1						
		CRYSTAL OSCILLATORS							
X01	VSX0246AT	CRYSTAL OSCILLATOR	1						
X02	EFBAL30D001K	CRYSTAL OSCILLATOR	1						
		MISCELLANEOUS							
	VQ1406	TERMINAL BASE	1						
	VJR0401	TERMINAL ANGLE	2						
	VWX1324	SPACER	1						

To guarantee the FUNCTION,SAFETY and RELIABILITY of repaired units,only use ORIGINAL REPLACEMENT PARTS which are listed with their part numbers in this parts list section.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks	Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
							INTEGRATED CIRCUIT		
		DIODE			IC1	LA7051	IC	1	
D1501	GL450	PHOTO DIODE	1						
							TRANSISTORS		
		MISCELLANEOUS			Q1	2SC2570A	TRANSISTOR	1	
	VMD0911	LED HOLDER	1		Q2	2SC2570A	TRANSISTOR	1	
							NOTE:		
							THE OTHER PARTS FOR		
							RF CONVERTER ARE NOT		
							AVAILABLE AS SPARE PARTS.		
	■ VEK3577	TAKE UP PHOTO Tr. C.B.A.		(NLA)					
		CAPACITOR							
C1502	ECKF1H102KB	C.CAPACITOR 50V 100P	1			■ ENC87962	RF CONVERTER		NV-D48B<1>
		CONNECTOR					DIODES		
P1508	VJS2165	CONNECTOR	1		D1	MA1051	ZENER	1	
					D2	HSM276S	DIODE	1	
					D3	MA166	DIODE	1	
					D4	MA75WK	DIODE	1	
		TRANSISTOR			D5	MA166	DIODE	1	
Q1502	PN150NV	TRANSISTOR	1						
							INTEGRATED CIRCUIT		
		RESISTOR			IC1	LA7051	IC	1	
R1503	ERDS2TJ222	C.RESISTOR 1/4W 2.2K	1						
							TRANSISTORS		
		MISCELLANEOUS			Q1	2SC2570A	TRANSISTOR	1	
	VMD0645	PHOTO Tr. HOLDER	1		Q2	2SC2570A	TRANSISTOR	1	
					Q3	2SC3130	TRANSISTOR	1	
							NOTE:		
							THE OTHER PARTS FOR		
							RF CONVERTER ARE NOT		
							AVAILABLE AS SPARE PARTS.		
	■ VEK3578	SUUPLY PHOTO Tr. C.B.A.		(NLA)					
		CAPACITOR							
C1501	ECKF1H102KB	C.CAPACITOR 50V 1000P	1						
		TRANSISTOR							
Q1501	PN150NV	TRANSISTOR	1						
		MISCELLANEOUS							
	VMD0645	PHOTO Tr. HOLDER	1						
	■ ENC87966	RF CONVERTER		NV-D48EG<1>					
		DIODES							
D1	MA1051	ZENER	1						
D2	HSM276S	DIODE	1						
D3	MA166	DIODE	1						
D4	MA166	DIODE	1						

To guarantee the FUNCTION,SAFETY and RELIABILITY of repaired units,only use ORIGINAL REPLACEMENT PARTS which are listed with their part numbers in this parts list section.